

README.cycladesZ.txt

The Cyclades-Z must have firmware loaded onto the card before it will operate. This operation should be performed during system startup,

The firmware, loader program and the latest device driver code are available from Cyclades at

<ftp://ftp.cyclades.com/pub/cyclades/cyclades-z/linux/>