

reboot.txt

Reboot property to control system reboot on PPC4xx systems:

By setting "reset\_type" to one of the following values, the default software reset mechanism may be overridden. Here the possible values of "reset\_type":

- 1 - PPC4xx core reset
- 2 - PPC4xx chip reset
- 3 - PPC4xx system reset (default)

Example:

```
cpu@0 {  
    device_type = "cpu";  
    model = "PowerPC, 440SPe";  
    ...  
    reset-type = <2>;          /* Use chip-reset */  
};
```