


Work-Package 5: “Demonstrator”

## Automatic Test Runner User manual

**A comprehensive guide for writing and running SRS 330 scenarios.**

Alexis Julin, Didier Weckmann, Nicolas Van Landeghem

February 2015



Funded by:


 Federal Ministry  
 of Education  
 and Research

 Région de  
 Bruxelles-  
 Capitale

 GOBIERNO  
 DE ESPAÑA

 MINISTERIO  
 DE INDUSTRIA, ENERGÍA  
 Y TURISMO

This page is intentionally left blank

**Work-Package 5: “Demonstrator”****OETCS/WP5/M5.3  
February 2015**

# Automatic Test Runner User manual

**A comprehensive guide for writing and running SRS 330 scenarios.****Document approbation**

| Lead author:              | Technical assessor:       | Quality assessor:      | Project lead:                   |
|---------------------------|---------------------------|------------------------|---------------------------------|
| location / date           | location / date           | location / date        | location / date                 |
| signature                 | signature                 | signature              | signature                       |
| Didier Weckmann<br>(ERSA) | Didier Weckmann<br>(ERSA) | Ainhua Gracia<br>(SQS) | Klaus-Rüdiger Hase<br>(DB Netz) |

Alexis Julin, Didier Weckmann, Nicolas Van Landeghem

ERSA  
5 Rue Maurice Blin  
67500 Haguenau, France**Description of work**

Prepared for OpenETCS Project

**Abstract:** This document present how the Automatic Test Runner can be used to execute Baseline 3 scenarios. This document also describe the scenario file format and its syntax.

**Disclaimer:** This work is licensed under the "openETCS Open License Terms" (oOLT) dual Licensing: European Union Public Licence (EURL v.1.1+) AND Creative Commons Attribution-ShareAlike 3.0 – (cc by-sa 3.0)

THE WORK IS PROVIDED UNDER openETCS OPEN LICENSE TERMS (oOLT) WHICH IS A DUAL LICENSE AGREEMENT INCLUDING THE TERMS OF THE EUROPEAN UNION PUBLIC LICENSE (VERSION 1.1 OR ANY LATER VERSION) AND THE TERMS OF THE CREATIVE COMMONS PUBLIC LICENSE ("CCPL"). THE WORK IS PROTECTED BY COPYRIGHT AND/OR OTHER APPLICABLE LAW. ANY USE OF THE WORK OTHER THAN AS AUTHORIZED UNDER THIS OLT LICENSE OR COPYRIGHT LAW IS PROHIBITED.

BY EXERCISING ANY RIGHTS TO THE WORK PROVIDED HERE, YOU ACCEPT AND AGREE TO BE BOUND BY THE TERMS OF THIS LICENSE. TO THE EXTENT THIS LICENSE MAY BE CONSIDERED TO BE A CONTRACT, THE LICENSOR GRANTS YOU THE RIGHTS CONTAINED HERE IN CONSIDERATION OF YOUR ACCEPTANCE OF SUCH TERMS AND CONDITIONS.

<http://creativecommons.org/licenses/by-sa/3.0/>  
<http://joinup.ec.europa.eu/software/page/eupl/licence-eupl>

## Modification History

| Version | Section   | Modification / Description   | Author             |
|---------|-----------|--|--------------------|
| 0.1     | All parts | Creation   | Christophe Menager |
| 1.0     | All parts | Official version   | Christophe Menager |
| 1.1     | All parts | Add option to set SRS language for message   | Eric Schellenberg  |
| 2.0     | All parts | Update for new version with integrated DMI   | Christophe Menager |
| 2.1     | All parts | Correction of driver action  | Eric Schellenberg  |
| 2.2     | All parts | Added new WAIT_ICON and BUTTON commands  | Flavien Bridault   |
| 2.3     | All parts | REGENBRK_ON/OFF, EDDYCUR-RBRK_ON/OFF, MAGNSHOE-BRK_ON/OFF descriptions were erroneous and didn't reflect reality in code | Didier Weckmann    |
| 2.4     | All parts | NTC_MODULE in Config_EVCInit   | Flavien Bridault   |
| 2.5     | All parts | Config_Scenario section  | Flavien Bridault   |
| 2.6     | All parts | Add tests for speed monitoring status  | Stéphane Chenevoy  |
| 2.7     | All parts | Add WAIT_DYNAMIC commands  | Didier Weckmann    |
| 2.8     | All parts | Add EXPECTED_TO_FAIL command   | Didier Weckmann    |
| 2.9     | All parts | Add WAIT_BUTTON ACK_XXX  | Didier Weckmann    |
| 2.10    | All parts | Add EVC_CONFIG, NV_FROM_HEX_BUFFER and COUNTRIES_ID  | Alexis Julin       |
| 2.11    | All parts | Reply to GE comments   | Didier Weckmann    |
| 2.12    | All parts | Add WAIT_TEXT description  | Alexis Julin       |
| 2.13    | All parts | Add CHECK_TRACKCONDITION description   | Alexis Julin       |

# Table of Contents

# Figures and Tables

**Figures**

**Tables**

## 1 Abstract

This document explains how to use the Automatic Test Runner.

The purpose of the Automatic Test Runner is to provide a tool that allows the automatic tests of the on-board simulator with a set of scenarios during developments in order to validate the changes and perform non regression tests.

The tester is a graphical application integrating an on-board and a simplified DMI. It can simulate all interfaces to the EVC (e.g. balises, radio, loops, odometer, TIU and driver interfaces). It can test the internal state of on-board in order to check its correct behaviour according to an input scenario.

In a first step, this document only concerns the simulated demonstrator. Indeed, the physical demonstrator will be available in a second step. Thus, the document will be updated accordingly.

## 2 How to create scenarios

### 2.1 Introduction

A scenario is a text file containing the description of interactions with the on-board and test conditions on the on-board internal states and/or outputs (TIU, radio message) The scenario describes how the Automatic Test Runner has to stimulate the interfaces of the on-board:

- Odometer: by simulating a train movement according to a given speed profile.
- Train interface: by simulating the train device inputs to the on-board.
- Driver: by simulating actions of the driver on a driver machine interface (DMI).
- Balise: by simulating the emission of balise contents to the on-board.
- Loop: by simulating the emission of loop contents to the on-board.
- Radio: by simulating radio communication from RBC/RIU to on-board.

According to the described interactions, a defined behaviour of the on-board is awaited and test conditions can be described in the scenario in order to test the internal state of the on-board and validate the awaited behaviour. These test conditions are defined later in the document and have different trigger: waiting a preset time, waiting a preset location, waiting a predefined output, ...

Note: The file extension for scenario files is ‘.sce’.

### 2.2 Scenario file description

A scenario file is composed of several sections which are indicated in the file between brackets: “[<section name>]”.

Here is the list of the different section names:

**SCENARIO:** Main section for the scenario execution.



- SpeedProfile:** Description of the speed profile used for train movement simulation.
- BaliseTrackside:** Description of balise contents to be sent to on-board.
- LoopTrackside:** Description of loop messages to be sent to on-board.
- Config\_SRSNationalDefaults:** Description of the default national values used by on-board.
- Config\_EVCInit:** Description of starting conditions used by on-board.
- Config\_TrainData:** Description of train data used by on-board.
- Config\_RBCData1:** Description of the first RBC parameters used for testing.
- Config\_RBCData2:** Description of the second RBC parameters used for testing.
- Config\_Scenario:** Specific options for the testrunner about the current scenario.
- Config\_EBModel\_Default:** Configuration of default emergency brake parameter for all combination of brakes
- Config\_EBModel\_0..15:** Configuration of emergency brake parameter for specific combination of brakes. There are 16 combinations : Config\_EBModel\_0 to Config\_EBModel\_15.
- Config\_SBModel\_Default:** Configuration of default service brake parameter for all combination of brakes
- Config\_SBModel\_0..7:** Configuration of service brake parameter for specific combination of brakes. There are 8 combinations : Config\_SBModel\_0 to Config\_SBModel\_7.

FixedData refer to SRS section A3.1. To improve the EVC testability, it is also possible to specify other values, e.g. SAFECONNECTION\_TIMEOUT or MAX\_RECONNECTION\_TIME can be shorten.

For data defined within SRS packets, these have to be set using the dedicated SRS message (e.g. gradient profile is defined within packet 21).

The user can also define its own sections for balise, loop and radio message contents and radio execution thread.

Comments lines can be added in the scenario file using “#”. If some data of section Config\_SRSNationalDefaults, Config\_FixedData, Config\_EVCInit or Config\_TrainData are not defined, default values are used (see the corresponding chapter for more information about the default values).

### 2.2.1 Scenario inclusion

It is possible to include files in a scenario file when common sections are used. This can be done anywhere in the file by using the ‘INCLUDE’ keyword as follows:

*INCLUDE=<file>*

## 2.2.2 Main section: SCENARIO

This section is composed of a succession of commands. These commands can request different type of actions:

- DRIVER\_ACTION:

**Table 1. DRIVER\_ACTION**

|                       |   |  |
|-----------------------|---|--|
| <b>Description</b>    | Simulates a driver actions interacting with the EVC (DMI or TIU interfaces). Optionally the scenario execution can be suspended a given time delay before executing next command. |  |
| <b>Syntax</b>         | <i>DRIVER_ACTION</i> = <Action>, <Delay>  |  |
| <b>&lt;Action&gt;</b> | <Action> on the DMI:  |  |
|                       | <i>Level0</i>   | ETCS level 0 entry                               |
|                       | <i>Level1</i>   | ETCS level 1 entry                               |
|                       | <i>Level2</i>   | ETCS level 2 entry                               |
|                       | <i>Level3</i>   | ETCS level 3 entry                               |
|                       | <i>DriverID</i>   | Driver identifier entry                          |
|                       | <i>TrainRunningNumber</i>   | Train running number entry                       |
|                       | <i>TrainData</i>  | Train data entry                                 |
|                       | <i>TrainData+TRN</i>  | Train data entry with train running number entry |
|                       | <i>StartOfMission</i>   | Start of mission request                         |
|                       | <i>NonLeadingModeEntry</i>  | Non leading entry request                        |
|                       | <i>NonLeadingModeExit</i>   | Non leading exit request                         |
|                       | <i>ShuntingModeEntry</i>  | Shunting entry request                           |
|                       | <i>ShuntingModeExit</i>   | Shunting exit request                            |
|                       | <i>OverrideEOA</i>  | Request to override EOA                          |
|                       | <i>OverrideUnsuitability</i>  | Request to override route unsuitability          |
|                       | <i>AckBrake</i>   | Acknowledgement for brake icon                   |
|                       | <i>AckMessage</i>   | Acknowledgement for message                      |
|                       | <i>AckModeOrLevel</i>   | Acknowledgement for mode/Level icon              |
|                       | <i>AckTAF</i>   | Acknowledgement for track ahead free             |
|                       | <i>ConfirmIntegrity</i>   | Confirm integrity                                |
|                       | <i>EnterLevel</i>   | Open level menu                                  |
|                       | <i>MainWindow</i>   | Return to main window                            |
|                       | <i>SlipperyTrack</i>  | Select slippery track                            |
|                       | <i>NonSlipperyTrack</i>   | Select non slippery track                        |
|                       | <Action> on the TIU:  |  |
|                       | <i>MainSwitchOn</i>   | Set EVC power TIU input to 'on'                  |

|                      |  |  |
|----------------------|--|--|
|                      | <i>MainSwitchOff</i>   | Set EVC power TIU input to 'off'                             |
|                      | <i>TrainIntegrityOK</i>  | Set integrity device TIU input to 'OK'                       |
|                      | <i>TrainIntegrityNOK</i>   | Set integrity device TIU input to 'NOK'                      |
|                      | <i>OpenCabinA</i>  | Set cabin status TIU input to 'cabin A opened'               |
|                      | <i>OpenCabinB</i>  | Set cabin status TIU input to 'cabin B opened'               |
|                      | <i>CloseCabin</i>  | Set cabin status TIU input to 'no cabin opened'              |
|                      | <i>EVCIsolationOn</i>  | Switch to Isolation mode                                     |
|                      | <i>EVCIsolationReset</i>   | Reset Isolation mode   |
|                      | <i>EVCSleepingOn</i>   | Set Sleeping TIU input to 'on'                               |
|                      | <i>EVCSleepingOff</i>  | Set sleeping TIU input to 'off'                              |
|                      | <i>ColdMovementDetectOn</i>  | Set cold movement detector input to 'on'                     |
|                      | <i>ColdMovementDetectOff</i>   | Set cold movement detector input to 'off'                    |
|                      | <i>DirectionNominal</i>  | Set direction controller TIU input to 'Nominal' (forward)    |
|                      | <i>DirectionReverse</i>  | Set direction controller TIU input to 'Reverse' (backward)   |
|                      | <i>DirectionStandstill</i>   | Set direction controller TIU input to 'Standstill' (neutral) |
|                      | <i>DirectionUndefined</i>  | Set direction controller TIU input to 'Undefined'            |
|                      | <i>SBOn</i>  | Set service brake TIU input to 'on'                          |
|                      | <i>SBOff</i>   | Set service brake TIU input to 'off'                         |
|                      | <i>EBOn</i>  | Set emergency brake TIU input to 'on'                        |
|                      | <i>EBOff</i>   | Set emergency brake TIU input to 'off'                       |
|                      | <i>SBOutOfOrder</i>  | Set service brake out of order                               |
|                      | <i>EBOutOfOrder</i>  | Set emergency brake out of order                             |
|                      | <i>MCBOpen</i>   | Set main circuit breaker TIU input to 'open'                 |
|                      | <i>MCBClose</i>  | Set main circuit breaker TIU input to 'close'                |
|                      | <i>PantographDown</i>  | Set pantograph TIU input to 'down'                           |
|                      | <i>PantographUp</i>  | Set pantograph TIU input to 'up'                             |
|                      | <i>PassengerEBOff</i>  | Set passenger emergency brake TIU input to 'off'             |
|                      | <i>PassengerEBOn</i>   | Set passenger emergency brake TIU input to 'on'              |
| <b>&lt;Delay&gt;</b> | Time delay in seconds to wait before executing next command (optional) |  |

|                |                                    |
|----------------|------------------------------------|
| <b>Example</b> | <i>DRIVER_ACTION = DriverID, 1</i> |
|----------------|------------------------------------|

- MOVE\_TRAIN:

Table 2. MOVE\_TRAIN

|                    |   |
|--------------------|---|
| <b>Description</b> | Simulates train movement in forward direction according to speed profile. |
| <b>Syntax</b>      | <i>MOVE_TRAIN</i>   |

- MOVE\_TRAIN\_BACK:

Table 3. MOVE\_TRAIN\_BACK

|                    |  |
|--------------------|--|
| <b>Description</b> | Simulates train movement in backward direction according to speed profile. |
| <b>Syntax</b>      | <i>MOVE_TRAIN_BACK</i>   |

- WAIT\_TIME:

Table 4. WAIT\_TIME

|                      |   |
|----------------------|---|
| <b>Description</b>   | Waits the given time delay before executing next command.   |
| <b>Syntax</b>        | <i>WAIT_TIME = &lt;Delay&gt;</i>                            |
| <b>&lt;Delay&gt;</b> | Time delay in seconds to wait before executing next command |
| <b>Example</b>       | <i>WAIT_TIME = 1</i>  |

- WAIT\_SPEED:

Table 5. WAIT\_SPEED

|                      |   |
|----------------------|---|
| <b>Description</b>   | Waits the given speed to be reached by the train movement simulation before executing next command. |
| <b>Syntax</b>        | <i>WAIT_SPEED = &lt;Speed&gt;</i>   |
| <b>&lt;Speed&gt;</b> | Speed in km/h to be reached before executing next command   |
| <b>Example</b>       | <i>WAIT_SPEED = 101</i>   |

- WAIT\_LOCATION:

Table 6. WAIT\_LOCATION

|                         |  |
|-------------------------|--|
| <b>Description</b>      | Waits the given location to be reached by the train movement simulation before executing next command. |
| <b>Syntax</b>           | <i>WAIT_LOCATION = &lt;Location&gt;</i>  |
| <b>&lt;Location&gt;</b> | Location in meters to be reached before executing next command   |
| <b>Example</b>          | <i>WAIT_LOCATION = 100</i>   |

- WAIT\_STANDSTILL:

Table 7. WAIT\_STANDSTILL

|                    |  |
|--------------------|--|
| <b>Description</b> | Waits the train movement simulation to reach standstill before executing next command. |
| <b>Syntax</b>      | <i>WAIT_STANDSTILL</i>   |

- CHECK\_TRACKCONDITION:

Table 8. CHECK\_TRACKCONDITION

|                          |  |   |
|--------------------------|--|---|
| <b>Description</b>       | Checks if a specified track condition is at the moment active An exclamation mark can be added as a prefix to the track condition name in order to test that it is currently not active. |   |
| <b>Syntax</b>            | <i>CHECK_TRACKCONDITION = &lt;Track Condition 1&gt;, ..., !&lt;Track Condition n&gt;</i>   |   |
| <b>&lt;Condition&gt;</b> | <i>TUNNEL_STOPPING_AREA</i>  | Tunnel stopping area                              |
|                          | <i>SOUND_HORN</i>  | Sound horn  |
|                          | <i>NON_STOPPING_AREA</i>   | Non stopping area                                 |
|                          | <i>POWERLESS_LOW_PANTO</i>   | Powerless section                                 |
|                          | <i>RADIO_HOLE</i>  | Radio hole  |
|                          | <i>AIR_TIGHTNESS</i>   | Air tightness                                     |
|                          | <i>SWITCHOFF_REGENERATIVE_BRAKE</i>  | Switch off regenerative brake                     |
|                          | <i>SWITCHOFF_EDDY_CURRENT_BRAKE_FOR_SB</i>   | Switch off eddy current brake for service brake   |
|                          | <i>SWITCHOFF_EDDY_CURRENT_BRAKE_FOR_EB</i>   | Switch off eddy current brake for emergency brake |
|                          | <i>SWITCHOFF_MAGNETIC_SHOE_BRAKE</i>   | Switch off magnetic shoe brake                    |
| <b>Example</b>           | <i>CHECK_TRACKCONDITION = !POWERLESS_LOW_PANTO, AIR_TIGHTNESS</i>  |   |

- WAIT\_STATUS:

Table 9. WAIT\_STATUS

|                          |  |  |
|--------------------------|--|--|
| <b>Description</b>       | Waits the EVC to reach given internal status before executing next command. Several conditions can be requested at the same time. Optionally the scenario execution can be stopped with failure if internal status is not reached in the given time delay. |  |
| <b>Syntax</b>            | <i>WAIT_STATUS = &lt;Condition 1&gt;, ..., &lt;Condition n&gt;, &lt;Delay&gt;, &lt;FATAL&gt;</i>   |  |
| <b>&lt;Condition&gt;</b> | <i>EB_ON</i>   | Emergency brake intervention request TIU status is 'on'  |
|                          | <i>EB_OFF</i>  | Emergency brake intervention request TIU output is 'off' |
|                          | <i>SB_ON</i>   | Service brake intervention request TIU output is 'on'    |
|                          | <i>SB_OFF</i>  | Service brake intervention request TIU output is 'off'   |

|  |                        |   |
|--|------------------------|---|
|  | <i>CUTOFF_ON</i>       | Cut off traction intervention request TIU output is 'on'  |
|  | <i>CUTOFF_OFF</i>      | Cut off traction intervention request TIU output is 'off' |
|  | <i>MCB_OPEN</i>        | Main circuit breaker request TIU output is 'open'         |
|  | <i>MCB_CLOSE</i>       | Main circuit breaker request TIU output is 'closed'       |
|  | <i>PANTOGRAPH_LOW</i>  | pantograph request TIU output is 'low'                    |
|  | <i>PANTOGRAPH_UP</i>   | pantograph request TIU output is 'up'                     |
|  | <i>AIRTIGHT_ON</i>     | Airtight request TIU output is 'on'                       |
|  | <i>AIRTIGHT_OFF</i>    | Airtight request TIU output is 'off'                      |
|  | <i>PEB_INHIBIT</i>     | Passenger emergency brake TIU output is 'inhibited'       |
|  | <i>PEB_PERMIT</i>      | Passenger emergency brake TIU output is 'permitted'       |
|  | <i>REGENBRK_ON</i>     | Regenerative brake TIU output is 'permitted'              |
|  | <i>REGENBRK_OFF</i>    | Regenerative brake TIU output is 'inhibited'              |
|  | <i>EDDYCURRBRK_ON</i>  | Eddy current brake TIU output is 'permitted'              |
|  | <i>EDDYCURRBRK_OFF</i> | Eddy current brake TIU output is 'inhibited'              |
|  | <i>MAGNSHOEBRK_ON</i>  | Magnetic shoe brake TIU output is 'permitted'             |
|  | <i>MAGNSHOEBRK_OFF</i> | Magnetic shoe brake TIU output is 'inhibited'             |
|  | <i>LEVEL_0</i>         | EVC ETCS is level 0                                       |
|  | <i>LEVEL_1</i>         | EVC ETCS is level 1                                       |
|  | <i>LEVEL_2</i>         | EVC ETCS is level 2                                       |
|  | <i>LEVEL_3</i>         | EVC ETCS is level 3                                       |
|  | <i>RADIOSAFE_ON</i>    | Radio safe connection is established                      |
|  | <i>RADIOSAFE_OFF</i>   | Radio safe connection is not established                  |
|  | <i>RADIOCONN_ON</i>    | Radio session is established                              |
|  | <i>RADIOCONN_OFF</i>   | Radio session is not established                          |
|  | <i>MODE_FS</i>         | EVC mode is Full Supervision                              |
|  | <i>MODE_OS</i>         | EVC mode is On Sight                                      |
|  | <i>MODE_SR</i>         | EVC mode is Staff Responsible                             |
|  | <i>MODE_SH</i>         | EVC mode is Shunting                                      |
|  | <i>MODE_UN</i>         | EVC mode is Unfitted                                      |

|                      |  |                                    |
|----------------------|--|------------------------------------|
|                      | <i>MODE_SL</i>   | EVC mode is Sleeping               |
|                      | <i>MODE_SB</i>   | EVC mode is Standby                |
|                      | <i>MODE_TR</i>   | EVC mode is Trip                   |
|                      | <i>MODE_PT</i>   | EVC mode is Post Trip              |
|                      | <i>MODE_SF</i>   | EVC mode is System Failure         |
|                      | <i>MODE_IS</i>   | EVC mode is Isolation              |
|                      | <i>MODE_NP</i>   | EVC mode is No Power               |
|                      | <i>MODE_NL</i>   | EVC mode Non Leading               |
|                      | <i>MODE_SE</i>   | EVC mode is STM European           |
|                      | <i>MODE_SN</i>   | EVC mode is STM National           |
|                      | <i>MODE_RV</i>   | EVC mode is Reversing              |
|                      | <i>MONITORING_CSM</i>  | Train in ceiling speed monitoring  |
|                      | <i>MONITORING_PIM</i>  | Train in pre-indication monitoring |
|                      | <i>MONITORING_TSM</i>  | Train in target speed monitoring   |
|                      | <i>MONITORING_RSM</i>  | Train in release speed monitoring  |
|                      | <i>OPERATED_SYSTEM_V1</i>  | Current operated system version 1  |
|                      | <i>OPERATED_SYSTEM_V2</i>  | Current operated system version 2  |
| <b>&lt;Delay&gt;</b> | Time delay for condition to be reached (optional)  |                                    |
| <b>&lt;FATAL&gt;</b> | if 'FATAL' keyword is set, the scenario is stopped with FAILURE status if condition is not reached in the given time delay. (optional) |                                    |
| <b>Example</b>       | <i>WAIT_STATUS = MODE_FS, EB_OFF, LEVEL_1, 5, FATAL</i>  |                                    |

- WAIT\_TEXT:

Table 10. WAIT\_TEXT

|                    |  |
|--------------------|--|
| <b>Description</b> | text message to be tested. An exclamation mark can be added as a prefix to the text in order test that it is currently not displayed on the DMI. |
| <b>Syntax</b>      | <i>WAIT_TEXT = &lt;text1&gt;, &lt;text2&gt;, ..., &lt;textN&gt;, &lt;Delay&gt;, FATAL</i>  |
| <b>Example</b>     | <i>WAIT_TEXT = SR stop order, !SH stop order, 5, FATAL</i>   |

- WAIT\_TEXT\_ORDERED:

Table 11. WAIT\_TEXT\_ORDERED

|                    |   |
|--------------------|---|
| <b>Description</b> | ordered list text messages to be tested. From older to newer. Suffix (ack) specify if text message is waiting a driver acknowledgement or not |
| <b>Syntax</b>      | <i>WAIT_TEXT_ORDERED= &lt;text1&gt;, &lt;text2&gt;, ..., &lt;textN&gt;, &lt;Delay&gt;, FATAL</i>  |
| <b>Example</b>     | <i>WAIT_TEXT_ORDERED = Hello world 1(ack), Hello world 2, 5, FATAL</i>  |

- CHECK\_PARAM:

Table 12. CHECK\_PARAM

|                          |   |                                    |
|--------------------------|---|------------------------------------|
| <b>Description</b>       | Checks an internal EVC value. Optionally the scenario execution can be stopped with a failure return if the condition on the checked parameter is not verified. |                                    |
| <b>Syntax</b>            | <i>CHECK_PARAM = &lt;Condition&gt;, FATAL</i>   |                                    |
| <b>&lt;Condition&gt;</b> | The condition is given with the following syntax: <Parameter> <comparison> <value>:   |                                    |
|                          | <i>EOA_SPEED</i>  | End of authority speed             |
|                          | <i>EOA_LOCATION</i>   | End of authority location          |
|                          | <i>EB_SPEED</i>   | Emergency brake intervention speed |
|                          | <i>SB_SPEED</i>   | Service brake intervention speed   |
|                          | <i>PERM_SPEED</i>   | Permitted speed                    |
|                          | <i>WARN_SPEED</i>   | Warning speed                      |
|                          | <i>TARGET_SPEED</i>   | Target speed                       |
|                          | <i>RELEASE_SPEED</i>  | Release speed                      |
|                          | <i>MRSP</i>   | Most restrictive speed             |
|                          | <i>TARGET_LOCATION</i>  | Target location                    |
|                          | <i>ADHESION</i>   | Adhesion factor value              |
|                          | <i>ESTIM_FRONT_LOCATION</i>   | Estimated front train position     |
|                          | The <value> is compared to the internal value according to the comparison symbol '>', '<' or '=', '>=', '<='  |                                    |
| <b>&lt;FATAL&gt;</b>     | if 'FATAL' keyword is set, the scenario is stopped with FAILURE status if condition is not reached in the given time delay. (optional)                          |                                    |
| <b>Example</b>           | <i>CHECK_PARAM = EOA_LOCATION &gt; 495, FATAL</i>   |                                    |

- SET:

Table 13. SET

|                       |                                  |  |
|-----------------------|----------------------------------|--|
| <b>Description</b>    | Modify RBC connection status.    |  |
| <b>Syntax</b>         | <i>SET = &lt;Status&gt;</i>      |  |
| <b>&lt;Status&gt;</b> | <i>RBC_SAFE_OFF</i>              | Shutdown safe connection of radio module 1       |
|                       | <i>RBC_SAFE_ON</i>               | Enable safe connection of radio module 1         |
|                       | <i>RBC_NET_EMPTY_LIST</i>        | radio module 1 returns an empty network list     |
|                       | <i>RBC_NET_FAIL_REGISTRATION</i> | radio module 1 refuses network registration      |
|                       | <i>RBC_NET_RESET</i>             | radio module 1 accepts network requests normally |
|                       | <i>RBC2_SAFE_OFF</i>             | Shutdown safe connection of radio module 2       |
|                       | <i>RBC2_SAFE_ON</i>              | Enable safe connection of radio module 2         |



|                |                                   |  |
|----------------|-----------------------------------|--|
|                | <i>RBC2_NET_EMPTY_LIST</i>        | radio module 2 returns an empty network list     |
|                | <i>RBC2_NET_FAIL_REGISTRATION</i> | radio module 2 refuses network registration      |
|                | <i>RBC_NET_RESET</i>              | radio module 2 accepts network requests normally |
| <b>Example</b> | <i>SET = RBC_NET_RESET</i>        |  |

- DO\_RADIO:

Table 14. DO\_RADIO

|                            |   |
|----------------------------|---|
| <b>Description</b>         | Executes a user defined section in parallel to the main section. This is useful for radio management that has to be performed in parallel to actions of the main section. |
| <b>Syntax</b>              | <i>DO_RADIO = &lt;SectionName&gt;</i>   |
| <b>&lt;SectionName&gt;</b> | It is a user defined section that has to be executed  |
| <b>Example</b>             | <i>DO_RADIO = OnBoardInitSession</i>  |

- RBC\_RADIO:

Sends a RBC radio message defined in the given section.

Table 15. RBC\_RADIO

|                            |  |
|----------------------------|--|
| <b>Description</b>         | Sends a RBC radio message defined in the given section.  |
| <b>Syntax</b>              | <i>RBC_RADIO = &lt;SectionName&gt;</i>   |
| <b>&lt;SectionName&gt;</b> | It is a user defined section that contains the radio message description that has to be sent to EVC. |
| <b>Example</b>             | <i>RBC_RADIO = RBCConfiguration</i>  |

- WAIT\_RADIO\_SENT:

Table 16. WAIT\_RADIO\_SENT

|                            |  |
|----------------------------|--|
| <b>Description</b>         | Waits the EVC to send a radio message corresponding to the one described in the given user defined section in the given time delay before executing the next command. Optionally the scenario execution can be stopped with a failure return if the radio message is not sent in the given time delay. |
| <b>Syntax</b>              | <i>WAIT_RADIO_SENT = &lt;SectionName&gt;, &lt;Delay&gt;, FATAL</i>   |
| <b>&lt;SectionName&gt;</b> | It is a user defined section that contains the radio message description that is awaited to be sent by EVC.  |
| <b>&lt;Delay&gt;</b>       | Time delay in seconds for waiting EVC to send radio message  |
| <b>&lt;FATAL&gt;</b>       | If 'FATAL' keyword is set, the scenario is stopped with FAILURE status if radio message is not sent within time given delay. (optional)  |
| <b>Example</b>             | <i>WAIT_RADIO_SENT = RIM_InitCommSession, 10, FATAL</i>  |

- CONNECT\_RADIO:

Table 17. CONNECT\_RADIO

|                    |  |
|--------------------|--|
| <b>Description</b> | Simulate a connection initiated by RBC for radio module 1. |
| <b>Syntax</b>      | <i>CONNECT_RADIO</i>                                       |

- CONNECT\_RADIO2:

Table 18. CONNECT\_RADIO2

|                    |  |
|--------------------|--|
| <b>Description</b> | Simulate a connection initiated by RBC for radio module 2. |
| <b>Syntax</b>      | <i>CONNECT_RADIO2</i>                                      |

- WAIT\_SYMBOL:

Table 19. WAIT\_SYMBOL

|                             |   |
|-----------------------------|---|
| <b>Description</b>          | Waits the EVC to ask the DMI to display a given icon in a specific area.  |
| <b>Syntax</b>               | <i>WAIT_SYMBOL = &lt;SymbolNumber&gt;, &lt;SymbolArea&gt;, ACK, &lt;Delay&gt;, FATAL</i>  |
| <b>&lt;SymbolNumber&gt;</b> | Number of the symbol such as found in ERA_ERTMS document. You can also specify NONE if you want to test that nothing is displayed in a specific area. |
| <b>&lt;SymbolNumber&gt;</b> | Area on the DMI where the symbol is expected to be displayed.   |
| <b>&lt;ACK&gt;</b>          | Optional, if present we test that this symbol requires the driver acknowledgement.  |
| <b>&lt;Delay&gt;</b>        | Time delay in seconds for waiting EVC to ask display of the symbol.   |
| <b>&lt;FATAL&gt;</b>        | If 'FATAL' keyword is set, the scenario is stopped with FAILURE status if the button is not displayed within time given delay. (optional)             |
| <b>Example</b>              | <i>WAIT_SYMBOL = ST02, A4, 2, FATAL</i>   |

- WAIT\_BUTTON:

Table 20. WAIT\_BUTTON

|                       |   |
|-----------------------|---|
| <b>Description</b>    | Waits the EVC to request the DMI the availability of one or several menu buttons.   |
| <b>Syntax</b>         | <i>WAIT_BUTTON = &lt;Button1&gt;, &lt;Button2&gt;, ..., &lt;ButtonN&gt;, &lt;Delay&gt;, FATAL</i>   |
| <b>&lt;Button&gt;</b> | Name of the button to be tested. An exclamation mark can be added as a prefix to the button name in order test that the button is currently not displayed on the DMI. The name can be one of those: |
|                       | <i>SOM</i>  |
|                       | <i>SHUNTING</i>   |
|                       | <i>EXIT_SHUNTING</i>  |
|                       | <i>NON_LEADING</i>  |
|                       | <i>MAINTAIN_SHUNTING</i>  |
|                       | <i>DRIVER_ID</i>  |
|                       | <i>TRAIN_RUN_NB</i>   |

|                      |   |
|----------------------|---|
|                      | <i>ETCS_LEVEL</i>   |
|                      | <i>TRAIN_DATA</i>   |
|                      | <i>TRAIN_DATA_VIEW</i>  |
|                      | <i>SR_DATA</i>  |
|                      | <i>LANGUAGE_SELECT</i>  |
|                      | <i>OVERRIDE_EOA</i>   |
|                      | <i>ADHESION_FACTOR</i>  |
|                      | <i>SYSTEM_VERSION</i>   |
|                      | <i>SOUND</i>  |
|                      | <i>BRIGHTNESS</i>   |
|                      | <i>CONFIRM_INTEG</i>  |
|                      | <i>ISOLATION</i>  |
|                      | <i>DMI_WAIT</i>   |
|                      | <i>USE_SHORT_NUMBER</i>   |
|                      | <i>ENTER_RBC_DATA</i>   |
|                      | <i>ENTER_RADIO_ID</i>   |
|                      | <i>CONTACT_LAST_RBC</i>   |
|                      | <i>TRAIN_DATA_SWITCH</i>  |
|                      | <i>FIXED_DATA_ENTRY</i>   |
|                      | <i>VBC_SET</i>  |
|                      | <i>VBC_REMOVE</i>   |
|                      | <i>ACK_MODE</i>   |
|                      | <i>ACK_MESSAGE</i>  |
|                      | <i>ACK_BRAKE</i>  |
| <b>&lt;Delay&gt;</b> | Time delay in seconds for waiting EVC to ask display of the button.   |
| <b>&lt;FATAL&gt;</b> | If 'FATAL' keyword is set, the scenario is stopped with FAILURE status if the button(s) availability do(es) not match within time given delay. (optional) |
| <b>Example</b>       | <i>WAIT_BUTTON = ETCS_LEVEL, DRIVER_ID, !SOM, 1, FATAL</i>  |

- WAIT\_DYNAMIC:

Table 21. WAIT\_DYNAMIC

|                             |   |
|-----------------------------|---|
| <b>Description</b>          | Waits the EVC to send to the DMI Dynamic data.                                |
| <b>Syntax</b>               | <i>WAIT_DYNAMIC = DMI_VARIABLE [= &lt;/&gt;] z, ..., &lt;Delay&gt;, FATAL</i> |
| <b>&lt;DMI_VARIABLE&gt;</b> | Name of the DMI variable to test. The name can be one of those:               |
|                             | <i>DMI_T_CLOCK</i>  |
|                             | <i>DMI_V_TRAIN</i>  |
|                             | <i>DMI_X_VTRAIN_DIGITS</i>  |

|                      |  |
|----------------------|--|
|                      | <i>DMI_O_TRAIN</i>   |
|                      | <i>DMI_O_BRAKETARGET</i>   |
|                      | <i>DMI_X_OBRAKETARGET_DIGITS</i>                                     |
|                      | <i>DMI_V_TARGET</i>  |
|                      | <i>DMI_V_PERMITTED</i>   |
|                      | <i>DMI_V_RELEASE</i>   |
|                      | <i>DMI_O_BCSP</i>  |
|                      | <i>DMI_V_INTERVENTION</i>  |
|                      | <i>DMI_M_MODE</i>  |
|                      | <i>DMI_M_LEVEL</i>   |
|                      | <i>DMI_NID_STM</i>   |
|                      | <i>DMI_NID_C</i>   |
|                      | <i>DMI_NID_C_UNKNOWN</i>   |
|                      | <i>DMI_M_WARNING</i>   |
|                      | <i>DMI_M_SUPSTATUS</i>   |
|                      | <i>DMI_O_LOA</i>   |
|                      | <i>DMI_V_LOA</i>   |
|                      | <i>DMI_O_KP_BALISE_TRACK_KILOMETER</i>                               |
|                      | <i>DMI_O_KP_DIST_TO_BALISE</i>                                       |
|                      | <i>DMI_M_KP_FLAG</i>   |
|                      | <i>DMI_O_DIST_TO_TSA</i>   |
| <b>&lt;Delay&gt;</b> | Time delay in seconds for waiting EVC to the asked value to the dmi. |
| <b>&lt;FATAL&gt;</b> | If 'FATAL' keyword is set, the scenario is stopped with FAILURE.     |
| <b>Example</b>       | <i>WAIT_BUTTON = ETCS_LEVEL, DRIVER_ID, !SOM, 1, FATAL</i>           |

### 2.2.3 Speed profile section: SpeedProfile

This section describes how the train movement simulation has to behave. The train movement simulation is controlled in the main section with the 'MOVE\_TRAIN' and 'MOVE\_TRAIN\_BACK' commands. The train will start moving and will follow the given speed profile until standstill.

A speed profile is a succession of positions associated to a speed to reach at this location (<location(m)> = <speed(km/h)>). The locations of the speed profile correspond to the traveled distance of the train and not its absolute position. That's why they are always incrementing. It is the used command in the main section that will determine in which direction the train will move. A constant acceleration/deceleration is used between 2 points of the profile. The following example shows a speed profile with its associated main section and a graphic representing the obtained train movement:

Note: The on-board interventions are not taken into account in the train movement simulation.

### 2.2.4 Balise section: BaliseTrackside




Figure 1. Speed profile

This section describes the locations at which balise messages have to be sent to the EVC (<location(m)> = <user balise message name>). A user defined section describing the balise message content is associated to each location. As for the speed profile, the locations are given for the travelled distance.

The user defined sections contain the description of the balise message content. It uses the variable names as defined in SRS chapter 7 and 8 (See Erreur : source de la référence non trouvée) Message variables don't need to be defined if the default value is used but they have to be in the right order.

Note: The SRS language can be indicated in option with SRS=<version> Example: <location(m)> = <user balise message name>, SRS=2.3.0

During the execution, balise message contents are automatically sent to EVC when the location is reached.

The following example shows a balise trackside and the associated balise message content sections:

| [BaliseTrackside] | [BG_1_0]              | [BG_1_1]                 |
|-------------------|-----------------------|--------------------------|
| 100 = BG_1_0      | <i># Header</i>       | <i># Header</i>          |
| 105 = BG_1_1      | N_PIG = 0             | N_PIG = 1                |
|                   | N_TOTAL = 1           | N_TOTAL = 1              |
|                   | NID_C = 0             | NID_C = 0                |
|                   | NID_BG = 1            | NID_BG = 1               |
|                   | Q_LINK = 1            | Q_LINK = 1               |
|                   | <i># L1 MA packet</i> | <i># SSP packet</i>      |
|                   | NID_PACKET = 12       | NID_PACKET = 27          |
|                   | Q_DIR = 1             | Q_DIR = 2                |
|                   | Q_SCALE = 1           | V_STATIC = 2             |
|                   | V_MAIN = 30           |                          |
|                   | L_ENDSECTION = 500    | <i># Gradient packet</i> |
|                   |                       | NID_PACKET = 21          |

### 2.2.5 Loop section: LoopTrackside

This section describes the locations at which loop messages have to be sent to the on-board (<location(m)> = <user loop message name>). A user defined section describing the loop message content is associated to each location. As for the speed profile, the locations are given for the travelled distance.

The user defined sections contain the description of the loop message content. It uses the variable names as defined in SRS chapter 7 and 8. Message variables do not need to be defined if the default value is used but they have to be in the right order.

Note:

- the SRS language can be indicated in option with SRS=<version>;
- the spread spectrum code value can be indicated in option with SSCode=<SSCode>, if not indicated default value 15 is used.
- Example: <location(m)> = <user loop message name>, SSCode=3, SRS=2.3.0

During the execution, loop message contents are automatically sent to on-board when the location is reached. The following example shows a loop trackside and the associated loop message content sections:

| <b>[LoopTrackside]</b> | <b>[Loop0]</b>                     | <b>[Loop1]</b>                     |
|------------------------|------------------------------------|------------------------------------|
| 100 = Loop0            | <i># Header</i>                    | <i># Header</i>                    |
| 105 = Loop1            | NID_C = 0                          | NID_C = 0                          |
|                        | NID_LOOP = 1                       | NID_LOOP = 1                       |
|                        | <i># Infill location reference</i> | <i># Infill location reference</i> |
|                        | NID_PACKET = 136                   | NID_PACKET = 136                   |
|                        | Q_DIR = 2                          | Q_DIR = 2                          |
|                        | NID_BG = 1                         | NID_BG = 1                         |
|                        | <i># L1 MA packet</i>              | <i># L1 MA packet</i>              |
|                        | NID_PACKET = 12                    | NID_PACKET = 12                    |
|                        | Q_DIR = 2                          | Q_DIR = 2                          |
|                        | Q_SCALE = 1                        | Q_SCALE = 1                        |
|                        | V_MAIN = 0                         | V_MAIN = 30                        |
|                        | L_ENDSECTION = 0                   | L_ENDSECTION = 500                 |
|                        | <i># SSP packet</i>                | <i># SSP packet</i>                |
|                        | NID_PACKET = 27                    | NID_PACKET = 27                    |
|                        | Q_DIR = 2                          | Q_DIR = 2                          |
|                        | V_STATIC = 30                      | V_STATIC = 30                      |
|                        | <i># Gradient packet</i>           | <i># Gradient packet</i>           |
|                        | NID_PACKET = 21                    | NID_PACKET = 21                    |

### 2.2.6 Default national values configuration section: Config\_SRSNationalDefaults

This section defines the default national values used by EVC, before Start-of-Mission. These default national values can be overridden when the train receives a packet 3 from trackside. This will allow the Test Environment to be able to test the correct update of the national values data.

- COUNTRY\_ID:

Table 22. COUNTRY\_ID

|                      |  |
|----------------------|--|
| <b>Description</b>   | Country identifier of the country for which default national values are valid. |
| <b>Default value</b> | 0  |

- COUNTRIES\_ID:

Table 23. COUNTRIES\_ID

|                    |  |
|--------------------|--|
| <b>Description</b> | A list of country identifiers for which default national values are valid. |
|--------------------|--|

|                      |                        |
|----------------------|------------------------|
| <b>Default value</b> | 0                      |
| <b>Example</b>       | COUNTRIES_ID = 253;254 |

- DRIVER\_ADHESION:

Table 24. DRIVER\_ADHESION

|                       |  |
|-----------------------|--|
| <b>Description</b>    | Qualifier for the modification of trackside adhesion factor by driver. |
| <b>SRS Name</b>       | <i>Q_NVDRIVER_ADHES</i>  |
| <b>Special values</b> | – 0: not allowed<br>– 1: allowed                                       |
| <b>Default value</b>  | 0  |

- SH\_SPEED:

Table 25. SH\_SPEED

|                      |                                       |
|----------------------|---------------------------------------|
| <b>Description</b>   | Shunting mode permitted speed (km/h). |
| <b>SRS Name</b>      | <i>V_NVSHUNT</i>                      |
| <b>Range</b>         | 0 km/h – 600 km/h (in 5 km/h step)    |
| <b>Default value</b> | 30 km/h                               |

- SR\_SPEED:

Table 26. SR\_SPEED

|                      |  |
|----------------------|--|
| <b>Description</b>   | Staff Responsible mode permitted speed (km/h). |
| <b>SRS Name</b>      | <i>V_NVSTFF</i>                                |
| <b>Range</b>         | 0 km/h – 600 km/h (in 5 km/h step)             |
| <b>Default value</b> | 40 km/h  |

- OS\_SPEED:

Table 27. OS\_SPEED

|                      |                                       |
|----------------------|---------------------------------------|
| <b>Description</b>   | On Sight mode permitted speed (km/h). |
| <b>SRS Name</b>      | <i>V_NVONSIGHT</i>                    |
| <b>Range</b>         | 0 km/h – 600 km/h (in 5 km/h step)    |
| <b>Default value</b> | 30 km/h                               |

- UN\_SPEED:

Table 28. UN\_SPEED

|                    |                                       |
|--------------------|---------------------------------------|
| <b>Description</b> | Unfitted mode permitted speed (km/h). |
| <b>SRS Name</b>    | <i>V_NVUNFIT</i>                      |
| <b>Range</b>       | 0 km/h – 600 km/h (in 5 km/h step)    |



|                      |          |
|----------------------|----------|
| <b>Default value</b> | 100 km/h |
|----------------------|----------|

- RELEASE\_SPEED:

Table 29. RELEASE\_SPEED

|                      |                                       |
|----------------------|---------------------------------------|
| <b>Description</b>   | Release Speed permitted speed (km/h). |
| <b>SRS Name</b>      | <i>V_NVREL</i>                        |
| <b>Range</b>         | 0 km/h – 600 km/h (in 5 km/h step)    |
| <b>Default value</b> | 40 km/h                               |

- ROLLAWAY\_DISTANCE:

Table 30. ROLLAWAY\_DISTANCE

|                       |  |
|-----------------------|--|
| <b>Description</b>    | Distance limit used for roll away and reverse movement protection (meter). |
| <b>SRS Name</b>       | <i>D_NVROLL</i>  |
| <b>Range</b>          | 0 meters – 327 660 meters (in 1 meter step)                                |
| <b>Special values</b> | INFINITY: deactivates roll away and reverse movement protection            |
| <b>Default value</b>  | 2 meters   |

- SB\_USETOTARGET:

Table 31. SB\_USETOTARGET

|                       |   |
|-----------------------|---|
| <b>Description</b>    | Permission to use service brake when braking to a target is supervised. |
| <b>SRS Name</b>       | <i>Q_NVSRBKTRG</i>  |
| <b>Special values</b> | – 0: no<br>– 1: yes   |
| <b>Default value</b>  | yes   |

- EB\_RUNRELEASE:

Table 32. EB\_RUNRELEASE

|                       |  |
|-----------------------|--|
| <b>Description</b>    | Permission to release the emergency brake immediately if the condition why the system has triggered the emergency brake (speed exceeds emergency brake intervention limit, lack of driver reaction) is not fulfilled any more. |
| <b>SRS Name</b>       | <i>Q_NVEMRRLS</i>  |
| <b>Special values</b> | – 0: only at standstill<br>– 1: immediate release possible   |
| <b>Default value</b>  | only at standstill   |

- OVERRIDEEOA\_ENTRYSPED:

**Table 33. OVERRIDEEOA\_ENTRYSPPEED**

|                      |   |
|----------------------|---|
| <b>Description</b>   | Maximum speed limit allowing the driver to select the "override EOA" function (km/h). |
| <b>SRS Name</b>      | <i>V_NVALLOWOVTRP</i>   |
| <b>Range</b>         | 0 km/h – 600 km/h (in 5 km/h step)  |
| <b>Default value</b> | 0 km/h  |

- OVERRIDEEOA\_MAXSPEED:

**Table 34. OVERRIDEEOA\_MAXSPEED**

|                      |   |
|----------------------|---|
| <b>Description</b>   | Permitted speed limit to be supervised when the "override EOA" function is active (km/h). |
| <b>SRS Name</b>      | <i>V_NVSUPOVTRP</i>   |
| <b>Range</b>         | 0 km/h – 600 km/h (in 5 km/h step)  |
| <b>Default value</b> | 30 km/h   |

- OVERRIDEEOA\_MAXDISTANCE:

**Table 35. OVERRIDEEOA\_MAXDISTANCE**

|                      |   |
|----------------------|---|
| <b>Description</b>   | Maximum distance for overriding the train trip (meter). |
| <b>SRS Name</b>      | <i>D_NVOVTRP</i>  |
| <b>Range</b>         | 0 meters – 327 670 meters (in 1 meter step)             |
| <b>Default value</b> | 200 meters  |

- OVERRIDEEOA\_MAXTIME:

**Table 36. OVERRIDEEOA\_MAXTIME**

|                      |  |
|----------------------|--|
| <b>Description</b>   | Maximum time for overriding the train trip (second). |
| <b>Range</b>         | 0 second – 255 seconds (in 1 second step)            |
| <b>Default value</b> | 60 seconds   |

- DRIVERID\_RUNCHANGE:

**Table 37. DRIVERID\_RUNCHANGE**

|                       |   |
|-----------------------|---|
| <b>Description</b>    | Entry of Driver ID permitted while running. |
| <b>SRS Name</b>       | <i>M_NVDERUN</i>                            |
| <b>Special values</b> | – 0: no<br>– 1: yes                         |
| <b>Default value</b>  | yes   |

- PT\_MAXDISTANCE:

**Table 38. PT\_MAXDISTANCE**

|                      |   |
|----------------------|---|
| <b>Description</b>   | Maximum distance for reversing in Post Trip mode (meter). |
| <b>SRS Name</b>      | <i>D_NVPOTRP</i>  |
| <b>Range</b>         | 0 meters – 327 670 meters (in 1 meter step)               |
| <b>Default value</b> | 200 meters  |

- CONTACT\_TIME:

Table 39. CONTACT\_TIME

|                       |   |
|-----------------------|---|
| <b>Description</b>    | Maximal time without new "safe" radio message (second). |
| <b>SRS Name</b>       | <i>T_NVCONTACT</i>                                      |
| <b>Range</b>          | 0 second – 254 seconds (in 1 second step)               |
| <b>Special values</b> | INFINITY: deactivates supervision of radio link         |
| <b>Default value</b>  | INFINITY  |

- SR\_MAXDISTANCE:

Table 40. SR\_MAXDISTANCE

|                       |  |
|-----------------------|--|
| <b>Description</b>    | Maximum distance for running in Staff Responsible mode (meter).      |
| <b>SRS Name</b>       | <i>D_NVSTFF</i>  |
| <b>Range</b>          | 0 meters – 327.660 meters (in 1 meter step)                          |
| <b>Special values</b> | INFINITY: deactivates distance supervision in Staff Responsible mode |
| <b>Default value</b>  | INFINITY   |

- NOCONTACT\_REACTION:

Table 41. NOCONTACT\_REACTION

|                       |  |
|-----------------------|--|
| <b>Description</b>    | Indicates the reaction to be performed when T_NVCONTACT timer elapses.   |
| <b>SRS Name</b>       | <i>M_NVCONTACT</i>   |
| <b>Special values</b> | <ul style="list-style-type: none"> <li>– NONE: no reaction</li> <li>– TRIP: train trip</li> <li>– SB: service brake application</li> </ul> |
| <b>Default value</b>  | no reaction  |

- NV\_FROM\_HEX\_BUFFER:

Table 42. NV\_FROM\_HEX\_BUFFER

|                    |   |
|--------------------|---|
| <b>Description</b> | Allows to initialize EVC with a general radio message (24) containing packet 3.     |
| <b>Format</b>      | A list of hexadecimal values splited by comma that represents general radio message |

|                      |   |
|----------------------|---|
| <b>Example</b>       | NV_FROM_HEX_BUFFER = 18, 08, 80, 00, 00, 00, 00, 00, 00, 00, 68, 31, 10, 00, 02, 3f, 4f, f0, c1, 83, 20, 0a, 00, 28, 06, 18, 03, 27, f8, 0c, 84, 69, ff, fd |
| <b>Default value</b> | none  |
| <b>Warning</b>       | If NV_FROM_HEX_BUFFER is defined all other values define in this section are removed  |

- INHIB\_SPD\_INACC\_COMPENSATION:

Table 43. INHIB\_SPD\_INACC\_COMPENSATION

|                       |  |
|-----------------------|--|
| <b>Description</b>    | Compensation of the speed measurement inaccuracy used for the calculation of speed restriction to ensure given permitted braking distance. |
| <b>SRS Name</b>       | <i>Q_NVINHSMICPERM</i>   |
| <b>Special values</b> | <ul style="list-style-type: none"> <li>– 0: no</li> <li>– 1: yes</li> </ul>  |
| <b>Default value</b>  | yes  |

### 2.2.7 EVC configuration section: Config\_EVCInit

This section allow definition of values of the EVC at power on, i.e. at initialization state.

- LINE\_LEVEL:

Table 44. LINE\_LEVEL

|                       |  |
|-----------------------|--|
| <b>Description</b>    | Default ETCS level.  |
| <b>Special values</b> | <ul style="list-style-type: none"> <li>– 0: level 0</li> <li>– 1: level 1</li> <li>– 2: level 2</li> <li>– 3: level 3</li> </ul> |
| <b>Default value</b>  | level 3  |

- RBC\_ID:

Table 45. RBC\_ID

|                      |  |
|----------------------|--|
| <b>Description</b>   | Default RBC identifier.  |
| <b>Range</b>         | $RBC\_ID = NID\_C * 2^{14} + NID\_RBC$ <ul style="list-style-type: none"> <li>– NID_C: 0 – 1024</li> <li>– NID_RBC: 0 – 16384</li> </ul> |
| <b>Default value</b> | 789  |

- RBC\_PHONE:

Table 46. RBC\_PHONE

|                      |                           |
|----------------------|---------------------------|
| <b>Description</b>   | Default RBC phone number. |
| <b>Range</b>         | 1 to 16 digits value      |
| <b>Default value</b> | 1234123412341234          |

- NETWORK\_ID:

Table 47. NETWORK\_ID

|                      |                                   |
|----------------------|-----------------------------------|
| <b>Description</b>   | Default radio network identifier. |
| <b>Range</b>         | 1 to 6 digits value               |
| <b>Default value</b> | 123456                            |

- COUNTRY\_ID:

Table 48. COUNTRY\_ID

|                      |  |
|----------------------|--|
| <b>Description</b>   | Country identifier of the last relevant balise group (LRBG). |
| <b>Range</b>         | 0 – 1024   |
| <b>Default value</b> | 0  |

- GROUP\_ID:

Table 49. GROUP\_ID

|                      |  |
|----------------------|--|
| <b>Description</b>   | Identifier of the last relevant balise group (LRBG). |
| <b>Range</b>         | 0 – 16384  |
| <b>Default value</b> | 4522   |

- DISTANCE:

Table 50. DISTANCE

|                      |  |
|----------------------|--|
| <b>Description</b>   | Distance to the reference last relevant balise group from train front. |
| <b>Range</b>         | 0 meter – 327.670 meters   |
| <b>Default value</b> | 50   |

- DIRECTION:

Table 51. DIRECTION

|                       |   |
|-----------------------|---|
| <b>Description</b>    | Validity direction for the reference balise group (LRBG).   |
| <b>Special values</b> | <ul style="list-style-type: none"> <li>– NOMINAL</li> <li>– REVERSE</li> <li>– UNDEFINED</li> </ul> |
| <b>Default value</b>  | NOMINAL   |

- VALIDITY:

Table 52. VALIDITY

|                       |   |
|-----------------------|---|
| <b>Description</b>    | Validity of the last relevant balise group (LRBG).  |
| <b>Special values</b> | <ul style="list-style-type: none"> <li>– VALID</li> <li>– INVALID</li> <li>– UNKNOWN</li> </ul> |
| <b>Default value</b>  | VALID   |

- NTC\_MODULE:

Table 53. NTC\_MODULE

|                       |  |
|-----------------------|--|
| <b>Description</b>    | Name of the NTC module to instantiate (only one currently).                                      |
| <b>Special values</b> | <ul style="list-style-type: none"> <li>– GENERIC</li> <li>– GENERICSS</li> <li>– TEST</li> </ul> |
| <b>Default value</b>  | GENERIC  |

- EVC\_CONFIG:

Table 54. EVC\_CONFIG

|                    |   |
|--------------------|---|
| <b>Description</b> | Allows to activate EVC configuration.   |
| <b>Values</b>      | <ul style="list-style-type: none"> <li>– CFG_RADIO_INTERNAL_TIME_STAMP : Internal time stamping (not use T_TRAIN)</li> <li>– CFG_USE_JRU : Use JRU (generates JRU data file)</li> <li>– CFG_RECORD_TO_CSV_FILE : Record supervision data to CSV file</li> <li>– CFG_BAL_WITH_ODO_STAMP : Balise are received with odo stamp</li> <li>– CFG_LOOP_WITH_SSCODE : Loop are received with spread spectrum code</li> <li>– CFG_LOCAL_TIME_STAMP : Request local time stamp otherwise GMT time in log &amp; JRU record</li> <li>– CFG_RECORDER_LOG_ADD_FULL_TIME_STAMP : add time stamp in EuroCabLog.dat like 2009-05-29/08:15:21.29</li> </ul> |
| <b>Example</b>     | EVC_CONFIG = CFG_LOOP_WITH_SSCODE CFG_USE_JRU   |
| <b>Warning</b>     | CFG_RADIO_INTERNAL_TIME_STAMP and CFG_BAL_WITH_ODO_STAMP are mandatories for EVC then EVC set these configurations automatically and they can be removed  |

## 2.2.8 Train data configuration section: Config\_TrainData

This section defines a default train data set but also allows test automation by simulating user actions (e.g. from DMI).

- BALISE\_COM\_AVAILABLE:

**Table 55. BALISE\_COM\_AVAILABLE**

|                       |  |
|-----------------------|--|
| <b>Description</b>    | Indicates if balise communication is available on-board. |
| <b>Special values</b> | – 0: not available<br>– 1: available                     |
| <b>Default value</b>  | available  |

- LOOP\_COM\_AVAILABLE:

**Table 56. LOOP\_COM\_AVAILABLE**

|                       |   |
|-----------------------|---|
| <b>Description</b>    | Indicates if loop communication is available onboard. |
| <b>Special values</b> | – 0: not available<br>– 1: available                  |
| <b>Default value</b>  | available   |

- RADIO\_COM\_AVAILABLE:

**Table 57. RADIO\_COM\_AVAILABLE**

|                      |   |
|----------------------|---|
| <b>Description</b>   | Indicates the number of radio equipments available onboard. |
| <b>Range</b>         | 0 – 2   |
| <b>Default value</b> | 1   |

- INTEGRITY\_DEVICE\_AVAILABLE:

**Table 58. INTEGRITY\_DEVICE\_AVAILABLE**

|                       |   |
|-----------------------|---|
| <b>Description</b>    | Indicates if integrity detection device is available. |
| <b>Special values</b> | – 0: not available<br>– 1: available                  |
| <b>Default value</b>  | available   |

- SERVICE\_BRAKE\_AVAILABLE:

**Table 59. SERVICE\_BRAKE\_AVAILABLE**

|                       |  |
|-----------------------|--|
| <b>Description</b>    | Indicates if service brakes are available. |
| <b>Special values</b> | – 0: not available<br>– 1: available       |
| <b>Default value</b>  | available                                  |

- ETCS\_PHONE1:

**Table 60. ETCS\_PHONE1**

|                    |  |
|--------------------|--|
| <b>Description</b> | Phone number of first radio equipment. |
| <b>Range</b>       | 1 to 16 digits value                   |

- ETCS\_PHONE2:

**Table 61. ETCS\_PHONE2**

|                    |   |
|--------------------|---|
| <b>Description</b> | Phone number of second radio equipment. |
| <b>Range</b>       | 1 to 16 digits value                    |

- TCO\_AVAILABLE:

**Table 62. TCO\_AVAILABLE**

|                       |   |
|-----------------------|---|
| <b>Description</b>    | Indicates if traction cut off is available. |
| <b>Special values</b> | – 0: not available<br>– 1: available        |
| <b>Default value</b>  | available                                   |

- USE\_BRK\_FEEDBACK:

**Table 63. USE\_BRK\_FEEDBACK**

|                       |  |
|-----------------------|--|
| <b>Description</b>    | Indicate if brake feedback is available. |
| <b>Special values</b> | – 0: not available<br>– 1: available     |
| <b>Default value</b>  | not available                            |

- BRK\_PERCENTAGE:

**Table 64. BRK\_PERCENTAGE**

|                      |   |
|----------------------|---|
| <b>Description</b>   | Brake percentage for train data conversion model. |
| <b>Range</b>         | Integer value                                     |
| <b>Default value</b> | 135   |

- ETCS\_ID:

**Table 65. ETCS\_ID**

|                      |                                  |
|----------------------|----------------------------------|
| <b>Description</b>   | ETCS identifier of the on-board. |
| <b>Range</b>         | 0 – 16777215                     |
| <b>Default value</b> | 4554                             |

- BALISEANTENNA\_OFFSET:

**Table 66. BALISEANTENNA\_OFFSET**



|                      |   |
|----------------------|---|
| <b>Description</b>   | Offset of balise antenna relative to train front. |
| <b>Range</b>         | Integer value (in meters)                         |
| <b>Default value</b> | 0 meter   |

- TRAIN\_CATEGORY:

Table 67. TRAIN\_CATEGORY

|                      |                               |
|----------------------|-------------------------------|
| <b>Description</b>   | Train category of the train.  |
| <b>Range</b>         | Integer value. See (NC_TRAIN) |
| <b>Default value</b> | 1                             |

- CUTOFF\_TIME:

Table 68. CUTOFF\_TIME

|                      |                           |
|----------------------|---------------------------|
| <b>Description</b>   | Traction cut off time.    |
| <b>Range</b>         | Double value (in seconds) |
| <b>Default value</b> | 1.0 second                |

- SPEED\_MAX:

Table 69. SPEED\_MAX

|                      |                        |
|----------------------|------------------------|
| <b>Description</b>   | Maximum train speed.   |
| <b>Range</b>         | Double value (in km/h) |
| <b>Default value</b> | 300 km/h (83.3 m/s)    |

- TRAIN\_LENGTH:

Table 70. TRAIN\_LENGTH

|                      |                          |
|----------------------|--------------------------|
| <b>Description</b>   | Train length.            |
| <b>Range</b>         | Double value (in meters) |
| <b>Default value</b> | 100 meters               |

- TRAIN\_MAXACCEL:

Table 71. TRAIN\_MAXACCEL

|                      |                                     |
|----------------------|-------------------------------------|
| <b>Description</b>   | Train maximum acceleration.         |
| <b>Range</b>         | Double value (in m/s <sup>2</sup> ) |
| <b>Default value</b> | 0.5 m/s <sup>2</sup>                |

- LOADING\_GAUGE\_MASK:

Table 72. LOADING\_GAUGE\_MASK

|                      |                                     |
|----------------------|-------------------------------------|
| <b>Description</b>   | Loading gauge type of the train.    |
| <b>Range</b>         | Integer value. See (M_LOADINGGAUGE) |
| <b>Default value</b> | 1                                   |

- AXLE\_LOAD:

Table 73. AXLE\_LOAD

|                      |                         |
|----------------------|-------------------------|
| <b>Description</b>   | Axle load of the train. |
| <b>Range</b>         | Double value (in kg)    |
| <b>Default value</b> | 23 000 kg               |

- ODO\_FIXED\_ERROR:

Table 74. ODO\_FIXED\_ERROR

|                      |                                |
|----------------------|--------------------------------|
| <b>Description</b>   | Fixed error on odometric data. |
| <b>Range</b>         | Double value (in meter)        |
| <b>Default value</b> | 5 meters                       |

- TRACTION\_POWER:

Table 75. TRACTION\_POWER

|                      |  |
|----------------------|--|
| <b>Description</b>   | List of traction power types equipped by the train.  |
| <b>Range</b>         | Space separated integer value list. See (M_TRACTION) |
| <b>Default value</b> | 11 48  |

- COLD\_MOVEMENT\_DETECTOR\_AVAILABLE:

Table 76. COLD\_MOVEMENT\_DETECTOR\_AVAILABLE

|                       |  |
|-----------------------|--|
| <b>Description</b>    | Indicate if cold movement detector is available. |
| <b>Special values</b> | – 0: not available<br>– 1: available             |
| <b>Default value</b>  | not available                                    |

## 2.2.9 Train data configuration section: Config\_FixedData

- SAFECONNECTION\_TIMEOUT:

Table 77. SAFECONNECTION\_TIMEOUT

|                      |                                 |
|----------------------|---------------------------------|
| <b>Description</b>   | Safe connection repeat timeout. |
| <b>Range</b>         | Double value (in seconds)       |
| <b>Default value</b> | 20 seconds                      |

- MAX\_RECONNECTION\_TIME:

Table 78. MAX\_RECONNECTION\_TIME

|                      |  |
|----------------------|--|
| <b>Description</b>   | Maximum time to maintain a communication session in case of failed re-connection attempts. |
| <b>Range</b>         | Double value (in seconds)  |
| <b>Default value</b> | 300 seconds  |

### 2.2.10 Train data configuration section: Config\_RBCData

- RBC\_OFF\_DISCONNECT\_TIMEOUT:

Table 79. RBC\_OFF\_DISCONNECT\_TIMEOUT

|                      |  |
|----------------------|--|
| <b>Description</b>   | When the RBC is off, (after calling SET=RBC_SAFE_OFF) and a safe connection is requested, it replies by a disconnection request. When we need to test the absence of a reply, we may want to delay this behaviour. |
| <b>Range</b>         | Double value (in seconds)  |
| <b>Default value</b> | 0.5 seconds  |

### 2.2.11 Scenario configuration section: Config\_Scenario

- DMI\_SIMPLIFIED\_SUPPORTED:

Table 80. DMI\_SIMPLIFIED\_SUPPORTED

|                      |   |
|----------------------|---|
| <b>Description</b>   | Tells if this scenario can be executed when the simplified DMI is used. |
| <b>Range</b>         | 0 or 1  |
| <b>Default value</b> | 1 (True)  |

- EXPECTED\_TO\_FAIL:

Table 81. EXPECTED\_TO\_FAIL

|                      |   |
|----------------------|---|
| <b>Description</b>   | Tells if this scenario will fail because the fix is not yet done and should not be counted as a regression. |
| <b>Range</b>         | Not available   |
| <b>Default value</b> | Not available   |

### 2.2.12 Brake parameters configuration sections

### 2.2.13 Config\_EBModel\_Default section

Config\_EBModel\_Default allow you to set brake models and factor for all combinations of brakes.

- T\_brake\_emergency:

**Table 82. T\_brake\_emergency**

|                      |                               |
|----------------------|-------------------------------|
| <b>Description</b>   | Emergency brake build up time |
| <b>Range</b>         | Double value (in seconds)     |
| <b>Default value</b> | 1 second                      |

- A\_brake\_emergency:

**Table 83. A\_brake\_emergency**

|                      |   |
|----------------------|---|
| <b>Description</b>   | Emergency brake deceleration models   |
| <b>Format</b>        | <i>speed/deceleration [speed/deceleration [...]]</i> with unit km/h and m/s <sup>-2</sup> |
| <b>Default value</b> | 0.0/0.88 600.0/0.0  |

- K\_wet:

**Table 84. K\_wet**

|                      |  |
|----------------------|--|
| <b>Description</b>   | K_wet correction factors   |
| <b>Format</b>        | <i>speed/factor [speed/factor [...]]</i> with unit km/h and Double value |
| <b>Default value</b> | 0.0/1.0  |

- K\_dry\_0 to K\_dry\_9:

**Table 85. K\_dry\_0 to K\_dry\_9**

|                      |  |
|----------------------|--|
| <b>Description</b>   | K_dry correction factors. There is 10 possibilities according EBCL values : 50%, 90%, 99.0%, 99.9%, 99.99%, 99.999%, 99.9999%, 99.99999%, 99.999999%, 99.9999999%. |
| <b>Format</b>        | <i>speed/factor [speed/factor [...]]</i> with unit km/h and Double value   |
| <b>Default value</b> | 0.0/1.0  |

### 2.2.14 Config\_EBModel\_0 to Config\_EBModel\_15 section

There is 15 possible sections corresponding to 15 combinations of brake used. Parameters are the same as **Config\_EBModel\_Default** section. In addition you can set which brake is used.

Parameters added are the following :

- RegenBrakeUsed:

**Table 86. RegenBrakeUsed**

|                       |  |
|-----------------------|--|
| <b>Description</b>    | Indicate if regenerative brake is used |
| <b>Special values</b> | 0: not used                            |
| •                     | 1: used                                |
| <b>Default value</b>  | 0                                      |

- EddyBrakeUsed:

**Table 87. EddyBrakeUsed**

|                       |  |
|-----------------------|--|
| <b>Description</b>    | Indicate if eddy current brake is used |
| <b>Special values</b> | 0: not used                            |
| •                     | 1: used                                |
| <b>Default value</b>  | 0                                      |

- MShoeBrakeBrakeUsed:

**Table 88. MShoeBrakeBrakeUsed**

|                       |   |
|-----------------------|---|
| <b>Description</b>    | Indicate if magnetic shoe brake is used |
| <b>Special values</b> | 0: not used                             |
| •                     | 1: used                                 |
| <b>Default value</b>  | 0                                       |

- EpBrakeUsed:

**Table 89. EpBrakeUsed**

|                       |   |
|-----------------------|---|
| <b>Description</b>    | Indicate if electro-pneumatic brake is used |
| <b>Special values</b> | 0: not used                                 |
| •                     | 1: used                                     |
| <b>Default value</b>  | 0   |

Example:

```

[ Config_EBModel_0 ]
RegenBrakeUsed           = 1
EddyBrakeUsed             = 1
MShoeBrakeBrakeUsed      = 1
EpBrakeUsed               = 1
T_brake_emergency        = 2.2
A_brake_emergency        = 0/1.07  140/0.80  150/0.44
K_wet                    = 0/1.2      160/0.35
K_dry_0                  = 0/1.3      160/0.37
K_dry_1                  = 0/1.4      160/0.38
K_dry_2                  = 0/1.5      160/0.39
K_dry_3                  = 0/1.6      160/0.40
K_dry_4                  = 0/1.7      160/0.41
K_dry_5                  = 0/1.8      160/0.42

```

|          |         |         |          |
|----------|---------|---------|----------|
| 180/0.44 | K_dry_6 | = 0/1.9 | 180/0.43 |
|          | K_dry_7 | = 0/2.0 | 160/0.44 |
| 250/0.38 | K_dry_8 | = 0/2.1 | 160/0.45 |
|          | K_dry_9 | = 0/2.2 | 160/0.46 |

### 2.2.15 Config\_SBModel\_Default section

- T\_brake\_service:

Table 90. T\_brake\_service

|                      |                             |
|----------------------|-----------------------------|
| <b>Description</b>   | Service brake build up time |
| <b>Range</b>         | Double value (in seconds)   |
| <b>Default value</b> | 1 second                    |

- A\_brake\_service:

Table 91. A\_brake\_service

|                      |   |
|----------------------|---|
| <b>Description</b>   | Service brake deceleration models   |
| <b>Format</b>        | <i>speed/deceleration [speed/deceleration [...]]</i> with unit km/h and m/s <sup>-2</sup> |
| <b>Default value</b> | 0.0/0.8272 600.0/0.0  |

### 2.2.16 Config\_SBModel\_0 to Config\_SBModel\_7 section

There is 7 possible sections corresponding to 7 combinations of brake used. Parameters are the same as **Config\_SBModel\_Default** section. In addition you can set which brake is used. Parameters added are the following :

- RegenBrakeUsed:

Table 92. RegenBrakeUsed

|                       |  |
|-----------------------|--|
| <b>Description</b>    | Indicate if regenerative brake is used |
| <b>Special values</b> | 0: not used                            |
| •                     | 1: used                                |
| <b>Default value</b>  | 0                                      |

- EddyBrakeUsed:

Table 93. EddyBrakeUsed

|                       |  |
|-----------------------|--|
| <b>Description</b>    | Indicate if eddy current brake is used |
| <b>Special values</b> | 0: not used                            |
| •                     | 1: used                                |

|                      |   |
|----------------------|---|
| <b>Default value</b> | 0 |
|----------------------|---|

- EpBrakeUsed:

Table 94. EpBrakeUsed

|                       |   |
|-----------------------|---|
| <b>Description</b>    | Indicate if electro-pneumatic brake is used |
| <b>Special values</b> | 0: not used<br>• 1: used                    |
| <b>Default value</b>  | 0   |

Example:

```
[ Config_SBModel_6 ]
RegenBrakeUsed      = 0
EddyBrakeUsed       = 1
EpBrakeUsed         = 1
T_brake_service     = 2.4
A_brake_service     = 0/1.07 70/0.80
```

### 2.2.17 Config\_NormSBModel\_TrainInP and Config\_NormSBModel\_TrainInG section

**Config\_NormSBModel\_TrainInG** allow you to set the normal service brake parameters for "Passenger train in P" or "Freight train in P".

**Config\_NormSBModel\_TrainInP** allow you to set the normal service brake parameters for "Freight Train in G".

For these sections the following parameters are needed:

- A\_SB01:

Table 95. A\_SB01

|                      |                        |
|----------------------|------------------------|
| <b>Description</b>   | Pivot values A_SB01    |
| <b>Range</b>         | Double value (in km/h) |
| <b>Default value</b> | 2                      |

- A\_SB12:

Table 96. A\_SB02

|                      |                        |
|----------------------|------------------------|
| <b>Description</b>   | Pivot values A_SB12    |
| <b>Range</b>         | Double value (in km/h) |
| <b>Default value</b> | 5                      |

- Brake\_Model\_1:

**Table 97. Brake\_Model\_1**

|                      |   |
|----------------------|---|
| <b>Description</b>   | Normal service brake deceleration model when A_brake_service(V = 0) <= A_SB01             |
| <b>Format</b>        | <i>speed/deceleration [speed/deceleration [...]]</i> with unit km/h and m/s <sup>-2</sup> |
| <b>Default value</b> | 0.0/0.2 600.0/0.0   |

- Brake\_Model\_2:

**Table 98. Brake\_Model\_2**

|                      |   |
|----------------------|---|
| <b>Description</b>   | Normal service brake deceleration model when A_SB01 < A_brake_service(V = 0) <= A_SB12    |
| <b>Format</b>        | <i>speed/deceleration [speed/deceleration [...]]</i> with unit km/h and m/s <sup>-2</sup> |
| <b>Default value</b> | 0.0/0.2 600.0/0.0   |

- Brake\_Model\_3:

**Table 99. Brake\_Model\_3**

|                      |   |
|----------------------|---|
| <b>Description</b>   | Normal service brake deceleration model when A_SB12 < A_brake_service(V = 0)              |
| <b>Format</b>        | <i>speed/deceleration [speed/deceleration [...]]</i> with unit km/h and m/s <sup>-2</sup> |
| <b>Default value</b> | 0.0/0.2 600.0/0.0   |

### 2.2.18 Kn\_Factors section

- Kn\_n:

**Table 100. Kn\_n**

|                      |  |
|----------------------|--|
| <b>Description</b>   | Correction factor for negative gradient on normal service deceleration   |
| <b>Format</b>        | <i>speed/factor [speed/factor [...]]</i> with unit km/h and Double value |
| <b>Default value</b> | 15.0/1.0   |

- Kn\_p:

**Table 101. Kn\_p**

|                      |  |
|----------------------|--|
| <b>Description</b>   | Correction factor for positive gradient on normal service deceleration   |
| <b>Format</b>        | <i>speed/factor [speed/factor [...]]</i> with unit km/h and Double value |
| <b>Default value</b> | 15.0/1.0   |

## 3 How to run the Automatic Test Runner

First of all, to run the Automatic Test Runner (preliminary Test Environment), a terminal has to be opened and the current directory changed to the Automatic Test Runner working directory:

```
>cd test_runner/bin
```



### 3.1 Single scenario execution

It is possible to run one single scenario by calling the application directly with the scenario as argument in the Automatic Test Runner working directory:

```
>./test_runner <ScenarioFileName>
```

### 3.2 Parameters

Parameters can be displayed by launching the software without any of them:

```
>./test_runner
```

Usage: test\_runner <FILE> [OPTIONS]

Options:

-m : manual mode, disable DMI driver action (automated clicks)

-j : enable JRU recording

-l : generate logs when scenario fail

-a : autoclose application at the end of scenario

### 3.3 Graphical user interface




Figure 2. Main window

Description :

1. Integrated ERA DMI (If available)
2. Logs selector. Default is “Scenario”.
3. Curve window button
4. Logs display
5. TIU : Output of train and on-board
6. Odometric data and internal status

### 3.3.1 DMI

Driver actions of a scenario are simulated on the DMI by automated clicks. For each driver action the sequence of clicks are saved in a configuration file `.testrunner_rc` located in the folder of the test runner application.

Example:

```
DriverID = "click(600,350);wait(200);click(500,110);wait(850);"
```

The command `wait(time)` permit the software to update content (display, data) before the next click. All commands shall be separated by a semicolon. Display of automated clicks is represented by a red circle on the DMI.




Figure 3. An automated click on Start

*Warning :* User actions on DMI are not inhibited. Therefore, it is not recommended to interact with the DMI during a test execution.

### 3.3.2 Logs view

The logs views informs user about:

- Executed commands
- Results of tests
- Trackside messages
- On-board messages

Messages can be displayed in a separated window by double-clicking on them.

*Radio 1* and *Radio 2* logs give status of the connection with the on-board. A green icon is displayed when connection is established with on-board. At the end of the scenario execution, the result is displayed:

- **SUCCESS:** the scenario has been executed until end successfully




Figure 4. Message window

- **FAILURE:** the scenario execution has been interrupted during execution due to an error in the scenario or a 'FATAL' argument in a condition test that has not been fulfilled.

### 3.3.3 Curve supervision display

Curve window display supervision curve computed by on-board. This window can be switched on/off by clicking Curve button on the main window.

Options on the bottom right of the window allow user to adjust the view. A save function is available to record all points in a single CSV file in the data/curve/ directory.




Figure 5. Curve window

#### 4 Example of scenario file

```
# test scenario definition
# start in level 1, move and transition to level 2

[SCENARIO]

# SoM in level 1

DRIVER_ACTION    = MainSwitchOn
WAIT_STATUS      = MODE_SB, 2, FATAL
DRIVER_ACTION    = OpenCabinA , 2
DRIVER_ACTION    = DriverID , 2
WAIT_TIME        = 1
DRIVER_ACTION    = Level1
WAIT_TIME        = 1
DRIVER_ACTION    = TrainData
WAIT_TIME        = 1
DRIVER_ACTION    = StartOfMission
WAIT_TIME        = 1
DRIVER_ACTION    = ACK

WAIT_STATUS      = LEVEL_1, EB_OFF, SB_OFF, MODE_SR, 5, FATAL

DRIVER_ACTION    = DirectionNominal
```

```

MOVE_TRAIN

WAIT_LOCATION = 30

DO_RADIO = Connection+MA

# wait TAF to level border
WAIT_LOCATION = 100
WAIT_RADIO_SENT = MArequestFree , 5, FATAL

# wait level transition location
WAIT_LOCATION = 130

WAIT_STATUS = LEVEL_2, EB_OFF, SB_OFF, MODE_FS, 5, FATAL

WAIT_LOCATION = 530
WAIT_STATUS = LEVEL_2, EB_OFF, SB_OFF, MODE_FS, 5, FATAL

# ----- Radio Procedures -----

[ Connection+MA]
WAIT_RADIO_SENT = InitCommSession , 10, FATAL
RBC_RADIO          = ConfigurationDetermination
WAIT_RADIO_SENT = SessionEstablished , 5, FATAL
WAIT_RADIO_SENT = ValidatedTrainData , 5, FATAL
RBC_RADIO          = AckTrainData
RBC_RADIO          = MA

# ----- RBC telegrams -----

[ ConfigurationDetermination ]
NID_MESSAGE = 32
NID_LRBG     = 1
M_VERSION = 16d

[ AckTrainData ]
NID_MESSAGE = 8
NID_LRBG     = 1

[MA]
NID_MESSAGE = 3
NID_LRBG     = 1
# MA data
NID_PACKET   = 15
Q_DIR         = 1
Q_SCALE       = 1
L_ENDSECTION = 5000
# SSP
NID_PACKET   = 27

```

```

Q_DIR          = 1
Q_SCALE        = 1
V_STATIC       = 60
# Gradient
NID_PACKET     = 21

# ----- EVC telegrams -----

[ InitCommSession ]
NID_MESSAGE = 155

[ SessionEstablished ]
NID_MESSAGE = 159

[ ValidatedTrainData ]
NID_MESSAGE = 129
NID_PACKET = 0
NID_PACKET = 11

[ MArequestFree ]
NID_MESSAGE = 132
NID_PACKET = 9
NID_LTRBG   = 11

# ----- Balises -----

[ BaliseTrackside ]
# announcement of level transition
30 = BG1_1
35 = BG1_2

# TAF free to L2 border
100 = BG2_1
105 = BG2_2

[ BG1_1 ]
N_PIG   = 0
N_TOTAL = 1
NID_C   = 0
NID_BG  = 1
Q_LINK  = 1
# level transition packet
NID_PACKET = 41
Q_DIR      = 1
Q_SCALE    = 1
D_LEVELTR  = 100
M_LEVELTR  = 3
L_ACKLEVELTR = 50
# order to contact RBC
NID_PACKET = 42

```

```

Q_DIR                = 1
Q_RBC                = 1
# Ending packet
NID_PACKET = 255

[BG1_2]
N_PIG    = 1
N_TOTAL  = 1
NID_C    = 0
NID_BG   = 1
Q_LINK   = 1
# Ending packet
NID_PACKET = 255

[BG2_1]
N_PIG    = 0
N_TOTAL  = 1
NID_C    = 0
NID_BG   = 2
Q_LINK   = 1
# TAF free to level 2 border
NID_PACKET = 90
Q_DIR      = 1
NID_BG     = 11
# Ending packet
NID_PACKET = 255

[BG2_2]
N_PIG    = 1
N_TOTAL  = 1
NID_C    = 0
NID_BG   = 2
Q_LINK   = 1
# Ending packet
NID_PACKET = 255

# ----- Speed Profile -----

[ SpeedProfile ]
0 = 0
500 = 40
1000 = 0

# ----- configuration -----

[ Config_EVCInit ]
LINE_LEVEL      = 1
COUNTRY_ID      = 0
GROUP_ID        = 4522
DISTANCE        = 50

```



|           |   |         |
|-----------|---|---------|
| DIRECTION | = | NOMINAL |
| VALIDITY  | = | VALID   |

[ Config\_TrainData ]

|                            |   |                     |
|----------------------------|---|---------------------|
| ETCS_ID                    | = | 4554                |
| BALISEANTENNA_OFFSET       | = | 10                  |
| TRAIN_CATEGORY             | = | 1                   |
| LOADING_GAUGE_MASK         | = | 1                   |
| AXLE_LOAD                  | = | 237000              |
| TRACTION_POWERS            | = | 0, 1, 5, 41, 78, 11 |
| TRAIN_LENGTH               | = | 100                 |
| TRAIN_MASS                 | = | 142000.0            |
| TRAIN_MAXACCEL             | = | 0.5                 |
| SPEED_MAX                  | = | 300                 |
| EB_TIME                    | = | 1.0                 |
| EB_TIME                    | = | 1.0                 |
| CUTOFF_TIME                | = | 1.0                 |
| BALISE_COM_AVAILABLE       | = | 1                   |
| LOOP_COM_AVAILABLE         | = | 1                   |
| RADIO_COM_AVAILABLE        | = | 1                   |
| INTEGRITY_DEVICE_AVAILABLE | = | 1                   |
| SERVICE_BRAKE_AVAILABLE    | = | 1                   |
| ETCS_PHONE1                | = | 1234123412341234    |
| ETCS_PHONE2                | = | 1234123412341235    |

[ Config\_SRSNationalDefaults ]

|                         |   |     |
|-------------------------|---|-----|
| COUNTRY_ID              | = | 0   |
| DRIVER_ADHESION         | = | 0   |
| SH_SPEED                | = | 30  |
| SR_SPEED                | = | 40  |
| OS_SPEED                | = | 30  |
| UN_SPEED                | = | 100 |
| RELEASE_SPEED           | = | 40  |
| ROLLAWAY_DISTANCE       | = | 2   |
| SB_USETOTARGET          | = | 1   |
| EB_RUNRELEASE           | = | 0   |
| OVERRIDEEOA_ENTRYSPEED  | = | 0   |
| OVERRIDEEOA_MAXSPEED    | = | 30  |
| OVERRIDEEOA_MAXDISTANCE | = | 200 |
| OVERRIDEEOA_MAXTIME     | = | 60  |
| DRIVERID_RUNCHANGE      | = | 1   |