

101	①	②	③	④	⑤	flashing : Error / initialing battery only
102	①	② ②	③ ②	④	⑤	flashing : Error / initialing charger inserted
201	①	②	③	④	⑤	flashing 5 second, wait 30 senconds, repeat battery volumn less than 10%, suggest chargeing ASAP battery only
202	①	②	③	④	⑤	flashing only after key being pressed 5 second battery volumn between 10% and 20% battery only
203	①	②	③	④	⑤	flashing only after key being pressed 5 second battery volumn between 20% and 40% battery only
204	①	②	③	④	⑤	flashing only after key being pressed 5 second battery volumn between 40% and 60% battery only
205	①	②	③	④	⑤	flashing only after key being pressed 5 second battery volumn between 60% and 80% battery only
206	①	②	③	④	⑤	flashing only after key being pressed 5 second battery volumn between 80% and 100% battery only
301	① ①	②	③	④	⑤	always flashing battery volumn less than 0% to 20% charger inserted
302	① ①	① ①	③	④	⑤	always flashing battery volumn less than 20% to 40% charger inserted
303	① ①	① ①	① ①	④	⑤	always flashing battery volumn less than 40% to 60% charger inserted
304	① ①	① ①	① ①	① ①	⑤	always flashing battery volumn less than 60% to 80% charger inserted
305	① ①	① ①	① ①	① ①	① ①	always flashing battery volumn less than 80% to 90% charger inserted
306	① ①	① ①	① ①	① ①	① ①	contant on, no flashing, battery is full. battery volumn less than 90% to 100% charger inserted