

Experion PKS
Moore Mycro Interface Reference

EPDOC-XX73-en-431A
February 2015

Release 431

| Document | Release | Issue | Date |
|--------------------|---------|-------|---------------|
| EPDOC-XX73-en-431A | 431 | 0 | February 2015 |

Disclaimer

This document contains Honeywell proprietary information. Information contained herein is to be used solely for the purpose submitted, and no part of this document or its contents shall be reproduced, published, or disclosed to a third party without the express permission of Honeywell International Sàrl.

While this information is presented in good faith and believed to be accurate, Honeywell disclaims the implied warranties of merchantability and fitness for a purpose and makes no express warranties except as may be stated in its written agreement with and for its customer.

In no event is Honeywell liable to anyone for any direct, special, or consequential damages. The information and specifications in this document are subject to change without notice.

Copyright 2015 - Honeywell International Sàrl

Contents

- Planning considerations for installing and configuring Moore Mycro controllers 5**
 - Devices supported by the Moore Mycro interface 6
 - Other documentation for Moore Mycro 7
 - Architectures for Moore Mycro 8
 - Configuring the Moore Mycro controller 9
 - Communication settings for Moore Mycro 10
- Moore Mycro channel and controller reference 11**
 - Main properties for a Moore Mycro channel 12
 - Port properties for a Moore Mycro channel 14
 - Main properties for a Moore Mycro controller 15
 - Optimizing Moore Mycro scanning performance 16
 - Moore Mycro scan packets 16
- Moore Mycro points reference 17**
 - Defining a Moore Mycro address for a point parameter 18
 - Addresses supported by the Moore Mycro interface 20
- Troubleshooting Moore Mycro issues 33**
 - Testing Moore Mycro communications with the server 34
 - Troubleshooting Moore Mycro point configuration errors 34
- Notices 35**
 - Documentation feedback 36
 - How to report a security vulnerability 37
 - Support 38
 - Training classes 39

Planning considerations for installing and configuring Moore Mycro controllers

This reference describes how to set up, configure, and test Moore Mycro controller communications with the server.

Revision history

| Revision | Date | Description |
|----------|---------------|------------------------------|
| A | February 2015 | Initial release of document. |

How to use this guide

The following steps show the order in which the controller interface should be configured. Complete each step before starting the next.

Steps for connecting and configuring a Moore Mycro 352 controller.

| Steps | Go to |
|---|--|
| Set the communication parameters | Communication settings for Moore Mycro |
| Connect to the server via RS-232 or RS-422 | Configuring the Moore Mycro controller |
| Use Quick Builder to define channels | <ul style="list-style-type: none">Moore Mycro channel and controller reference<i>Quick Builder User's Guide</i> |
| Use Quick Builder to define controllers | <ul style="list-style-type: none">Moore Mycro channel and controller reference<i>Quick Builder User's Guide</i> |
| Download channel and controller definitions to the server | <i>Quick Builder User's Guide</i> |
| Test communications | Testing Moore Mycro communications with the server |
| Use Quick Builder to define points | Defining a Moore Mycro address for a point parameter |

Related topics

“Devices supported by the Moore Mycro interface” on page 6

“Other documentation for Moore Mycro” on page 7

“Architectures for Moore Mycro” on page 8

“Communication settings for Moore Mycro” on page 10

“Configuring the Moore Mycro controller” on page 9

“Moore Mycro channel and controller reference” on page 11

“Testing Moore Mycro communications with the server” on page 34

“Defining a Moore Mycro address for a point parameter” on page 18

Devices supported by the Moore Mycro interface

The server specifically supports the Moore Mycro 352 device using this interface. See the *SLDC Link Interface Communications User's Manual* for details on available addresses for this device.

While the interface has not been tested with the following devices, the communication protocol used is the same as the Moore Mycro 352 device. Therefore, this interface should work with the following controllers:

- Moore Model 324 Programmable Sequence Controller
- Moore Model 351 Triple Loop Digital Controller
- Moore Model 382 Logic and Sequence Controller
- Moore Model 383 Multi-Point Display Station

Other documentation for Moore Mycro

The following Moore Products books describe in great detail the address space of all the devices supported by this interface. They also provide information about the physical configuration of the Units. Reading these books would be useful when installing the interface.

- *Model 352 SLDC Link Interface Communications User's Manual*; Part No: AD352-40
- *Model 352 SLDC Installation and Service Instruction*; Part No: SD352

The manuals listed below provide detailed information concerning the configuration of other units.

- *Model 320 Local Instrument Link Independent Computer Interface User's Manual*; Part No: AD320-10
- *Local Instrument Link - Installation & Service Manual*; Part No: SD15492

Architectures for Moore Mycro

“Figure 1: Sample system design—minimum system” describes an example of a system design integrating the server with a network of Moore controllers.




Figure 1: Sample system design—minimum system

The RS-232 and RS-422 server interface to the Moore 320 ICI allows only one connected ICI unit per server channel.

As many as 32 Moore controllers can be connected at once on a single Local Instrument Link (LIL).

Using two links enables up to 64 Moore stations to be connected to a single channel. “Figure 2: Sample system design—expanded system” describes an expanded LIL system.




Figure 2: Sample system design—expanded system

Configuring the Moore Mycro controller

Configure the Moore Mycro 352 SLDC and Moore Mycro 320 ICI before connecting to the server. The following configuration must be performed to allow the server interface to communicate correctly with the devices. See the Moore Mycro documentation for details on setting up the following configuration.

To connect Moore Mycro 352 to the server

- 1 Enable the Link Interface Option Function Block on the Moore Mycro 352 (Function Block 98 on the device), then set up the relevant internal variables in Function Block 98 to point to the appropriate internal variables.
- 2 Ensure that the Moore is in Console Source mode (as opposed to Computer Source mode). This is verified by building a status point to read Bit 4 of L1ST (see the topic titled "Addresses supported by the Moore Mycro interface" for more information).
- 3 The Moore 320 ICI must be set up to use Binary Transmission Mode, Link Acknowledge Delay Enabled, and Null Filled Data Enabled.
Any other configuration of the Moore PLCs should be done by direct hardware configuration, a third-party loader package, or if possible by using the Moore Mycro test utility, **mmutst**. See the topic titled "Testing Moore Mycro communications with the server" for instructions on running the test utility.

Related topics

"Planning considerations for installing and configuring Moore Mycro controllers" on page 5

"Addresses supported by the Moore Mycro interface" on page 20

"Testing Moore Mycro communications with the server" on page 34

Communication settings for Moore Mycro

Set up the communication parameters between the server and the Moore ICI. See the Moore documentation for details on setting up these parameters.

The Unit Address of each device on the Local Instrument Link must be set to a unique value between 1 and 64.

Parity is selectable for the interface between the ICI and the server computer. Parity may be ODD, EVEN, or NONE. Use of parity is recommended.

Bauds are selectable for the interface between the ICI and the server computer. “Table 1: Selectable bauds for Moore 320 ICI” displays selectable bauds for the Moore 320 ICI.

Table 1: Selectable bauds for Moore 320 ICI

| Baud | Moore 320 ICI |
|--------|---------------|
| 38,400 | Yes |
| 19,200 | Yes |
| 9600 | Yes |
| 4800 | Yes |
| 2400 | Yes |
| 1200 | Yes |
| 300 | Yes |

Moore Mycro channel and controller reference

This section describes the configuration and addressing information specific to Moore Mycro channels and controllers.

In addition to the information contained in this reference, and for help to build channels and controllers, see the section titled "Building controllers or channels" in the *Quick Builder User's Guide*.

Related topics

"Main properties for a Moore Mycro channel" on page 12

"Port properties for a Moore Mycro channel" on page 14

"Main properties for a Moore Mycro controller" on page 15

"Optimizing Moore Mycro scanning performance" on page 16

"Planning considerations for installing and configuring Moore Mycro controllers" on page 5

Main properties for a Moore Mycro channel

The Main tab defines the basic properties for a Moore Mycro channel.

For information about how to create a channel, see the topic titled "Building controllers and channels" in the *Quick Builder User's Guide*.



Attention

You need to define one server channel for each connection with a Moore Mycro 320 ICI.

| Property | Description |
|----------------------|--|
| Name | The unique name of the channel. A maximum of 10 alphanumeric characters (no spaces or double quotes). Note: In Station displays, underscore characters (_) appear as spaces. |
| Description | (Optional) A description of the channel. A maximum of 132 alphanumeric characters, including spaces. |
| Marginal Alarm Limit | <p>The communications alarm marginal limit at which the channel is declared to be marginal. When this limit is reached, a high priority alarm is generated. To change the priority of the alarm system wide, see the topic titled "Configuring system alarm priorities" in the <i>Server and Client Configuration Guide</i>. To change the priority of the alarm for one channel, see the topic titled "About configuring custom system alarm priorities for an individual channel or controller" in the <i>Server and Client Configuration Guide</i>.</p> <p>A channel barometer monitors the total number of requests and the number of times the controller did not respond or response was incorrect. The barometer increments by two or more, depending on the error, and decrements for each good call.</p> <p>To calculate an acceptable marginal alarm limit, use the formula: Square root of the number of controllers on the channel \times Marginal Alarm Limit defined on those controllers (Normally, you specify the same value for all controllers on a channel).</p> <p>For example, if there are 9 controllers on the channel and their Marginal Alarm Limit is set to 25, the value would be 3 (which is the square root of 9) \times 25 = 75.</p> |
| Fail Alarm Limit | <p>The communications alarm fail limit at which the channel is declared to have failed. When this barometer limit is reached, an urgent alarm is generated. To change the priority of the alarm system wide, see the topic titled "Configuring system alarm priorities" in the <i>Server and Client Configuration Guide</i>. To change the priority of the alarm for one channel, see the topic titled "About configuring custom system alarm priorities for an individual channel or controller" in the <i>Server and Client Configuration Guide</i>.</p> <p>Set this to double the value specified for the channel Marginal Alarm Limit.</p> |
| Connect Timeout | <p>The length of time that the server attempts to connect to the controller. The server will stop trying to connect to the controller once the timeout period passes. The default value 10 seconds.</p> <p>Use the default value unless the communications line has a high error rate, or unless you are using modems.</p> |
| Read Timeout | <p>The length of time that the server will wait for a reply from the controller. The server will stop waiting once the timeout period passes. The default value is 2 seconds.</p> <p>Use the default value unless the communications line has a high error rate, or unless you are using modems.</p> |
| Item Type | The type of channel specified when this item was created. |
| Last Modified | The date and time the channel properties were modified. |
| Last Downloaded | The date and time the channel was last downloaded to the server. |

| Property | Description |
|-------------|--|
| Item Number | <p>The unique item number currently assigned to this channel, in the format <i>CHNCC</i>, where <i>cc</i> is the channel number.</p> <p>You can change the item number if you need to match your current server database configuration. The number must be between <i>01</i> and the maximum number of channels allowed for your system. For more information about setting the maximum value, see the topic titled "Adjusting sizing of non-licensed items" in the <i>Supplementary Installation Tasks Guide</i>.</p> |

Port properties for a Moore Mycro channel

The Port tab defines the communication-related properties for a channel. The only Port Type you can define for a Moore Mycro is *serial*.



Attention

The Serial Port settings must match the settings on your communication devices.

Serial port properties

| Property | Description |
|---------------------|--|
| Serial Port Name | The device name of the serial port. |
| Baud | The number of data bits per second. The default is <i>9600</i> . |
| Number of Data Bits | The number of data bits used for transmission. The default is <i>8</i> . |
| Stop Bits | The number of stop bits used for transmission The default is <i>1</i> . |
| Parity | Defines parity verification of each character and must match configuration on the end device. The default is <i>NONE</i> . |
| Checksum | The type of checksum error detection used for the port. Select the value that matches the setting on the communication device. <ul style="list-style-type: none"> • <i>CRC16_0</i> or <i>CRC16_1</i> (if Cyclic Redundancy Check (CRC) is set) • <i>ONESCOMP</i> or <i>TWOSCOMP</i> (if Longitudinal Redundancy Check (LRC) is set) • <i>XOR</i> (If exclusive or is set) |
| XON/XOFF | The type of XON/XOFF software flow control used to stop a receiver from being overrun with messages from a sender. The types are: <ul style="list-style-type: none"> • <i>Input</i> (use XON/XOFF to control the flow of data on the receive line) • <i>none</i> (default) • <i>Output</i> (use XON/XOFF to control the flow of data on the transmit line) |
| Handshaking Options | RS-232 <ul style="list-style-type: none"> • Enable RTS/CTS flow control. Select if you want to use RTS/CTS for flow control to stop a receiver from being overrun with messages from a sender. • Detect DCD. Select if the Data Carrier Detect communication status line of the COM port requires monitoring (usually when using modem or microwave linking). When selected, the communications fails if the desired COM status line is not high—for example, on a dial-up link connection for a modem. • Detect DSR. Select if the Data Set Ready communication status line of the COM port requires monitoring (usually when using modem or microwave linking). When selected, the communications fails if the desired COM status is not achieved. RS-422. No options available. RS-485. Not applicable for Moore Mycro. |

Main properties for a Moore Mycro controller

Use the Main tab to define the basic properties for a Moore Mycro controller.

For information about how to create a controller, see the topic titled "Building controllers and channels" in the *Quick Builder User's Guide*.

| Property | Description |
|----------------------|---|
| Name | The unique name of the controller. A maximum of <i>10</i> alphanumeric characters (no spaces or double quotes). Note: In Station displays, underscore characters (<i>_</i>) appear as spaces. |
| Description | (Optional) A description of the controller. A maximum of <i>132</i> alphanumeric characters, including spaces. |
| Channel Name | The name of the channel on which the controller communicates with the server. (You must have already defined a channel for it to appear in this list.) |
| Marginal Alarm Limit | The communications alarm marginal limit at which the controller is declared to be marginal. When this limit is reached, a high priority alarm is generated. To change the priority of the alarm system wide, see the topic titled "Configuring system alarm priorities" in the <i>Server and Client Configuration Guide</i> . To change the priority of the alarm for one controller, see the topic titled "About configuring custom system alarm priorities for an individual channel or controller" in the <i>Server and Client Configuration Guide</i> . A controller barometer monitors the total number of requests and the number of times the controller did not respond or response was incorrect. The barometer increments by two or more, depending on the error, and decrements for each good call. The default value is <i>25</i> . |
| Fail Alarm Limit | The communications alarm fail limit at which the controller is declared to have failed. When this barometer limit is reached, an urgent alarm is generated. To change the priority of the alarm system wide, see the topic titled "Configuring system alarm priorities" in the <i>Server and Client Configuration Guide</i> . To change the priority of the alarm for one controller, see the topic titled "About configuring custom system alarm priorities for an individual channel or controller" in the <i>Server and Client Configuration Guide</i> . Set this to double the value specified for the controller Marginal Alarm Limit. The default is <i>50</i> . |
| Controller Type | Select the controller type as one of: <ul style="list-style-type: none"> • 352 Single Loop Digital Controller • 320 Independent Computer Interface • 383 Multi Point Display Station • 351 Triple Loop Digital Controller • 324 Programmable Sequence Controller • 382 Logic and Sequence Controller |
| Station Address | The station address (LSA) of the Moore Mycro device. |
| Item Type | The type of controller specified when this item was created. |
| Last Modified | The date and time the controller properties were modified. |
| Last Downloaded | The date and time the controller was last downloaded to the server. |
| Item Number | The unique item number currently assigned to this controller, in the format <i>RTUnnnnn</i> . You can change the item number if you need to match your current server database configuration. The number must be between <i>01</i> and the maximum number of controllers allowed for your system. For more information about setting the maximum value, see the topic titled "Adjusting sizing of non-licensed items" in the <i>Supplementary Installation Tasks Guide</i> . |

Optimizing Moore Mycro scanning performance

The maximum amount of data that can be acquired from an controller is influenced by the rate of sending scan packets to the controller. An understanding of the Moore Mycro scan packets will help you configure points so that optimal data acquisition performance can be achieved by maximizing the amount of data acquired with each scan packet.

The scan packets that have been built can be listed by using the utility **lisscn** (list scan). Listing scan packets helps verify the scanning strategy.

For more information about **lisscn**, see the section titled "Command Reference" in the *Server and Client Configuration Guide*.

Moore Mycro scan packets

Up to 100 controller addresses using the same scan period and accessing parameter 1 of the Moore Mycro controller can be combined into a single scan packet. However, addresses not accessing parameter 1 but using the same scan period can only be combined in groups of five into a single scan packet. Therefore, to minimize the number of scan packets, use slower scan periods for all points not accessing parameter 1 and try to use the same scanning period for all these points as well.

Moore Mycro points reference

This section describes how to configure points for a Moore Mycro controller using Quick Builder.

In addition to the information contained in this reference, and for help to build points, see the section titled "Building and configuring points" in the *Quick Builder User's Guide*.

Related topics


"Defining a Moore Mycro address for a point parameter" on page 18

Defining a Moore Mycro address for a point parameter

For **PV Source Address**, **Source Address**, and **Destination Address** the format for a Moore Mycro controller address is:

ControllerName Address

| Part | Description |
|-----------------------|---|
| <i>ControllerName</i> | The name of the Moore Mycro controller. |
| <i>Address</i> | <p>The address in the controller where the value is recorded. Address syntax will depend on the type of address format you select:</p> <ul style="list-style-type: none"> • Address Format Option 1. The preferred form of addressing. See the section below titled "Address Format Option 1" for more information. • Address Format Option 2. Explicitly states the channel and parameter number of the parameter required. It should be used only to specify addresses on the device that are <i>not listed</i> in the topic titled "Addresses supported by the Moore Mycro interface," or addresses where no mnemonic has been defined. See the section below titled "Address Format Option 2" for more information. |

If you would like help with the address, you can use the Address Builder. To display the Address Builder, click  next to **Address**.

Address Format Option 1

To specify the address of a point parameter in a controller LPU or other controller, the preferred address format is:

A:Mnemonic [B:bb|ParamType]

| Part | Description |
|------------------|---|
| <i>Mnemonic</i> | ASCII representation of the address. See the topic titled "Addresses supported by the Moore Mycro interface." |
| <i>bb</i> | <p>(Optional) Bit Number for status point addresses only. Value between 0 and 15. If specified, only the raw bit value is used. Cannot be used in conjunction with <i>ParamType</i>.</p> <p>All status point types in server and MD parameters of a point are automatically set to address bits (Status Word type) even if the B: command line is not specified. If the B: is not specified for a status word then the bit offset is set to the default of 0.</p> |
| <i>ParamType</i> | (Optional) Tuning parameter type override. If specified, will override the parameter type given in the device address definition file, <i>data/mmu_352_def</i> . Cannot be used in conjunction with bit number. See the section below titled "Parameter data types." |

Example

A:L1S (Loop 1 Set point)

A:L2V (Loop 2 Valve)

A:SS B:6 (Configuration Hold Mode of Station Status Word)

A:ING DIG (Channel G as a Digital)

Address Format Option 2

While the Moore Mycro 352 Interface should work with all addressable parameters, it has not been tested with all of them and its operation is not guaranteed.

The addressing format is:

C: *ccc* P: *ppp* [B: *bb* | *ParamType*]

| Part | Description |
|------------------|---|
| <i>ccc</i> | Moore Channel (not the server channel) in the Mycro 352, between 1 and 256. |
| <i>ppp</i> | Moore Parameter, between 1 and 256. |
| <i>bb</i> | (Optional) Bit Number for status point addresses only. Value between 0 and 15. If specified, only the raw bit value is used. Cannot be used in conjunction with <i>ParamType</i> . All status point types in server and MD parameters of a point are automatically set to address bits (Status Word type) even if the B: command line is not specified. If the B: is not specified for a status word then the bit offset is set to the default of 0. |
| <i>ParamType</i> | (Optional) Tuning parameter type override. If specified, will override the parameter type given in the device address definition file, <i>data/mmu_352_def</i> . Cannot be used in conjunction with bit number. See the section below titled "Parameter data types." |



Attention

The channel or the parameter can be entered in decimal, hexadecimal or octal. If the channel or parameter is prefixed by 0x, then it is processed as hexadecimal, for example, *C:0x10 P:0x08* = *C:16 P:8*. If the channel or parameter is prefixed by 0 then it is processed as octal, for example, *C:010 P:005* = *C:8 P:5*. If there is no prefix it is treated as decimal.

Example

C:6 P:3 (Time Integral for Moore 352 Controller #1 with Time scaling)

C:19 P:1 (Channel B Alarm Status word)

C:3 P:1 B:14 (Bit of the status parameter which indicates whether the associated SLDC Station has an error)

C:210 P:20 PRCNT (A previously undefined address at channel 210 parameter 20)

Parameter data types

Eight different parameter data types can be applied to each point address.

| Data Type | Description | Counts | Server Scaled |
|-----------|----------------------|-----------------|---------------|
| PGAIN | Proportional Gain | -100.0 to 100.0 | No |
| ITIME | Integral Time | 0.01 to 1000 | No |
| DTIME | Derivative Time | 0.00 to 100.0 | No |
| DGAIN | Derivative Gain | 1.00 to 30.00 | No |
| PRCNT | Percentage (Default) | 0 to 100.0% | No |
| STAND | Standard (Scaled) | 0 to 100.0% | Yes |
| C16 | One to one mapping | 0 to 65535 | No |
| DIG | Mapped Digital | 0 or 1 | No |

The parameter data type STAND is a scaled format of PRCNT and will be scaled by server to a value between the ranges set by the RANGE keyword during the point build. Certain addresses on the Moore 352 device require specific RANGE settings to output the correct value. See the topic titled "Addresses supported by the Moore Mycro interface" for more information.

All the parameter data types are 16-bit (2-byte) words. The default data type for predefined parameters is specified in the device address definition file *mmu_352_def*. The default parameter data type for addresses that

are not defined in the definition file is the Percentage Type. The device address definition file also uses the ASCII string STATS to define addresses which are Status Words.

The parameter data type DIG allows Moore digital addresses to be interpreted as a digital value in the server. The Moore 352 internally stores a digital value as an analog value. It uses the value 0x080 for the value 0 and the value 0xF80 for the value 1. Setting a status point parameter's data type to be DIG causes the server to automatically perform this mapping when reading or writing from a Moore 352 address.

Example

Configure a status point PV address as A:IND DIG

The server will read the analog value at the address IND. If the value is 0xF80 then the status point will be set to 1. If the value is 0x080 then the status point will be set to 0.

Related topics

“Planning considerations for installing and configuring Moore Mycro controllers” on page 5

Addresses supported by the Moore Mycro interface

All the Moore channel parameters listed in the *Moore Model 352 SLDC User's Manual* are addressable. Note that not all parameters are able to be controlled.

The ASCII names for each address are defined in text files found in *server\data*. There is one text file for each type of Moore Mycro device. To add additional ASCII names for addresses or to look up the configured ASCII name for an address, view the associated device address definition file for that device.

| Moore Mycro Device | Device Address Definition Filename |
|--------------------|------------------------------------|
| Moore 352 | mmu_352_def |
| Moore 320 | mmu_320_def |
| Moore 383 | mmu_383_def |
| Moore 351 | mmu_351_def |
| Moore 324 | mmu_324_def |
| Moore 382 | mmu_382_def |

Global data parameters (Parameter 1) supported for the Moore 352

Check the Read/Write column to determine which addresses are writable. The interface does not allow any of the database records to be accessed.

| Channel | Param Type | Mnemonic | Read/Write | Description |
|---------|---------------|----------|------------|-----------------------------|
| 1 | C16 | SDS | R | Station Data Size (\$0026) |
| 2 | C16 | ST | R | Station Type (\$0001) |
| 3 | Status word 4 | SS | R/W | Station Status |
| 4 | C16 | SEC | R | Station Error Code |
| 5 | Status word 5 | FBS | R/W | Function Block Status |
| 6 | STAND | L1P | R | Loop 1 Process ¹ |
| 7 | STAND | L1S | R/W | Loop 1 Set point |

¹ For L1P, L1S, L2P, L2S - RANGE in Quick Builder should match the Process HI and LO configured on the device

| Channel | Param Type | Mnemonic | Read/Write | Description |
|---------|----------------|----------|------------|------------------------|
| 8 | PRCNT | L1V | R/W | Loop 1 Valve |
| 9 | Status word 2 | L1ST | R/W | Loop 1 Status |
| 10 | Status word 6 | L1A | R/W | Loop 1 Alarm Status |
| 11 | STAND | L2P | R | Loop 2 Process |
| 12 | STAND | L2S | R/W | Loop 2 Set point |
| 13 | PRCNT | L2V | R | Loop 2 Valve |
| 14 | Status word 15 | L2ST | R/W | Loop 2 Status |
| 15 | STAND | INA | R | Channel A |
| 16 | Status word 7 | CAA | R/W | Channel A Alarm Status |
| 17 | Status word 8 | CAS | R/W | Channel A Status |
| 18 | STAND | INB | R | Channel B |
| 19 | Status word 9 | CBA | R/W | Channel B Alarm Status |
| 20 | Status word 10 | CBS | R/W | Channel B Status |
| 21 | STAND | INC | R | Channel C |
| 22 | Status word 11 | CCA | R/W | Channel C Alarm Status |
| 23 | Status word 12 | CCS | R/W | Channel C Status |
| 24 | STAND | IND | R | Channel D |
| 25 | Status word 13 | CDA | R/W | Channel D Alarm Status |
| 26 | Status word 14 | CDS | R/W | Channel D Status |
| 27 | STAND | INE | R | Channel E |
| 28 | STAND | INF | R | Channel F |
| 29 | STAND | ING | R | Channel G |
| 30 | STAND | INH | R | Channel H |
| 31 | STAND | O70 | R/W | FB98 Output No. 70 |
| 32 | STAND | O71 | R/W | FB98 Output No. 71 |
| 33 | STAND | O72 | R/W | FB98 Output No. 72 |
| 34 | STAND | O73 | R/W | FB98 Output No. 73 |
| 35 | STAND | O74 | R/W | FB98 Output No. 74 |
| 36 | STAND | O75 | R/W | FB98 Output No. 75 |
| 37 | STAND | O76 | R/W | FB98 Output No. 76 |
| 38 | STAND | O77 | R/W | FB98 Output No. 77 |

Data parameters other than 1 supported for the Moore 352

| Channel | Parameter | Param Type | Mnemonic | Read/Write | Description |
|---------|-----------|------------|----------|------------|-------------------------------------|
| 6 | 2 | PGAIN | PG1 | R/W | Proportional Gain for Controller #1 |
| | 3 | ITIME | TI1 | R/W | Time Integral for Controller #1 |
| | 4 | DTIME | TD1 | R/W | Time Derivative for Controller #1 |
| | 5 | DGAIN | DG1 | R/W | Derivative Gain for Controller #1 |
| | 6 | PRCNT | MR1 | R | Manual Reset for Controller #1 |

| Channel | Parameter | Param Type | Mnemonic | Read/Write | Description |
|---------|-----------|------------|----------|------------|---|
| 7 | 7 | STAND | R | R | Ratio for FB07 ² |
| | 8 | STAND | B | R | Bias for FB08 ³ |
| | 2 | PRCNT | TSP1 | R/W | Target Set point for Set point #1 |
| | 3 | STAND | RT1 | R/W | Ramp Time for Set point #1 ⁴ |
| 10 | 4 | PRCNT | SPHL1 | R/W | Hi Limit setting of HI/LO Limit #1 |
| | 5 | PRCNT | SPLL1 | R/W | Lo Limit setting of HI/LO Limit #1 |
| | 2 | PRCNT | L1A1L | R/W | Loop 1 Alarm #1 Limit |
| | 3 | PRCNT | L1A2L | R/W | Loop 1 Alarm #2 Limit |
| | 4 | PRCNT | L1A3L | R/W | Loop 1 Alarm #3 Limit |
| | 5 | PRCNT | L1A4L | R/W | Loop 1 Alarm #4 Limit |
| | 6 | Status | L1A1T | R | Loop 1 Alarm #1 Type Word |
| | 7 | Status | L1A2T | R | Loop 1 Alarm #2 Type Word |
| 11 | 8 | Status | L1A3T | R | Loop 1 Alarm #3 Type Word |
| | 9 | Status | L1A4T | R | Loop 1 Alarm #4 Type Word |
| | 2 | PGAIN | PG2 | R/W | Proportional Gain for Controller #2 |
| | 3 | ITIME | TI2 | R/W | Time Integral for Controller #2 |
| | 4 | DTIME | TD2 | R/W | Time Derivative for Controller #2 |
| | 5 | DGAIN | DG2 | R/W | Derivative Gain for Controller #2 |
| | 6 | PRCNT | MR2 | R/W | Manual Reset for Controller #2 |
| 12 | 7 | ITIME | TH | R/W | Time Lead for FB41 |
| | 8 | ITIME | TL | R/W | Time Lag for FB40 |
| | 2 | PRCNT | TSP2 | R/W | Target Set point for Set point #2 |
| | 3 | STAND | RT2 | R/W | Ramp Time for Set point #2 ⁵ |
| 16 | 4 | PRCNT | SPHL2 | R/W | Hi Limit setting for HI/LO Limit #2 |
| | 5 | PRCNT | SPLL2 | R/W | Lo Limit setting for HI/LO Limit #2 |
| 19 | 2 | PRCNT | CAA1L | R/W | Channel A Alarm #1 Limit |
| | 3 | PRCNT | CAA2L | R/W | Channel A Alarm #2 Limit |
| | 6 | Status | CAA1T | R | Channel A Alarm #1 Type Word |
| | 7 | Status | CAA2T | R | Channel A Alarm #2 Type Word |
| 19 | 2 | PRCNT | CBA1L | R/W | Channel B Alarm #1 Limit |
| | 3 | PRCNT | CBA2L | R/W | Channel B Alarm #2 Limit |
| | 6 | Status | CBA1T | R | Channel B Alarm #1 Type Word |
| | 7 | Status | CBA2T | R | Channel B Alarm #2 Type Word |

² For R - RANGE line in Quick Builder should be set to RANGE 0 38.4

³ For B - RANGE line in Quick Builder should be set to RANGE -100 100

⁴ For RT1 - RANGE line in Quick Builder should be set to RANGE 0 3840

⁵ For RT2 - RANGE line in Quick Builder should be set to RANGE 0 3840

| Channel | Parameter | Param Type | Mnemonic | Read/Write | Description |
|---------|-----------|------------|----------|------------|------------------------------|
| 22 | 2 | PRCNT | CCA1L | R/W | Channel C Alarm #1 Limit |
| | 3 | PRCNT | CCA2L | R/W | Channel C Alarm #2 Limit |
| | 6 | Status | CCA1T | R | Channel C Alarm #1 Type Word |
| | 7 | Status | CCA2T | R | Channel C Alarm #2 Type Word |
| 25 | 2 | PRCNT | CDA1L | R/W | Channel D Alarm #1 Limit |
| | 3 | PRCNT | CDA2L | R/W | Channel D Alarm #2 Limit |
| | 6 | Status | CDA1T | R | Channel D Alarm #1 Type Word |
| | 7 | Status | CDA2T | R | Channel D Alarm #2 Type Word |
| 31 | 2 | C16 | SO70 | R | Source for FB98 Output #70 |
| 32 | 2 | C16 | SO71 | R | Source for FB98 Output #71 |
| 33 | 2 | C16 | SO72 | R | Source for FB98 Output #72 |
| 34 | 2 | C16 | SO73 | R | Source for FB98 Output #73 |
| 35 | 2 | C16 | SO74 | R | Source for FB98 Output #74 |
| 36 | 2 | C16 | SO75 | R | Source for FB98 Output #75 |
| 37 | 2 | C16 | SO76 | R | Source for FB98 Output #76 |
| 38 | 2 | C16 | SO77 | R | Source for FB98 Output #77 |

Interpreting Status words



Attention

Parameter types that are not Status words are described in detail in the *Moore Model 352 SLDC User's Manual*.

| Status Word | Description |
|-------------------------|-------------------------------|
| Status Word 02 | Loop 1 Status |
| Status Word 04 | Station Status |
| Status Word 05 | Function Block Status |
| Status Word 06 | Loop 1 Alarm Status |
| Status Word 07 | Channel A Alarm Status |
| Status Word 08 | Channel A Status |
| Status Word 09 | Channel B Alarm Status |
| Status Word 10 | Channel B Status |
| Status Word 11 | Channel C Alarm Status |
| Status Word 12 | Channel C Status |
| Status Word 13 | Channel D Alarm Status |
| Status Word 14 | Channel D Status |
| Status Word 15 | Loop 2 Status |
| Status Alarm Type Words | for Loop1, Channel A, B, C, D |

Status Word 02 – Loop 1 Status

| Bit | Meaning |
|-----|--------------------------|
| 0 | automatic (1)/manual (0) |

| Bit | Meaning |
|-----|---|
| 1 | local control (1)/non local (0) |
| 2 | standby sync (1)/no standby sync (0) |
| 3 | external (1)/internal (0) |
| 4 | console control (1)/not console (0) |
| 5 | computer control (1)/not computer (0) |
| 6 | ramping set point (1)/no ramping (0) |
| 7 | override (1)/no override (0) |
| 8 | emergency manual (1)/not em manual (0) |
| 9 | configuration hold (1)/not cfg hold (0) |
| 10 | HI SP limit (1)/no limit (0) |
| 11 | LO SP limit (1)/no limit (0) |
| 12 | out of service (1)/normal (0) |
| 13 | not used |
| 14 | not used |
| 15 | not used |

Status Word 04 – Station Status

| Bit | Meaning |
|-----|---|
| 0 | not used |
| 1 | not used |
| 2 | not used |
| 3 | database valid (1)/invalid (0) |
| 4 | not used |
| 5 | not used |
| 6 | configuration hold (1)/not cfg hold (0) |
| 7 | run mode (1)/config hold (0) |
| 8 | not used |
| 9 | not used |
| 10 | not used |
| 11 | config change #1 (1)/reset (0) |
| 12 | config change #2 (1)/reset (0) |
| 13 | config change #3 (1)/reset (0) |
| 14 | error (1)/no error (0) |
| 15 | not used |

Status Word 05 – Function Block Status

| Bit | Meaning |
|-----|---------------------------------------|
| 0 | alarm #1 FB12 (1)/no alarm (0) |
| 1 | alarm #2 FB12 (1)/no alarm (0) |
| 2 | deviation alarm FB12 (1)/no alarm (0) |

| Bit | Meaning |
|-----|---|
| 3 | flashing bargraph (1)/not flashing (0) |
| 4 | lo limit #1 FB09 (1)/no limit (0) |
| 5 | hi limit #1 FB09 (1)/no limit (0) |
| 6 | lo limit #2 FB51 (1)/no limit (0) |
| 7 | hi limit #2 FB51 (1)/no limit (0) |
| 8 | emergency local FB98 (1)/not em loc (0) |
| 9 | non-updating (1)/normal (0) |
| 10 | user status #1 FB15 high (1)/low (0) |
| 11 | user status #2 FB15 high (1)/low (0) |
| 12 | emergency internal FB11 (1)/normal (0) |
| 13 | not used |
| 14 | not used |
| 15 | not used |

Status Word 06 – Loop 1 Alarm Status

| Bit | Meaning |
|-----|---|
| 0 | alarm #1 (1) / no alarm (0) |
| 1 | not acked (1) / acked (0) |
| 2 | alarm #1 enabled (1) / not enabled (0) |
| 3 | alarm #2 (1) / no alarm (0) |
| 4 | not acked (1) / acked (0) |
| 5 | alarm #2 enabled (1) / not enabled (0) |
| 6 | alarm #3 (1) / no alarm (0) |
| 7 | not acked (1) / acked (0) |
| 8 | alarm #3 enabled (1) / not enabled (0) |
| 9 | alarm #4 (1) / no alarm (0) |
| 10 | not acked (1) / acked (0) |
| 11 | alarm #4 enabled (1) / not enabled (0) |
| 12 | link alarms out of service (1) / normal (0) |
| 13 | not used |
| 14 | not used |
| 15 | not used |

Status Word 07 – Channel A Alarm Status

| Bit | Meaning |
|-----|--------------------------------------|
| 0 | alarm #1 (1)/no alarm (0) |
| 1 | not acked (1)/acked (0) |
| 2 | alarm #1 enabled (1)/not enabled (0) |
| 3 | alarm #2 (1)/no alarm (0) |
| 4 | not acked (1)/acked (0) |

| Bit | Meaning |
|-----|---|
| 5 | alarm #2 enabled (1)/not enabled (0) |
| 6 | not used |
| 7 | not used |
| 8 | not used |
| 9 | not used |
| 10 | not used |
| 11 | not used |
| 12 | link alarms out of service (1)/normal (0) |
| 13 | not used |
| 14 | not used |
| 15 | not used |

Status Word 08 – Channel A Status

| Bit | Meaning |
|-----|---|
| 0 | not used |
| 1 | local control (1)/non local (0) |
| 2 | not used |
| 3 | not used |
| 4 | console control (1)/not console (0) |
| 5 | computer control (1)/not computer (0) |
| 6 | not used |
| 7 | not used |
| 8 | not used |
| 9 | not used |
| 10 | not used |
| 11 | not used |
| 12 | link alarms out of service (1)/normal (0) |
| 13 | not used |
| 14 | not used |
| 15 | not used |

Status Word 09 – Channel B Alarm Status

| Bit | Meaning |
|-----|---------------------------------------|
| 0 | not used |
| 1 | local control (1)/non local (0) |
| 2 | not used |
| 3 | not used |
| 4 | console control (1)/not console (0) |
| 5 | computer control (1)/not computer (0) |
| 6 | not used |

| Bit | Meaning |
|-----|---|
| 7 | not used |
| 8 | not used |
| 9 | not used |
| 10 | not used |
| 11 | not used |
| 12 | link alarms out of service (1)/normal (0) |
| 13 | not used |
| 14 | not used |
| 15 | not used |

Status Word 10 – Channel B Status

| Bit | Meaning |
|-----|---|
| 0 | not used |
| 1 | local control (1)/non local (0) |
| 2 | not used |
| 3 | not used |
| 4 | console control (1)/not console (0) |
| 5 | computer control (1)/not computer (0) |
| 6 | not used |
| 7 | not used |
| 8 | not used |
| 9 | not used |
| 10 | not used |
| 11 | not used |
| 12 | link alarms out of service (1)/normal (0) |
| 13 | not used |
| 14 | not used |
| 15 | not used |

Status Word 11 – Channel C Alarm Status

| Bit | Meaning |
|-----|--------------------------------------|
| 0 | alarm #1 (1)/no alarm (0) |
| 1 | not acked (1)/acked (0) |
| 2 | alarm #1 enabled (1)/not enabled (0) |
| 3 | alarm #2 (1)/no alarm (0) |
| 4 | not acked (1)/acked (0) |
| 5 | alarm #2 enabled (1)/not enabled (0) |
| 6 | not used |
| 7 | not used |
| 8 | not used |

| Bit | Meaning |
|-----|---|
| 9 | not used |
| 10 | not used |
| 11 | not used |
| 12 | link alarms out of service (1)/normal (0) |
| 13 | not used |
| 14 | not used |
| 15 | not used |

Status Word 12 – Channel C Status

| Bit | Meaning |
|-----|---|
| 0 | not used |
| 1 | local control (1)/non local (0) |
| 2 | not used |
| 3 | not used |
| 4 | console control (1)/not console (0) |
| 5 | computer control (1)/not computer (0) |
| 6 | not used |
| 7 | not used |
| 8 | not used |
| 9 | not used |
| 10 | not used |
| 11 | not used |
| 12 | link alarms out of service (1)/normal (0) |
| 13 | not used |
| 14 | not used |
| 15 | not used |

Status Word 13 – Channel D Alarm Status

| Bit | Meaning |
|-----|--------------------------------------|
| 0 | alarm #1 (1)/no alarm (0) |
| 1 | not acked (1)/acked (0) |
| 2 | alarm #1 enabled (1)/not enabled (0) |
| 3 | alarm #2 (1)/no alarm (0) |
| 4 | not acked (1)/acked (0) |
| 5 | alarm #2 enabled (1)/not enabled (0) |
| 6 | not used |
| 7 | not used |
| 8 | not used |
| 9 | not used |
| 10 | not used |

| Bit | Meaning |
|-----|---|
| 11 | not used |
| 12 | link alarms out of service (1)/normal (0) |
| 13 | not used |
| 14 | not used |
| 15 | not used |

Status Word 14 – Channel D Status

| Bit | Meaning |
|-----|---|
| 0 | not used |
| 1 | local control (1)/non local (0) |
| 2 | not used |
| 3 | not used |
| 4 | console control (1)/not console (0) |
| 5 | computer control (1)/not computer (0) |
| 6 | not used |
| 7 | not used |
| 8 | not used |
| 9 | not used |
| 10 | not used |
| 11 | not used |
| 12 | link alarms out of service (1)/normal (0) |
| 13 | not used |
| 14 | not used |
| 15 | not used |

Status Word 15 – Loop 2 Status

| Bit | Meaning |
|-----|--|
| 0 | auto set to 'I' |
| 1 | local control (1)/non local (0) |
| 2 | standby sync set to '0' |
| 3 | external/internal set to '0' |
| 4 | console control (1)/not console (0) |
| 5 | computer control (1)/not computer (0) |
| 6 | ramping set point (1)/not ramping (0) |
| 7 | override set to '0' |
| 8 | emergency manual set to '0' |
| 9 | configuration hold (1)/not config hold (0) |
| 10 | HI SP limit (1)/no limit (0) |
| 11 | LO SP limit (1)/no limit (0) |
| 12 | out of service (1)/normal (0) |

| Bit | Meaning |
|-----|----------|
| 13 | not used |
| 14 | not used |
| 15 | not used |

Status Alarm Type Words – for Loop1, Channel A, B, C, D

| Bit | Meaning |
|-----|--------------------------------|
| 0 | Alarm Type |
| 1 | |
| 2 | |
| 3 | Alarm Deadband |
| 4 | |
| 5 | Delay Time IN |
| 6 | |
| 7 | |
| 8 | Delay Time OUT |
| 9 | |
| 10 | |
| 11 | Ringback/Ringback not required |
| 12 | not used |
| 13 | not used |
| 14 | not used |
| 15 | not used |

where Alarm Type is enumerated as:

| Value | Meaning |
|-------|--------------------------|
| 0 | no alarm action required |
| 1 | HIGH alarm |
| 2 | LOW alarm |
| 3 | HIGH DEVIATION alarm |
| 4 | LOW DEVIATION alarm |
| 5 | ABSOLUTE DEVIATION alarm |
| 6 | OUT OF RANGE alarm |
| 7 | no alarm action required |

where Alarm Deadband is enumerated as:

| Value | Meaning |
|-------|---------------------|
| 0 | 0.1% alarm deadband |
| 1 | 0.5% alarm deadband |
| 2 | 1.0% alarm deadband |
| 3 | 5.0% alarm deadband |

where Delay Time IN and Delay Time OUT is enumerated as:

| Value | Meaning |
|-------|--------------|
| 0 | 0.0 seconds |
| 1 | 0.4 seconds |
| 2 | 1.0 seconds |
| 3 | 2.0 seconds |
| 4 | 5.0 seconds |
| 5 | 15.0 seconds |
| 6 | 30.0 seconds |
| 7 | 60.0 seconds |

Mapping between the server and the Moore 352 for bit 0 of the Loop 1 Status (L1ST) address

For ease of control and observation of the Loop 1 Status on the Moore Mycro 352 controller, some values on the server are mapped to different values on the Moore 352 controller. If either a status point or the MD parameter of a point is built with the address L1ST Bit 0 address (channel 9 parameter 1) on a Moore 352 controller, the following mapping is done:

Table 2: Mapping performed between the server and Moore 352

| Server Mode | Server Value | Moore 352 Value |
|-------------|--------------|-----------------|
| MAN-LSP | 0 | MANUAL/INTERNAL |
| AUTO-LSP | 1 | AUTO/INTERNAL |
| AUTO-RSP | 2 | AUTO/EXTERNAL |
| MAN-RSP | 6 | MANUAL/EXTERNAL |

For example, if the MD on a point is set to MAN-RSP, the status of the Loop 1 mode changes to MANUAL and EXTERNAL. The reverse mapping also applies.



Attention

- Mapping is not performed for Loop2. Mapping is only performed for the Moore Mycro 352 controller type. Other bits of the Status L1ST address and all other addresses on the device are read from and written to without any value mapping.

Related topics

“Configuring the Moore Mycro controller” on page 9

“Troubleshooting Moore Mycro issues” on page 33

Troubleshooting Moore Mycro issues

This section describes troubleshooting tasks for Moore Mycro that you can perform either on the server or from any Station.

Related topics

“Testing Moore Mycro communications with the server” on page 34

“Addresses supported by the Moore Mycro interface” on page 20

Testing Moore Mycro communications with the server

You use the Moore Mycro test utility, **mmutst**, to test communications between the server and the Moore Mycro controller after you have downloaded channel and controller definitions to the server database.

You can also use **mmutst** to change the values of registers that in turn set configuration items on the Moore Mycro controller.

Prerequisites

- Set up the controller.
- Connect all cables.
- Define the controller and channel in Quick Builder.
- Download the Quick Builder definitions to the server, without errors.
- Ensure the channel is out of service.

To run the mmutst utility

- 1 Open a Command Prompt window.
- 2 Type **mmutst** and then press Enter.
- 3 Follow the directions as prompted.

You can read and write data to all registers that can be addressed by the server.

Related topics

“Planning considerations for installing and configuring Moore Mycro controllers” on page 5

“Configuring the Moore Mycro controller” on page 9

Troubleshooting Moore Mycro point configuration errors

Errors while downloading to host

If points are configured with illegal configuration details, this might cause problems when they are downloaded to the server. If this occurs, read the output file created by Quick Builder and correct the errors.

Note that certain combinations of server point types and Moore Mycro 352 addresses are illegal. All Status Words on the device (addresses looking at certain bits) must be defined using the STA tag type or referenced from the MD parameter of a point. See the topic titled "Addresses supported by the Moore Mycro interface" for those addresses that are Status Words. Also, analog points and accumulator points cannot specify a bit field.

Unexpected point values

If a point does not have the expected value, the point might be configured incorrectly. Ensure that the point source address has the correct data type. If not, either check the point source address in the Quick Builder line or the device address definition file *mmu_352_def*.

If the point is a STAND format, check the RANGE specified. If the value conflicts with a value for a loop value on the faceplate of the Moore, check that the RANGE matches the Process Lo, Hi, and Decimal Point, which is configured in FB15.

For some values, the point value reported by server will be slightly different from the value shown on the faceplate of the Moore Mycro due to rounding errors on the device.

Notices

Trademarks

Experion®, PlantScape®, SafeBrowse®, TotalPlant®, and TDC 3000® are registered trademarks of Honeywell International, Inc.

OneWireless™ is a trademark of Honeywell International, Inc.

Other trademarks

Microsoft and SQL Server are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Trademarks that appear in this document are used only to the benefit of the trademark owner, with no intention of trademark infringement.

Third-party licenses

This product may contain or be derived from materials, including software, of third parties. The third party materials may be subject to licenses, notices, restrictions and obligations imposed by the licensor. The licenses, notices, restrictions and obligations, if any, may be found in the materials accompanying the product, in the documents or files accompanying such third party materials, in a file named third_party_licenses on the media containing the product, or at <http://www.honeywell.com/ps/thirdpartylicenses>.

Documentation feedback

You can find the most up-to-date documents on the Honeywell Process Solutions support website at:

<http://www.honeywellprocess.com/support>

If you have comments about Honeywell Process Solutions documentation, send your feedback to:

hpsdocs@honeywell.com

Use this email address to provide feedback, or to report errors and omissions in the documentation. For immediate help with a technical problem, contact your local Honeywell Process Solutions Customer Contact Center (CCC) or Honeywell Technical Assistance Center (TAC) listed in the “Support and other contacts” section of this document.

How to report a security vulnerability

For the purpose of submission, a security vulnerability is defined as a software defect or weakness that can be exploited to reduce the operational or security capabilities of the software.

Honeywell investigates all reports of security vulnerabilities affecting Honeywell products and services.

To report a potential security vulnerability against any Honeywell product, please follow the instructions at:

<https://honeywell.com/pages/vulnerabilityreporting.aspx>

Submit the requested information to Honeywell using one of the following methods:

- Send an email to security@honeywell.com.
- or
- Contact your local Honeywell Process Solutions Customer Contact Center (CCC) or Honeywell Technical Assistance Center (TAC) listed in the “Support and other contacts” section of this document.

Support

For support, contact your local Honeywell Process Solutions Customer Contact Center (CCC). To find your local CCC visit the website, <https://www.honeywellprocess.com/en-US/contact-us/customer-support-contacts/Pages/default.aspx>.

Training classes

Honeywell holds technical training classes on Experion PKS. These classes are taught by experts in the field of process control systems. For more information about these classes, contact your Honeywell representative, or see <http://www.automationcollege.com>.

Index

A

- address syntax 18
- addressing
 - Moore Mycro controllers 18, 20
- architectures
 - Moore Mycro 8

B

- baud 14

C

- channels
 - Moore Mycro channel 12
 - Moore Mycro controllers 11
 - reference 11
- checksum 14
- commands and utilities
 - lisscn 16
 - mmutst 9, 34
- communications
 - testing
 - Moore Mycro controllers 34
- configuring
 - Moore Mycro controllers 5
- connect timeout 12
- controllers
 - configuring
 - Moore Mycro controllers 5
 - controller type 15
 - Moore Mycro controllers 5–7, 9–12, 15–18, 33, 34
 - reference 11
 - type 15

D

- devices supported 6
- diagnostics
 - Moore Mycro controllers 34
- documentation
 - Moore Mycro 7

E

- error messages
 - point configuration 34

F

- fail alarm limit 12, 15

H

- handshaking options 14

L

- lisscn utility 16

M

- Main tab
 - Moore Mycro channel 12
 - Moore Mycro controller 15
- marginal alarm limit 12, 15
- mmutst utility 9, 34
- Moore Mycro controllers
 - addresses supported 20
 - addressing 18
 - architectures 8
 - baud 14
 - channels 11, 12
 - checksum 14
 - communication settings 10
 - configuring 5, 9
 - connect timeout 12
 - connecting to the server 9
 - controller type 15
 - controllers 11
 - devices supported 6
 - documentation 7
 - fail alarm limit 12, 15
 - handshaking options 14
 - lisscn utility 16
 - marginal alarm limit 12, 15
 - mmutst utility 9, 34
 - number of data bits 14
 - parameter data types 18
 - parity 14
 - planning considerations 5
 - points 17
 - read timeout 12
 - RS-232 14
 - RS-422 14
 - RS-485 14
 - scan packets 16
 - scanning performance 16
 - serial port properties 14
 - Station address 15
 - stop bits 14
 - supported addresses 20

- supported architectures 8
- supported devices 6
- testing communications 34
- troubleshooting 33, 34
- XON/XOFF 14

N

- number of data bits 14

P

- parameter data types 18
- parity 14
- points
 - errors 34
 - Moore Mycro controllers 17, 34
 - reference 17
 - troubleshooting 34
- port properties
 - ASEA channel 14
 - configuring 14

R

- read timeout 12
- RS-232
 - connections 8, 14
- RS-422
 - connections 8

- RS-485
 - connections 14
- RS-422
 - connections 14

S

- scanning
 - optimizing performance 16
- serial port properties 14
- stop bits 14
- supported devices 6

T

- testing communications
 - Moore Mycro controllers 34
- troubleshooting
 - Moore Mycro controllers 33, 34

U

- utilities
 - lisscn 16
 - mmutst 9, 34

X

- XON/XOFF 14