

NET3720 - Fall 2021 – Jenkins

Lab 2 - WPA2-PSK Security

Erika Hernandez

Lab Objectives:

- Configure AP
- Create SSID for AP

Hardware needed:

- Cisco Aironet 3700 AP
- ZYCEL PoE Switch
- USB to RS232 cable
- Computer

Software:

- Console application
 - PuTTY <http://the.earth.li/~sgtatham/putty/latest/x86/putty.exe>
 - Instructions on how to download PuTTY
 - <https://www.weber.edu/CS/remote-access.html>

Instructions:

In this lab you will learn how to configure a Cisco AP unit using the CLI. You will also learn how to create an SSID so people can

Method:

Internet is connected to the ZYXEL switch with Cat.6 cables. The switch is then connected to the Cisco AP unit with Cat.6 cables. In order to configure the AP it needs to be controlled by a computer. You are able to do this with USB to RS232 + VGA to RJ-45. Green light on the AP unit means its on, when you are connected to the AP successfully it will turn blue.

Connections:

Get Cat.6 cable connect one end to modem and other to ZYXEL switch **port 5**. connect the power to the switch. Get Cat.6 cable and connect one end to **port 1** on switch and the other end to **Ethernet** port on the Cisco switch. The RJ-45 end connect to **Console** connect the VGA to RS232, then the USB to a USB port on the computer. See Figure 1 for layout of how things are connected.




Figure 1

Turn on the **ZYXEL switch** on, and make sure the USB is plug and play and picks up on the computer.
 Go to the **Start** menu on your windows computer
 click on the **Device Manager**
 Go down on ports for my device it is on (**COM4**)



Figure 2

Open PuTTY Configuration




Figure 3

Access Cisco AP
Click on **Serial**
on Serial line you put **COM4** (or whatever yours says)
Speed **9600**
Then click on **Open**

This is what will show up press **Enter**



Figure 4

This is what will show up when you Press **Enter**




Figure 5

Type in password: class

then type enable

net-3720-ap4634> enable

password: class

net-3720-ap4634# sh ip interface brief

```
net-3720-ap4634#sh ip interface brief
Interface                IP-Address      OK? Method Status      Prot
ocol
BVI1                     192.168.0.43   YES DHCP    up          up
Dot11Radio0              unassigned      YES NVRAM    administratively down down
Dot11Radio1              unassigned      YES NVRAM    administratively down down
GigabitEthernet0         unassigned      YES NVRAM    up          up
net-3720-ap4634#
```

Figure 6

net-3720-ap4634#sh running-config

Output:

Building configuration...

Current configuration : 1646 bytes

!

version 15.3

no service pad

service timestamps debug datetime msec

service timestamps log datetime msec

service password-encryption

!

hostname net-3720-ap4634

!

!

logging rate-limit console 9

enable secret 5 \$1\$711L\$bTev5wtQCeNqXp.lrmdRo0

enable password 7 10400C0D5640405B412C2F392A293D312709

!

```
no aaa new-model
no ip source-route
no ip cef
!
!
!
!
dot11 pause-time 100
dot11 syslog
!
!
no ipv6 cef
!
!
username Cisco password 7 032752180500
!
!
bridge irb
!
!
!
interface Dot11Radio0
  no ip address
  shutdown
  antenna gain 0
  station-role root
  bridge-group 1
  bridge-group 1 subscriber-loop-control
  bridge-group 1 spanning-disabled
  bridge-group 1 block-unknown-source
  no bridge-group 1 source-learning
  no bridge-group 1 unicast-flooding
!
interface Dot11Radio1
  no ip address
  shutdown
  antenna gain 0
  peakdetect
  no dfs band block
  channel dfs
```

```

station-role root
bridge-group 1
bridge-group 1 subscriber-loop-control
bridge-group 1 spanning-disabled
bridge-group 1 block-unknown-source
no bridge-group 1 source-learning
no bridge-group 1 unicast-flooding
!
interface GigabitEthernet0
  no ip address
  duplex auto
  speed auto
  bridge-group 1
  bridge-group 1 spanning-disabled
  no bridge-group 1 source-learning
!
interface BVI1
  mac-address 5c83.8f44.4634
  ip address dhcp client-id GigabitEthernet0
  ipv6 address dhcp
  ipv6 address autoconfig
  ipv6 enable
!
ip forward-protocol nd
no ip http server
no ip http secure-server
ip http help-path
http://www.cisco.com/warp/public/779/smbiz/prodconfig/help/eag
!
!
bridge 1 route ip
!
!
!
line con 0
  password 7 045807071C32
  login
line vty 0 4
  login local
  transport input all

```

```
!  
end
```

```
net-3720-ap4634#configure terminal  
net-3720-ap4634(config)#interface bvi 1  
net-3720-ap4634(config-if)#ip address 192.168.0.43 255.255.255.0  
net-3720-ap4634(config-if)#exit  
net-3720-ap4634(config)#
```

Creating the SSID

```
net-3720-ap4634(config)#ip default-gateway 192.168.0.1  
  
net-3720-ap4634(config)#exit  
net-3720-ap4634#sh ip interface brief
```

```
net-3720-ap4634#sh ip interface brief  
Interface                IP-Address      OK? Method Status      Protocol  
BVI1                     192.168.0.43    YES manual up          up  
Dot11Radio0              unassigned      YES NVRAM   administratively down down  
Dot11Radio1              unassigned      YES NVRAM   administratively down down  
GigabitEthernet0         unassigned      YES NVRAM   up          up  
net-3720-ap4634#
```

Figure 7

Note: BVI1 is now saying Manual Up instead of DHCP

```
net-3720-ap4634#config terminal  
  
net-3720-ap4634(config)#dot11 ssid net3720-Hernandez  
  
net-3720-ap4634(config-ssid)#guest-mode  
  
net-3720-ap4634(config-ssid)#authentication open  
  
net-3720-ap4634(config-ssid)#authentication key-management wpa version  
2
```

```
net-3720-ap4634(config-ssid)#wpa-psk ascii Cisco2021
net-3720-ap4634(config-ssid)#exit
```

Enable Encryption to 4.2GHz Radio Interface

```
net-3720-ap4634(config)#interface dot11Radio 0
net-3720-ap4634(config-if)#encryption mode ciphers aes-ccm
net-3720-ap4634(config-if)#ssid net3720-Hernandez
net-3720-ap4634(config-if)#channelleast-congestied
net-3720-ap4634(config-if)#no shutdown
net-3720-ap4634(config-if)#exit
net-3720-ap4634(config)#exit
```

Now you are ready to connect to the WiFi--
Password: Cisco2021

🏠 net3720-Hernandez

Edit

Properties

SSID:	net3720-Hernandez
Protocol:	Wi-Fi 4 (802.11n)
Security type:	WPA2-Personal
Network band:	2.4 GHz
Network channel:	8
Link-local IPv6 address:	fe80::f098:41e:cc4:c803%26
IPv4 address:	192.168.0.33
IPv4 DNS servers:	192.168.0.1 205.171.3.25
Manufacturer:	Intel Corporation
Description:	Intel(R) Wi-Fi 6 AX200 160MHz
Driver version:	22.20.0.6
Physical address (MAC):	94-E6-F7-E2-96-0E

Copy

Figure 8

```
net-3720-ap4634#show tech-support
```



```
COM4 - PuTTY

----- show dot11 associations all-client -----

Address       : 94e6.f7e2.960e      Name       : net-3720-ap4634
IP Address    : 192.168.0.33        IPv6 Address : FE80::F098:41E:CC4:C803

Gateway Address : 0.0.0.0
Netmask Address : 0.0.0.0          Interface   : Dot11Radio 0
Bridge-group    : 1
reap_flags_1    : 0x0      ip_learn_type : 0x0      transient_static_ip : 0x0
Device         : ccx-client      Software Version : NONE
CCX Version     : 4              Client MFP      : Off

State          : Assoc           Parent         : self
SSID           : net3720-Hernandez
VLAN           : 0
Hops to Infra  : 1              Association Id  : 1
Clients Associated: 0           Repeaters associated: 0
Tunnel Address : 0.0.0.0
Key Mgmt type   : WPAv2 PSK      Encryption     : AES-CCMP
Current Rate    : m15-2          Capability      : WMM ShortHdr ShortSlot 11h
Supported Rates : 1.0 2.0 5.5 11.0 6.0 9.0 12.0 18.0 24.0 36.0 48.0 54.0 m0-2 m1-2 m2-2 m3-2
m4-2 m5-2 m6-2 m7-2 m8-2 m9-2 m10-2 m11-2 m12-2 m13-2 m14-2 m15-2
Voice Rates     : disabled       Bandwidth       : 20 MHz
Signal Strength : -24 dBm        Connected for   : 294 seconds
Signal to Noise : 60 dB         Activity Timeout : 29 seconds
Power-save      : Off           Last Activity    : 21 seconds ago
Apsd DE AC(s)  : NONE

Packets Input   : 1419           Packets Output  : 213
Bytes Input     : 329313         Bytes Output    : 55013
Duplicates Rcvd : 2             Data Retries    : 1
Decrypt Failed  : 0             RTS Retries     : 0
MIC Failed      : 0             MIC Missing     : 0
Packets Redirected: 0          Redirect Filtered: 0
IP source guard failed : 0      PPPoE passthrough failed : 0
DAI failed : IP mismatch : 0    src MAC mismatch : 0      target MAC mismatch
: 0
Existing IP failed : 0          New IP failed : 0
Client Vlan      : 0
llw Status       : Off
Client SGT       : 0
Session timeout  : 0 seconds
Reauthenticate in : never
```

Figure 9

When you are connected the Cisco AP will go from Green to Blue.

References

IT Support People. (2020, December 29). Configure Cisco Access Point using CLI with WPAv2 Authentication [Video]. Retrieved from <https://www.youtube.com/watch?v=JkUfTXuwj2U>