

Hamptons

THE HOME EXPERTS

D&S Appliances Ltd
136-137 High Street
Ilfracombe
EX34 9EZ

Tel: 0203 488 0344

2nd Floor
Standon House
21 Mansell Street
London
E1 8AA

Direct Line: 020 7265 6602

Direct Fax:

Email: HurbasS@hamptons.co.uk

Home: www.hamptons.co.uk

WORKS ORDER

Client: Sheung Yuen Lee & Chi Hin Sue Ann Law
Client No: C349567
Property: 141 Cambridge Avenue, London, NW6 5AA

Instructed By: Selen Hurbas
Date: 20/10/2023
Works ref: W518280
Purchase order: 1589830
Supplier a/c no: C512358

Instruction: Dishwasher stops working in the final stages of its program as it attempts to drain water. The water supply button keeps flashing as the dishwasher keeps trying to empty water that is no longer inside it. We looked online and we have reasons to believe there is a problem water being stuck in flood mode, as we first encountered this issue a few weeks ago and leaving it by (for the water to evaporate) worked, however now water is probably stuck again. Tipping the dishwasher to ensure the water leaves the system could solve the problem, however, we do not have access behind the dishwasher.[Appliance type: Dishwasher] [Appliance make: Bosch] [Appliance model: 9000868599] [Number of floors: 1] Note: The tenant would like to be present when the work is carried out.

Access:

Tenant / Occupant: Matthew James Thomas & Conor James Crook

Contact details: Mobile: 07503 162668, 07503176454

Phone:

Email: matthew.thomas2408@gmail.com, conorjc7@googlemail.com

IT IS IMPORTANT THAT YOU DO NOT CARRY OUT FURTHER WORKS THAN INSTRUCTED ABOVE WITHOUT THE FULL AUTHORISATION OF THE INSTRUCTOR NAMED ABOVE OR OTHER AUTHORISED STAFF WITHIN THIS OFFICE.

Please Charge To: Sheung Yuen Lee & Chi Hin Sue Ann Law

c/o Hamptons International. pminvoices@hamptons-int.com

All invoices should be presented in .pdf format and include the purchase order number to the above email address for prompt payment