

**QUALITY SYSTEM****PROCEDURE**

Process : Maintenance Manual Mandal Fairlead Shackles	Reg. Nr. : 002-18	Date : 02.10.2018
		Page : 1 of 1
	Revision : 0	Sign : RF

**Mandal Fairlead Shackle 90M-120M****1. Material**

SS 2387

Stainless steel

Rust stains may occur on surface on cast material,  
but will not affect strength of the product.

**2. Application**

The components are approved for use as mooring link between wire rope and fibre forerunner, and between fibre rope and fibre forerunner.

**3. Storing**

The Mandal Fairlead Shackles must be stored in a way that keeps them from exposure of any external influences, like chemical materials.

**4. Maintenance**

In normal use, it is not necessary to maintain them in any way, but for elements under long time storing, we can recommend:

- Fresh water flush for removing salt
- Dry the links properly
- A treatment with Dinitrol 4010, or similar, is recommended.  
This is a transparent rust protection treatment, on spray can.
- Storing in dry environment

**5. Installation****6. Inspection / discard**

Shackle to be checked for cracks or deformation. If no visible damage, it can be used.  
Operator/user is responsible for the evaluation.

**EUROPE MARINE AS**

Stensarmen 9, 3112 Tønsberg, Norway

Tel: +47 46886830    www.euroropemarine.no    Email: mailbox@euroropemarine.no