

OPERATING INSTRUCTIONS

Digilock KP and WP

To Unlock

Press the "C" key



Enter your four digit code

Press the "key symbol"



Pull the door open while the green LED is lit



Closing the door will automatically relock



To Unlock Using the Manager Code

Press the "C" key



Enter the five digit manager code

Press the "key symbol"



Pull the door open while the green LED is lit



Closing the door will automatically relock



PROGRAMMING INSTRUCTIONS

Digilock KP and WP

To Program a New User Code Using the Existing User Code

Press the "C" key



Press the "key symbol" to begin the programming mode



Enter the existing 4 digit User Code

Press the "key symbol"



The LED will emit a solid green light



While the green light is on, enter the new 4 digit User Code

Press the "key symbol" to end the programming mode



A double beep signifies successful programming



To Program a New User Code Using the Manager Code

Press the "C" key



Press the "key symbol" to begin the programming mode



Enter the 5 digit Manager Code

Press the "key symbol"



The LED will emit a solid green light



While the green light is on, enter the new 4 digit User Code

Press the "key symbol" to end the programming mode



A double beep signifies successful programming



PROGRAMMING INSTRUCTIONS

Digilock KP and WP

To Program a New Manager Code Using Existing Manager Code

Press the "C" key



Press the "key symbol" to begin the programming mode



Enter the existing 5 digit Manager Code

Press the "key symbol"



The LED will emit a solid green light



While the green light is on, enter the new 5 digit Manager Code

Press the "key symbol" to end the programming mode



A double beep signifies successful programming



To Program a New Manager Code Using the Owner Code

Press the "C" key



Press the "key symbol" to begin the programming mode



Enter the 6 digit Owner Code

Press the "key symbol"



The LED will emit a solid green light



While the green light is on, enter the new 5 digit Manager Code

Press the "key symbol" to end the programming mode



A double beep signifies successful programming

