

# MC2600 WEB Introduction

Ver:2.0

**MEGMEET**  
*everywhere*

# WEB Connect-1

Step1

- Set IP address



Step2

- Set WEB

Step3


- Connect Monitor and PC
- Log in WEB

# WEB Connect-2







# WEB Connect-3




- If the monitor IP address is 192.168.70.2, the computer IP address should set to 192.168.70.X, where X represents any number from 3 to 254;  
Note: The monitoring module and the computer must be in the same ip address segment, but should set different ip address.
- the subnet mask, default gateway settings are as left picture;

# WEB Connect-4



# WEB Connect-5



# WEB Connect-6



User name: admin

Password: 654321

# Main interface introduction

DC Voltage: 23.9V	Load Curr: 0A	Batt Curr: 1.2A	Battery Mode: Float	Alarm State: Major
System Information				
Software Version: 9.02150401		Hardware Version: 25.5		User Config Version: 1.03
System Information Settings				
Site Name:		Date and Time: 2018-1-1 00:07		Windows Time
<input type="text"/>	<input type="button" value="Set"/>	Year: <input type="text"/> Mon: <input type="text"/> Day: <input type="text"/> Hour: <input type="text"/> Min: <input type="text"/> Sec: <input type="text"/>	<input type="button" value="Set"/>	
Change The Operator Password		Change The Administrator Password		
<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>	
System Rectifier Type: 21000W		System Solar Type: 12000W		
<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>	
System Power Mode: Only Mains		System Restart:		
<input type="text" value="Only Mains"/>	<input type="button" value="Set"/>	<input type="button" value="Set"/>		<input type="button" value="Set"/>
Clear Alarm Log				
<input type="text" value="Clear Alarm Record"/>	<input type="button" value="Set"/>	Restore to Default:		<input type="button" value="Set"/>

Major Parameters

Parameter Menu

Main menu



# Major Parameters

DC Voltage: 23.9V	Load Curr: 0A	Batt Curr: 1.2A	Battery Mode: Float	Alarm State: Major
-------------------	---------------	-----------------	---------------------	--------------------

Display bus bar DC voltage

Display total load current

Display real-time battery current. The current is positive when the battery is charging, and negative when the battery is discharging.

Charge state: Float——float charge, Boost——boost charge

Display the alarm status of the system:

- If the system has a serious alarm, which is displayed as red 'Major'
- If the system has a normal alarm, which is displayed as orange 'Minor'
- If the system has no alarm, which is displayed as yellow 'Normal'

If need to know the specific alarm information of the system, check the Active Alarm menu under the Alarm menu



# Main menu

This page is a navigation page for important parameters. Through this page, can select the display, view, and settings of various parameters of the system.

- Input
- Diesel
- DC
- Modules
- Battery
  - Charge
  - LVD
  - Test
  - Temperature
  - BMS/BCM
- ECO
- Communication
- Alarm
  - Active Alarm
  - History Alarm
  - History Data Log
  - Battery Log
  - Alarm Config
- System
- Up/Download



# Input menu-1

AC Input Information			
AC-L1 Volt: ---V	AC-L2 Volt: ---V	AC-L3 Volt: ---V	AC Frequency: ---Hz
AC Input Settings			
AC Over Volt: 280V	AC Under Volt: 180V	Phase Loss Volt: 80V	AC Input Type: PH-3
<input type="text"/>	<input type="text"/>	<input type="text"/>	PH-1 <input type="button" value="Set"/>
<input type="button" value="Set"/>	<input type="button" value="Set"/>	<input type="button" value="Set"/>	<input type="button" value="Set"/>
PV Input Information			
PV Input Voltage: ---V			
PV Input Settings			
Solar Input Over Vol: 440V	Solar Input Under Vol: 110V		
<input type="text"/>	<input type="text"/>		
<input type="button" value="Set"/>	<input type="button" value="Set"/>		

MPPT input overvoltage and undervoltage setting

AC input over-voltage alarm threshold setting and system single-phase and three-phase input selection

Show AC input phase voltage



# DG menu-1

## Diesel Capacity Information

Diesel Capacity: ---- L

Diesel Voltage: ---- V

## Diesel Capacity Settings

Level Total Num Setting: 0

Diesel Capacity Level: Zero

Diesel Voltage Setting: 0 V

Diesel Capacity Setting: 0 L

Set

Set

Set

Set

Diesel Full Capacity: 100 L

Reset Diesel Capacity Settings:

Diesel Capacity High: 90 %

Diesel Capacity Low: 10 %

Set

Reset

Set

Set

Zero Position: 0V-0L

Full Position: 5V-100L

Lev1: --V- --L

Lev2: --V- --L

Lev3: --V- --L

Lev4: --V- --L

Lev5: --V- --L

Lev6: --V- --L

Lev7: --V- --L

Lev8: --V- --L

Lev9: --V- --L

Lev10: --V- --L

Lev11: --V- --L

Lev12: --V- --L

Lev13: --V- --L

Lev14: --V- --L

Lev15: --V- --L

Lev16: --V- --L

Lev17: --V- --L

Lev18: --V- --L

For oil tanks with irregular shapes, the voltage sampling value of the oil level sensor and the oil volume cannot be proportional to the full range. Through this area, the fuel tank capacity and the sampling voltage of the liquid level sensor can be set in sections. Up to 18 segments can be set

Display current fuel volume and oil sensor voltage.





# DG menu-2

## Diesel Capacity Information

Diesel Capacity: ---- L

Diesel Voltage: ---- V

## Diesel Capacity Settings

Level Total Num Setting: 0

Diesel Capacity Level: Zero

Diesel Voltage Setting: 0 V

Diesel Capacity Setting: 0 L

Set

Set

Set

Set

Diesel Full Capacity: 100 L

Reset Diesel Capacity Settings:

Diesel Capacity High: 90 %

Diesel Capacity Low: 10 %

Set

Reset

Set

Set

Zero Position: 0V-0L

Full Position: 5V-100L

Lev1: --V- --L

Lev2: --V- --L

Lev3: --V- --L

Lev4: --V- --L

Lev5: --V- --L

Lev6: --V- --L

Lev7: --V- --L

Lev8: --V- --L

Lev9: --V- --L

Lev10: --V- --L

Lev11: --V- --L

Lev12: --V- --L

Lev13: --V- --L

Lev14: --V- --L

Lev15: --V- --L

Lev16: --V- --L

Lev17: --V- --L

Lev18: --V- --L

Fuel tank fuel level high and low alarm threshold settings

To set maximum fuel quantity

Reset DG capacity settings



# DG menu-3

## Diesel Capacity Information

Diesel Capacity: ---- L

Diesel Voltage: ---- V


## Diesel Capacity Settings

Level Total Num Setting: 0	Diesel Capacity Level: Zero	Diesel Voltage Setting: 0 V	Diesel Capacity Setting: 0 L
<input type="text"/>	<input type="text" value="Zero"/>	<input type="text"/>	<input type="text"/>
<input type="button" value="Set"/>	<input type="button" value="Set"/>	<input type="button" value="Set"/>	<input type="button" value="Set"/>
Diesel Full Capacity: 100 L	Reset Diesel Capacity Settings:	Diesel Capacity High: 90 %	Diesel Capacity Low: 10 %
<input type="text"/>	<input type="button" value="Reset"/>	<input type="text"/>	<input type="text"/>
<input type="button" value="Set"/>		<input type="button" value="Set"/>	<input type="button" value="Set"/>
Zero Position: 0V-0L	Full Position: 5V-100L	Lev1: --V- --L	Lev2: --V- --L
Lev3: --V- --L	Lev4: --V- --L	Lev5: --V- --L	Lev6: --V- --L
Lev7: --V- --L	Lev8: --V- --L	Lev9: --V- --L	Lev10: --V- --L
Lev11: --V- --L	Lev12: --V- --L	Lev13: --V- --L	Lev14: --V- --L
Lev15: --V- --L	Lev16: --V- --L	Lev17: --V- --L	Lev18: --V- --L

Display the corresponding relationship between the voltage of each segment of the oil level sensor and the oil level of the fuel tank



# DG menu-4




For a fuel tank with a regular structure, if the fuel volume has a linear relationship with the fuel level detector voltage, as shown on the left, the settings are as follows:

- **Level Total Num setting:** 0
- **Diesel Capacity Level:** Zero
- **Diesel Voltage Setting:** Zero
- **Diesel Capacity Setting:** Zero



# DG menu-5



For an irregularly shaped fuel tank, the fuel volume of the fuel tank and the voltage of the fuel level detector are not linearly related, as shown on the left, the settings are as follows:

- **Level Total Num setting:** 1
- **Diesel Capacity Level:** Zero
- **Diesel Voltage Setting:** Zero
- **Diesel Capacity Setting:** Zero
  
- **Diesel Capacity Level:** Level 1
- **Diesel Voltage Setting:**  $\pi(R1^2 \cdot h1) / \text{Diesel Full Capacity} \cdot 5$
- **Diesel Capacity Setting:**  $\pi R1^2 \cdot h1$





# DG menu-6

## Diesel Generator Information

DG1 Run Status: **Stopped**

DG2 Run Status: **Stopped**

Display the operating status of the DG. The operating status of the DG is transmitted to the monitoring through the DI port of the monitoring module from DI/DO interface on subrack



# DG menu-7

## Diesel Generator Settings

DG1 Status: None		DG1 Start/Stop: None		DG2 Status: None		DG2 Start/Stop: None	
None	Set	None	Set	None	Set	None	Set
Voltage Controlled DG Start: Enable		Start DG On: 47.5V		Current Controlled DG Stop: Enable		Stop DG On: 10A	
Enable	Set		Set	Enable	Set		Set

DG1 operating status feedback port setting

Low busbar voltage start DG enable setting

Busbar voltage start DG threshold setting

Setting of DO port for start-stop signal of DG1

DG2 operating status feedback port setting

Current stop DG enable setting

Setting of DO port for start-stop signal of DG2

Current stop DG operating threshold setting



# DG menu-8

Capacity Controlled DG Start: Disable	Start DG On: 50%	Stop DG On: 95%	Daily DG Start: Disable
Enable <input type="button" value="Set"/>	<input type="text"/> <input type="button" value="Set"/>	<input type="text"/> <input type="button" value="Set"/>	Enable <input type="button" value="Set"/>

Battery remaining capacity start oil engine enable setting

Threshold of remaining battery capacity of start DG

Stop the battery remaining capacity threshold of the DG

Start the DG enable setting on a daily basis



# DG menu-9

Daily Start DG On: 17:00		Stop Delay: 5min		Monthly DG Start: Enable		Monthly Start Day1: 1	
Hour <input type="text"/>	Min <input type="text"/> <input type="button" value="Set"/>	<input type="text"/> <input type="button" value="Set"/>	<input type="text"/> <input type="button" value="Set"/>	Enable <input type="button" value="Set"/>	<input type="text"/> <input type="button" value="Set"/>	<input type="text"/> <input type="button" value="Set"/>	<input type="text"/> <input type="button" value="Set"/>
Monthly Start Day2: 10		Monthly Start Day3: 20		Monthly Start Time: 21:00		Monthly Charge Duration Time: 12H	
<input type="text"/> <input type="button" value="Set"/>	<input type="text"/> <input type="button" value="Set"/>	<input type="text"/> <input type="button" value="Set"/>	Hour <input type="text"/> Min <input type="text"/> <input type="button" value="Set"/>	<input type="text"/> <input type="button" value="Set"/>	<input type="text"/> <input type="button" value="Set"/>	<input type="text"/> <input type="button" value="Set"/>	<input type="text"/> <input type="button" value="Set"/>
Low Fuel Controlled DG Stop: Disable		DG Limit Power: Disable		DG Max Power: 21000 W			
Enable <input type="button" value="Set"/>	Enable <input type="button" value="Set"/>	<input type="text"/> <input type="button" value="Set"/>	<input type="text"/> <input type="button" value="Set"/>	<input type="text"/> <input type="button" value="Set"/>	<input type="text"/> <input type="button" value="Set"/>		

Start the DG parameter setting on a daily basis

Low oil level start DG enable setting

DG power limit enable setting

When the engine stop condition is reached, monitor the delay time of issuing the engine stop command





# DG menu-10

Daily Start DG On: 17:00		Stop Delay: 5min		Monthly DG Start: Enable		Monthly Start Day1: 1	
Hour	Min			Enable			
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
Monthly Start Day2: 10		Monthly Start Day3: 20		Monthly Start Time: 21:00		Monthly Charge Duration Time: 12H	
<input type="text"/>		<input type="text"/>		Hour		<input type="text"/>	
<input type="text"/>		<input type="text"/>		<input type="text"/>		<input type="text"/>	
Low Fuel Controlled DG Stop: Disable		DG Limit Power: Disable		DG Max Power: 21000 W			
Enable		Enable		<input type="text"/>			
<input type="text"/>		<input type="text"/>		<input type="text"/>			

Start the DG settings on a monthly basis

After starting the diesel engine monthly, the constant charging time of the DG



# DG menu-11


Daily Start DG On: 17:00		Stop Delay: 5min		Monthly DG Start: Enable		Monthly Start Day1: 1	
Hour <input type="text"/>	Min <input type="text"/>	<input type="text"/>	<input type="text"/>	Enable <input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
Monthly Start Day2: 10		Monthly Start Day3: 20		Monthly Start Time: 21:00		Monthly Charge Duration Time: 12H	
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	Hour <input type="text"/>	Min <input type="text"/>	<input type="text"/>	<input type="text"/>
Low Fuel Controlled DG Stop: Disable		DG Limit Power: Disable		DG Max Power: 21000 W			
Enable <input type="text"/>	<input type="text"/>	Enable <input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>		

The maximum power setting of the DG

Note: In order to prevent the engine from being unable to start due to excessive load power, the maximum power of the engine must be set. The monitoring module restricts the output power of the rectifier module to not greater than the maximum power of the diesel engine through the current limit command.



# DG menu-12



- DG Daily Running Time Arrive: 17:00
- DG Monthly Running Time Arrive : 1/10/20 21:00



# DC menu-1

DC Information			
Load 1 Curr: 0A	Load 1 Insant Energy: 0kWh	Load 1 Today Energy: 0kWh	Load 1 Total Energy: 0kWh
Load 2 Curr: 0A	Load 2 Insant Energy: 0kWh	Load 2 Today Energy: 0kWh	Load 2 Total Energy: 0kWh
Load 3 Curr: 0A	Load 3 Insant Energy: 0kWh	Load 3 Today Energy: 0kWh	Load 3 Total Energy: 0kWh
Load 4 Curr: ---A	Load 4 Insant Energy: ---kWh	Load 4 Today Energy: ---kWh	Load 4 Total Energy: ---kWh
Batt Curr: 1A	Batt Insant Energy: 0kWh	Batt Today Energy: 0kWh	Batt Total Energy: 0kWh
Batt 1 Mid V: ---V	Batt 2 Mid V: ---V	Batt 3 Mid V: ---V	Batt 4 Mid V: ---V

----- Load, battery current and energy consumption statistics

----- Battery pack midpoint voltage detection value





# DC menu-2

## DC Settings

DC Over Volt: 58.5V

Set

DC Under Volt: 47V

Set

Batt Mid Volt: No

Yes

Set

Battery Mid-Voltage Difference: 2V

Set

Heavy Load Ratio : 100%

Set

Load Shunt Current : 200A

Set

Load Shunt Volt : 25mV

Set

Load 1 Shunt: Yes

Yes

Set

Load 2 Shunt: Yes

Yes

Set

Load 3 Shunt: No

Yes

Set

Load 4 Shunt: No

Yes

Set

System output over/under voltage point setting

Load current overcurrent alarm coefficient setting

Battery midpoint voltage enable setting: whether to detect the battery midpoint voltage

Whether the load branch has a shunt setting



# DC menu-3

## DC Settings

DC Over Volt: 58.5V

Set

DC Under Volt: 47V

Set

Batt Mid Volt: No

Set

Battery Mid-Voltage Difference: 2V

Set

Heavy Load Ratio : 100%

Set

Load Shunt Current : 200A

Set

Load Shunt Volt : 25mV

Set

Load 1 Shunt: Yes

Set

Load 2 Shunt: Yes

Set

Load 3 Shunt: No

Set

Load 4 Shunt: No

Set

Battery cell voltage unbalance alarm threshold setting

Load shunt parameter setting




# DC menu-4

DC Calibration			
System Voltage Calibration Coefficient: $k = 1.004$		Reset Calibration Coefficient:	
System Voltage: <input type="text"/>	<input type="button" value="Set"/>	Calibration Type: <input type="text" value="System Voltage"/>	<input type="button" value="Set"/>
Battery 1 Mid-Point Voltage Calibration Coefficient: $k = 1.006$		Battery 2 Mid-Point Voltage Calibration Coefficient: $k = 1.004$	
Mid-Point Voltage 1: <input type="text"/>	<input type="button" value="Set"/>	Mid-Point Voltage 2: <input type="text"/>	<input type="button" value="Set"/>
Battery 3 Mid-Point Voltage Calibration Coefficient: $k = 1$		Battery 4 Mid-Point Voltage Calibration Coefficient: $k = 1$	
Mid-Point Voltage 3: <input type="text"/>	<input type="button" value="Set"/>	Mid-Point Voltage 4: <input type="text"/>	<input type="button" value="Set"/>
Load1 Current Calibration Coeff: $y = 1 \times 0$		Load2 Current Calibration Coeff: $y = 1 \times 0$	
Load1 Current Value: <input type="text"/>	<input type="button" value="Set"/>	Load2 Current Value: <input type="text"/>	<input type="button" value="Set"/>
Load3 Current Calibration Coeff: $y = 1 \times 0$		Load4 Current Calibration Coeff: $y = 1 \times 0$	
Load3 Current Value: <input type="text"/>	<input type="button" value="Set"/>	Load4 Current Value: <input type="text"/>	<input type="button" value="Set"/>

----- This page performs calibration settings for some parameters of DC sampling.



# Module menu-1.1



# Module menu-1.2

Modules Settings							
Sys Control Mode: Auto		Manual Manage Mode:		Rect Slot Number: 8		Solar Slot Number: 4	
Auto ▼	Set	Floating Char ▼	Set		Set		Set
Start Mode: Pool		Output Over Volt: 60.5V		Start Volt: 42V		Rect Current Limit: 122%	
Walk-In ▼	Set		Set		Set		Set
Default Output Volt: 52V		MPPT Scan Period: 300s					
	Set		Set				

Several operating options in manual mode

- ① Charge mode: You can manually control the system to immediately enter the equal charge, float charge, and battery test;
- ② LVD control: Manually control the power on and off of the load and battery;
- ③ DG control: Manually issue the start and stop commands to the DG;



# Module menu-1.3

## Modules Settings

Sys Control Mode: Auto		Manual Manage Mode:		Rect Slot Number: 8		Solar Slot Number: 4	
Auto	Set	Floating Char	Set		Set		Set
Start Mode: Pool		Output Over Volt: 60.5V		Start Volt: 42V		Rect Current Limit: 122%	
Walk-In	Set		Set		Set		Set
Default Output Volt: 52V		MPPT Scan Period: 300s					
	Set		Set				

Module output voltage overvoltage alarm point

MPPT tracking cycle setting

# Module menu-1.4

## Modules Settings

Sys Control Mode: Auto		Manual Manage Mode:		Rect Slot Number: 8		Solar Slot Number: 4	
Auto ▼	Set	Floating Char ▼	Set		Set		Set
Start Mode: Pocl		Output Over Volt: 60.5V		Start Volt: 42V		Rect Current Limit: 122%	
Walk-In ▼	Set		Set		Set		Set
Default Output Volt: 52V		MPPT Scan Period: 300s					
	Set		Set				

Number of rectifier module slots: Set according to the number of rectifier module slots in the system.

Note: It does not mean that there are several rectifier modules installed in the system.

Module output voltage: monitor the real-time voltage limit value sent to the module, and the output voltage of the rectifier module cannot exceed this value.





# Module menu-1.5

Modules Settings							
Sys Control Mode: Auto		Manual Manage Mode:		Rect Slot Number: 8		Solar Slot Number: 4	
Auto ▼	Set	Floating Char ▼	Set		Set		Set
Start Mode: Pocl		Output Over Volt: 60.5V		Start Volt: 42V		Rect Current Limit: 122%	
Walk-In ▼	Set		Set		Set		Set
Default Output Volt: 52V		MPPT Scan Period: 300s					
	Set		Set				

MPPT module slot number: set according to how many rectifier module slots in the system.

Note: It does not mean that there are several MPPT modules installed in the system.

Module current limit: the output current limit value issued by the monitoring module to the module, which is set as a percentage of the module's rated current.



# Module menu-2

Module Information									
Module No.	Vin/V	Vout/V	Iout/A	Power/kW	Temp/°C	Working Time/H	On/Off Status	Serial Number	On/Off Control
#1	---	---	---	---	---	---	---	---	On ▼ Set
#2	---	---	---	---	---	---	---	---	On ▼ Set
#3	---	---	---	---	---	---	---	---	On ▼ Set

Module real-time input voltage

Module real-time output voltage

Module real-time output current

Module real-time output power

Module air inlet temperature

Module running time: the module starts timing from the factory, the total running time


The module is individually powered on and off. Operable in manual mode, invalid in automatic mode

On/off status

Module barcode and software version



# Charging mode transition



# Charge menu-1

## Battery Groups Information

Batt 1 Curr: 0A	Batt 2 Curr: --A
Batt 1 SOC: 100%	Batt 2 SOC: --%

Display the real-time charging current of the battery and the remaining battery capacity



# Charge menu-2

Battery Charge Settings			
Float Voltage: 54.5V		Boost Voltage: 56V	
<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>
Charge Current Limit: 0.1C10		Solar Delta Volt: 1V	
<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>
Batt Capacity: 100Ah		Boost Charge Enable: Enable	
<input type="text"/>	<input type="button" value="Set"/>	<input type="text" value="Enable"/>	<input type="button" value="Set"/>

Float charge voltage setting.

For Lead-acid battery, FC voltage and boost voltage have different voltage; for lithium battery fc voltage=boost charge voltage

Battery charging current limit coefficient setting: battery charging current cannot be greater than  $0.1C_{10}$



# Charge menu-3

Battery Charge Settings			
Float Voltage: 54.5V		Boost Voltage: 56V	
<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>
Charge Current Limit: 0.1C10		Solar Delta Volt: 1V	
<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>
Batt Capacity: 100Ah		Boost Charge Enable: Enable	
<input type="text"/>	<input type="button" value="Set"/>	<input type="text" value="Enable"/>	<input type="button" value="Set"/>

Battery capacity setting: If all batteries have the same capacity, set the capacity here as the number of battery packs x the capacity of a single battery; if any group of batteries have different capacities, set it to the battery capacity with the smallest battery capacity.

Boost charge voltage setting

Overcharge alarm current coefficient setting

Boost charge enable setting



# Charge menu-4

Cyc Boost Period: 2400hour		Cyc Boost Enable: Enable	
<input type="text"/>	<input type="button" value="Set"/>	<input type="text" value="Enable"/>	<input type="button" value="Set"/>
Cyc Boost Time: 240min		Boost Limit Time: 1080min	
<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>

To set cyclic boost charging. 'Per.Boost Period' means interval time between twice timing boost charge. Battery charging voltage is 'Boost charge voltage' Setting value. Charge time is 'Per.Boost Time' setting value

During boost charge, monitor module will force system turns to float charge to secure system when boost charge time reaches to the value of 'Boost protect time'





# Charge menu-5

Boost To Float Curr: 0.01C10		Float To Boost Curr: 0.06C10	
<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>
Float To Boost Cap: 80%		Const Boost Time: 180min	
<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>

Setting of boost charge to float charge current value

Floating charge to boost charge capacity setting

Floating charge to average charge current value setting

Steady state equalization time setting



# Charge menu-6

Batt 1 Shunt: Yes		Batt 2 Shunt: No	
Yes	Set	Yes	Set
Batt Fuse Num: 2		Batt Shunt Current: 400A	
1	Set		Set
		Batt Shunt Volt: 25mV	
			Set

If the subrack has battery shunt, set to enable

Battery fuse group number setting: the default setting is 1 group, when the battery MCB trips, and the battery fuse 1 broken alarm is reported.

Battery shunt parameter setting



# Charge menu-7

Battery Current Calibration			
Batt1 Current Calibration Coeff: $y = 1.008x - 1.996$		Batt2 Current Calibration Coeff: $y = 1.002x - 0.394$	
Batt1 Actual Current: <input type="text"/>	<input type="button" value="Set"/>	Batt2 Actual Current: <input type="text"/>	<input type="button" value="Set"/>
Reset Calibration Parameter Type: <input type="text" value="Battery1 Current"/>	<input type="button" value="Set"/>		



If the battery current sampling is inaccurate, the battery current sampling can be calibrated through this interface:

- ① Reset battery current sampling coefficient
- ② Use tools such as clamp meter to measure the current sampling value and enter it into the text box in the figure above. Click on the settings




# LVD introduction-1

- LVD( Low Voltage Disconnect)
- LLVD(Load Low Voltage Disconnect)
- BLVD(Battery Low Voltage Disconnect)
- LVD Voltage and LVD Recovery Voltage can be set
- LVD Capacity and LVD Recovery Capacity can be set
- LVD Time and LVD Recovery Time can be set



# LVD introduction-3



Power System Electrical Schematic Diagram



# LVD menu-1

LVD Management							
LVD Mode: Volt Mode		Over Temp BLVD En: Enable		Under Temp BLVD En: Disable		BLVD Enable: Enable	
Volt Mode	Set	Enable	Set	Enable	Set	Enable	Set
LLVD 1 Enable: Enable		LLVD 2 Enable: Enable		LLVD 3 Enable: Disable		LLVD 4 Enable: Disable	
Enable	Set	Enable	Set	Enable	Set	Enable	Set

LVD mode setting

- ① Volt Mode: Use the busbar voltage as the LVD power-off criterion
- ② Time Mode: Use time as the basis for powering off the LVD. Start timing from battery discharge;
- ③ Cap Mode:: Use the remaining battery capacity as the basis for power-off

BLVD battery high and low temperature  
power-on enable setting

LLVD enable setting



# LVD menu-2

LVD Voltage Settings							
LLVD 1 Volt: 45V		LLVD 2 Volt: 44V		LLVD 3 Volt: 44V		LLVD 4 Volt: 44V	
<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>
LLVD 1 Recovery Volt: 50V		LLVD 2 Recovery Volt: 50V		LLVD 3 Recovery Volt: 50V		LLVD 4 Recovery Volt: 50V	
<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>
BLVD Volt: 43.5V		BLVD Recovery Volt: 50V					
<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>				

If the voltage power-off mode is selected, the protection voltage and recovery voltage of each power-off can be set through this interface.



# LVD menu-3

LVD Time Settings							
LLVD 1 Time: 360min		LLVD 2 Time: 360min		LLVD 3 Time: 360min		LLVD 4 Time: 360min	
<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>
BLVD Time: 480min							
<input type="text"/>	<input type="button" value="Set"/>						

If select the time power-off module, you can set the power-off time of each channel through this interface.

Note: Discharge from the battery is the starting point for timing.



# LVD menu-4

LVD Capacity Settings							
LLVD 1 Capacity: 15%		LLVD 2 Capacity: 15%		LLVD 3 Capacity: 15%		LLVD 4 Capacity: 15%	
<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>
BLVD Capacity: 5%							
<input type="text"/>	<input type="button" value="Set"/>						

If the battery capacity power-off mode is selected, the remaining capacity of each power-off battery can be set through this interface



# Battery test introduction

The battery test process allows for the battery to be discharged on-line using the system load. There are three types of battery test:

- Manual start and stop stable test or short test.
- Automatic stable test, if enabled.
- Automatic short test, if enabled.

Battery test screen is submenu of parameter setting screen, mainly used for operator to set battery test of system battery management.



# Battery test menu-1

Battery Test Settings			
Automatic Testing			
End Test Voltage: 45.2V		End Test Capacity: 70%	
<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>


In the process of battery test, if meet one of the following three conditions, exit the battery test and turn to float charge :

- Battery voltage reaches to 'End Test Voltage'
- Battery residual capacity reaches to 'End Test Cap'



# Short test introduction

- The output voltage of the rectifier is adjusted to the 'End Test Voltage'
- $\text{BattMaxCurr} - \text{BattMinCurr} < \text{Batt Curr Imbalance}$  during short test, Short Test is OK else Short Test is FAIL.
- End Test Voltage、Short Test Enable、Short Test Period、Short Test Time、Batt Curr Imbalance can be set



# Battery test menu-2

Short Test

Short Test Enable: Disable		Short Test Period: 720hour	
Enable ▾	Set		Set
Short Test Time: 5min		Batt Curr Imbalance: 5A	
	Set		Set


Short test enable setting

Short test time setting

Short test period setting

Short test alarm current setting

# Constant current test introduction



- Stable test mode is recommended in only one battery current system
- the battery discharge current is limited to 'Stable Test Curr'
- the battery test fault alarm appear when Stable test is not OK
- The battery test fault alarm disappears for 5 minutes, and become a historical alarm.
- Stable Test Curr Can be set
- stable test period Can be set
- the duration of stable test period Can be set

**Notice:** This type of battery test is designed to give an indication only of battery state of health.





# Battery test menu-3

## Constant Current Test

Batt Test Enable: Disable

Enable



Set

Stable Test Current: 0.2C10

Set

Stable Test Period: 4320hour

Set

End Test Time: 300min

Set

Constant current test enable setting

Constant current test parameter setting



# Battery test menu-4

## Peak Discharge Test

Peak Discharge: Disable

Enable

Set

Peak Period1: 08:00 -- 11:00

Hour

Min

- Hour

Min

Set

Peak Period2: 14:00 -- 15:00

Hour

Min

- Hour

Min

Set

Peak Period3: 18:00 -- 23:00

Hour

Min

- Hour

Min

Set

When set to 'Enable' , the system will enable peak battery discharge function. The battery will discharge during the peak period of electricity tariff, and the battery will be recharged for energy storage during other periods to achieve the purpose of reducing the electricity cost.

At the daily peak start time , the battery starts discharging.

At the daily peak end time, the battery stops discharging



# Temperature test-1

## Temperature and Humidity Information

Batt 1 Temp: ---°C	Batt 2 Temp: ---°C
Sen. 3 Temp: ---°C	Sen. 4 Temp: ---°C
Env Humidity: ---%RH	
Ws Env Temp: ---°C	Ws Env Humidity: ---%RH

This page displays real-time sampling values of battery temperature, ambient temperature and ambient humidity



# Temperature detect-2

## Temperature and Humidity Settings

Temp Comp Enable: Enable

Enable

Set

Temp Comp Coef: 96mV/C

Set

Temp Comp Center: 25°C

Set

Humidity Sensor: No

No

Set

Temp Sensor 1: Batt

Batt

Set

Temp Sensor 2: No

Batt

Set

Temp Sensor 3: No

Batt

Set

Temp Sensor 4: No

Batt

Set

Float charge voltage decrease value = (Battery temperature measuring value- 25) × Temperature compensation coefficient When rectifier communication fail or system over/under voltage, temperature compensation function will be invalid. When anyone battery temperature sensor is fault or disconnect, temperature compensation function will be invalid. When there are multiple temperature sensors, select the lowest temperature for temperature compensation



# Temperature detect-3

## Temperature and Humidity Settings

Temp Comp Enable: Enable

Enable

Set

Temp Comp Coef: 96mV/°C

Set

Temp Comp Center: 25°C

Set

Humidity Sensor: No

No

Set

Temp Sensor 1: Batt

Batt

Set

Temp Sensor 2: No

Batt

Set

Temp Sensor 3: No

Batt

Set

Temp Sensor 4: No

Batt

Set

Battery temperature sensor 1, 2, environmental humidity sensor enable setting

Temperature sensor 3, 4 type and enable setting



# Temperature detect-4

Temperature and Humidity Alarm			
Batt 1 Temp High+: 60°C		Batt 1 Temp High: 55°C	
<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>
Batt 1 Temp Low: -33°C		Batt 2 Temp High+: 60°C	
<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>
Batt 2 Temp High: 55°C		Batt 2 Temp Low : -33°C	
<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>

Temperature alarm thresholds of battery temperature sensors 1 and 2



# Temperature detect-5

Sen. 3 Temp High+: 60°C		Sen. 3 Temp High: 55°C	
<input type="text"/>	Set	<input type="text"/>	Set
Sen. 3 Temp Low: -33°C		Sen. 4 Temp High+: 60°C	
<input type="text"/>	Set	<input type="text"/>	Set
Sen. 4 Temp High: 55°C		Sen. 4 Temp Low: -33°C	
<input type="text"/>	Set	<input type="text"/>	Set
Env.Humidity H: 95%RH		Env.Humidity L: 5%RH	
<input type="text"/>	Set	<input type="text"/>	Set

Set the temperature alarm thresholds of temperature sensors 3 and 4

Set the humidity high and low alarm thresholds of the humidity sensor



# BMS information

BMS Settings

BMS protocol: Narada

Polarium

Set

BMS Total Num: 0

BMS Baud Rate: 9600

4800

Set

Unlock Password

Set


BMS Information

No	Pack Voltage/V	Current/A	SOC/%	SOH/%	Charging Switch State	Discharging Switch State	Limit Switch State	Max Cell Voltage/V	Min Cell Voltage/V	Max Cell Temperature/℃	Min Cell Temperature/℃	Average Cell Temperature/℃	Ambient Temperature/℃	Remain Capacity/AH	Battery Cycles	Model	Software Version	Hardware Version	Serial No	Date of Manufacture
----	----------------	-----------	-------	-------	-----------------------	--------------------------	--------------------	--------------------	--------------------	------------------------	------------------------	----------------------------	-----------------------	--------------------	----------------	-------	------------------	------------------	-----------	---------------------

If the monitoring module is connected to the lithium battery communication port, this page will display the relevant information of the BMS



# ECO introduction



In the ECO mode, the controller controls the rectifiers to switch on and off according to the load, so that the rectifiers work under the load rate with the highest efficiency.

ECO Abnormal Conditions:

- Both Mains and PV input failure
- DC under voltage
- Batteries are in testing
- Batteries are discharging
- Battery fuses failure
- BLVD disconnect
- Any rectifier module alarms (e.g., communication interruption)

**Note:**

When the system exit ECO due to the preceding reasons and any rectifier is turned off, the number of ECO exceptions increases by 1. If the number of ECO exceptions reaches 10 within 1 hour, ECO Pause alarm occur and the ECO function will be disabled. After 12 hours, the ECO function will automatically become enabled.



# ECO-1

ECO Information			
ECO State: Off		ECO Error State: 0	
ECO Settings			
ECO Enable: Disable		ECO Cycle Period: 168h	
Enable	Set		Set
Best Load Ratio: 60%		Rect Save Stop: 90%	
	Set		Set
Min Rect Num: 2		Phase Balance Prio: Enable	
	Set	Enable	Set
DryTime: 120min			
	Set		

Short test enable setting

Rect Save Start is also known as rectifier best operating-point. At the best operating-point, the rectifier module operates at a relatively high efficiency and is subject to more suitable stresses.



# ECO-2

ECO Information			
ECO State: Off		ECO Error State: 0	
ECO Settings			
ECO Enable: Disable		ECO Cycle Period: 168h	
<div>Enable</div>	<div>Set</div>	<div></div>	<div>Set</div>
Best Load Ratio: 60%		Rect Save Stop: 90%	
<div></div>	<div>Set</div>	<div></div>	<div>Set</div>
Min Rect Num: 2		Phase Balance Prio: Enable	
<div></div>	<div>Set</div>	<div>Enable</div>	<div>Set</div>
DryTime: 120min			
<div></div>	<div>Set</div>		

Period Time is also known as cycle activation time. In order to synchronize the life of all the rectifier modules, it is necessary to operate the module with a long sleep time at a certain time interval while allowing the module with a long working time to sleep. This time interval is cycle activation time.

# ECO-3

ECO Information			
ECO State: Off		ECO Error State: 0	
ECO Settings			
ECO Enable: Disable		ECO Cycle Period: 168h	
<div>Enable</div>	<div>Set</div>	<div></div>	<div>Set</div>
Best Load Ratio: 60%		Rect Save Stop: 90%	
<div></div>	<div>Set</div>	<div></div>	<div>Set</div>
Min Rect Num: 2		Phase Balance Prio: Enable	
<div></div>	<div>Set</div>	<div>Enable</div>	<div>Set</div>
DryTime: 120min			
<div></div>	<div>Set</div>		

Rect Save Stop is also known as system energy-saving point. If load / rated capacity ratio more than system energy-saving point, the power supply system exit energy-saving mode.

The minimum number of rectifier working

# ECO-4

## ECO Information

ECO State: Off

ECO Error State: 0

## ECO Settings

ECO Enable: Disable

ECO Cycle Period: 168h

Enable

Set

Set

Best Load Ratio: 60%

Rect Save Stop: 90%

Set

Set

Min Rect Num: 2

Phase Balance Prio: Enable

Set

Enable

Set

DryTime: 120min

Set

- Enable: In ECO mode, AC three-phase voltage balance is considered first, rectifier efficiency is considered second, and rectifier running time is considered third.
- Disable: In ECO mode, rectifier efficiency is considered first, and rectifier slot is considered second. Rectifier modules off from a lower slot, and rectifier modules on from a higher slot.



# Communication munu-1

Communication Information			
MAC Address: 68:27:19:21:73:A8			
IP Settings			
IP Address: 10.2.80.165	Subnet Mask: 255.255.255.0	Gateway Address: 10.2.80.1	
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="button" value="Set"/>

Set IP parameter



# Communication munu-2

Communication Settings			
Trap Address 1: 0.0.0.0		Trap Address 2: 0.0.0.0	
<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>
Comm Addr: 1		Baud Rate: 9600	
<input type="text"/>	<input type="button" value="Set"/>	<input type="text" value="9600"/>	<input type="button" value="Set"/>
Read Community: public		Reset SNMP Trap	
<input type="text"/>	<input type="button" value="Set"/>	Reset SNMP Trap:	<input type="button" value="Set"/>
Write Community: public			
<input type="text"/>	<input type="button" value="Set"/>		

Set communication parameter



# Active Alarm

Active Alarm List			
Active Alarm Number : 4			
BMS Detailed Alarms			
AlarmNo	AlarmName	BeginTime	AlarmLevel
1	BLVD	2018-01-01 00:52:04	Major Alarm

Alarm name

Alarm begin time

Alarm level



# History Alarm

## History Alarm List

History Alarm Number : 102

Maximum History Alarm Number can be shown : 100

AlarmNo	AlarmName	BeginTime	EndTime
1	SPD Alarm	2018-01-01 00:03:01	2018-01-01 00:03:47
2	SPD Alarm	2018-01-01 00:00:02	2018-01-01 00:03:01
3	Mains Failure	2018-01-01 00:00:30	2018-01-01 00:03:01
4	AC Breaker Open	2018-01-01 00:00:30	2018-01-01 00:03:01
5	Temp Sensor 1 Fault	2018-01-01 00:00:32	2018-01-01 00:03:01

Alarm name

Alarm begin time

Alarm end time



# Data Log

Data Log Settings									
Vin Config: undefined		Iout Config: undefined		BattCurr Config: undefined		BattTemp Config: undefined		Data Logs Period: undefinedmin	
AC Input Voltage ▾	Set	Load Current ▾	Set	Battery Current ▾	Set	Batt Temper1 ▾	Set		Set

Data Log Number : 103

Maximum Data Log Number can be shown : 100

Data Log List							
SeqNo	Data Log Time	Vin/V	Vout/V	Iout/A	BattCurr/A	BattTemp/°C	
01	2018-01-01 01:53:47	0.0	23.9	0.0	1.1	25.0	
02	2018-01-01 01:48:47	0.0	23.9	0.0	1.1	25.0	

Set which parameters need to be set for data log



# Battery Log

## Battery Log List

SeqNo	StartTime	StartMode	StartVolt	EndTime	EndMode	End Test Voltage	Discharge capacity of battery 1	Discharge capacity of battery 2
01	2022-05-19 15:42:09	Constant current test	51.10V	2022-05-19 15:47:00	Constant test exit on time	54.59V	0.0%	0.0%
02	2022-05-19 14:10:00	Constant current test	54.51V	2022-05-19 14:14:00	Constant test exit on time	48.60V	0.5%	0.0%
03	2022-05-19 14:00:00	Constant current test	54.52V	2022-05-19 14:04:01	Constant test exit on time	48.68V	0.5%	0.0%
04	2022-05-19 13:47:00	Constant current test	54.53V	2022-05-19 13:52:00	Constant test exit on time	50.24V	0.0%	0.0%
05	2022-05-19 11:37:00	Constant current test	52.97V	2022-05-19 11:42:00	Constant test exit on time	54.52V	0.0%	0.0%
06	2022-05-19 11:15:00	Constant current test	54.54V	2022-05-19 11:20:00	Constant test exit on time	54.53V	0.5%	0.0%
07	2022-05-19 10:14:00	Constant current test	54.54V	2022-05-19 10:19:00	Constant test exit on time	54.51V	0.0%	0.0%
08	2022-05-19 10:10:05	Constant current test	54.53V	2022-05-19 10:10:40	Manual exit test	51.73V	0.0%	0.0%



# Alarm Config

Alarm Config		
Alarm Name: DC Under Volt	Alarm Level: Major Alarm	Alarm Relay: None
Alarm Name: <input type="text" value="DC Under Volt"/> <input type="button" value="Set"/>	Alarm Level: <input type="text" value="No Alarm"/> <input type="button" value="Set"/>	Alarm Relay: <input type="text" value="None"/> <input type="button" value="Set"/>

Digital Input Config		
DI Id: DI1	DI Name: Climate Alarm	DI Alarm: NO
DI: <input type="text" value="DI1"/> <input type="button" value="Set"/>	DI Name: <input type="text" value="Climate Alarm"/> <input type="button" value="Set"/>	DI Alarm: <input type="text" value="NO"/> <input type="button" value="Set"/>

Digital Output Config	
DO Id: DO1	DO Alarm: NC
DO: <input type="text" value="DO1"/> <input type="button" value="Set"/>	DO Alarm: <input type="text" value="NO"/> <input type="button" value="Set"/>

Set the alarm level of the alarm and the DO corresponding to the alarm

Set DI name and DI's normally open normally closed state

Set the normally open and normally closed state of DO



# System menu-1

## System Information

Software Version: 9.02150401

Hardware Version: 25.5

User Config Version:1.03

Show monitor SW version

Show monitor user config version



# System menu-2

## System Information Settings

Site Name:		Date and Time: 2018-1-1 02:00	Windows Time
<input type="text"/>	<input type="button" value="Set"/>	Year <input type="text"/> Mon <input type="text"/> Day <input type="text"/> Hour <input type="text"/> Min <input type="text"/> Sec <input type="text"/>	<input type="button" value="Set"/>
Change The Operator Password		Change The Administrator Password	
<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>
System Rectifier Type: 21000W		System Solar Type: 12000W	
<input type="text"/>	<input type="button" value="Set"/>	<input type="text"/>	<input type="button" value="Set"/>
System Power Mode: Only Mains		System Restart:	
<input type="text" value="Only Mains"/>	<input type="button" value="Set"/>		<input type="button" value="Set"/>

Set site name

Modify password

Report the power of the rectifier module to  
the upper monitor

Restar the monitor

Modify the current time of  
monitoring

Report the power of the MPPT  
module to the upper monitor



# System menu-3

Clear Alarm Log			
Clear Alarm Record ▼	Set	Restore to Default:	Set

Clear log parameters and alarm records

Reset the monitor the factory parameter



# Upload/Download

Upload/Download File			
Download File		Select Configuration File	
Configuration File ▼	Download	选择文件 未选择任何文件	Upload
Software Upgrade			

- Upload and download configuration files
- Upgrade monitor program





A low-angle, upward-looking shot of a modern skyscraper with a glass and steel facade. The building's structure is composed of a grid of dark, intersecting lines that create a strong sense of perspective, drawing the eye towards the top of the frame. The sky is a pale, hazy blue, and two small, bright lights are visible on the building's facade, adding a touch of warmth to the scene.

**Thanks**