

ros_diff_drive

Generated by Doxygen 1.8.17

1 Module Index	1
1.1 Modules	1
2 Namespace Index	3
2.1 Namespace List	3
3 Hierarchical Index	5
3.1 Class Hierarchy	5
4 Class Index	7
4.1 Class List	7
5 Module Documentation	9
5.1 Pre initial values of PID regulators	9
5.1.1 Detailed Description	9
5.1.2 Variable Documentation	10
5.1.2.1 INT_LIMIT_FWD	10
5.1.2.2 INT_LIMIT_ROT	10
5.1.2.3 KP_FWD	10
5.1.2.4 KP_ROT	10
5.1.2.5 P_ANG_DST	10
5.1.2.6 P_ANG_THT	11
5.1.2.7 P_FWD_CUR	11
5.1.2.8 P_FWD_DST	11
5.1.2.9 TD_FWD	11
5.1.2.10 TD_ROT	11
5.1.2.11 TI_FWD	11
5.1.2.12 TI_ROT	11
5.2 Values updated during the callback of the odometry	12
5.2.1 Detailed Description	12
5.3 Values updated during the callback of the odometry	13
5.3.1 Detailed Description	13
5.4 Variables used for debugging purposes	14
5.4.1 Detailed Description	14
6 Namespace Documentation	15
6.1 config Namespace Reference	15
6.1.1 Detailed Description	16
6.2 debug Namespace Reference	16
6.2.1 Detailed Description	16
6.3 fsm Namespace Reference	16
6.3.1 Detailed Description	17
6.4 move_to_point Namespace Reference	17
6.4.1 Detailed Description	19

6.4.2 Function Documentation	19
6.4.2.1 angle_error_calc()	19
6.4.2.2 dyn_reconf_callback()	19
6.4.2.3 forward()	20
6.4.2.4 goal_position_callback()	20
6.4.2.5 idle()	20
6.4.2.6 position_callback()	20
6.4.2.7 rotate()	20
6.5 regulator Namespace Reference	21
6.5.1 Detailed Description	21
7 Class Documentation	23
7.1 fsm.FsmRobot Class Reference	23
7.1.1 Detailed Description	23
7.1.2 Constructor & Destructor Documentation	24
7.1.2.1 __init__()	24
7.1.3 Member Function Documentation	24
7.1.3.1 default()	24
7.1.3.2 switch_state()	24
7.1.3.3 validate_state()	25
7.2 fsm.FsmState Class Reference	25
7.2.1 Detailed Description	25
7.3 fsm.FsmStates Class Reference	26
7.3.1 Detailed Description	26
7.3.2 Member Data Documentation	27
7.3.2.1 Default	27
7.4 regulator.Regulator Class Reference	27
7.4.1 Detailed Description	28
7.4.2 Member Function Documentation	28
7.4.2.1 update_params()	28
7.4.3 Member Data Documentation	28
7.4.3.1 err_p_prev	28
Index	29

Chapter 1

Module Index

1.1 Modules

Here is a list of all modules:

Pre initial values of PID regulators	9
Values updated during the callback of the odometry	12
Values updated during the callback of the odometry	13
Variables used for debugging purposes	14

Chapter 2

Namespace Index

2.1 Namespace List

Here is a list of all documented namespaces with brief descriptions:

config	15
debug	16
fsm	16
move_to_point	17
regulator	21

Chapter 3

Hierarchical Index

3.1 Class Hierarchy

This inheritance list is sorted roughly, but not completely, alphabetically:

Enum	
fsm.FsmStates	26
fsm.FsmRobot	23
fsm.FsmState	25
regulator.Regulator	27

Chapter 4

Class Index

4.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

fsm.FsmRobot	Finite State Machine class Provides data structure for FSM as well as main methods for normal functioning and events logging	23
fsm.FsmState	FSM state class	25
fsm.FsmStates	Enumeration containing state machine states definitions	26
regulator.Regulator	Class of the regulator which contains parameters and methods which implement different control algorithms	27

Chapter 5

Module Documentation

5.1 Pre initial values of PID regulators

Values of PID parameters before the update from the dynamic reconfigure module. Advice is to keep current values.

Variables

- float `config.KP_ROT` = 0.0
Rotation KP constant.
- float `config.TI_ROT` = 0.000001
Rotation TI constant.
- float `config.TD_ROT` = 0.0
Rotation TD constant.
- float `config.INT_LIMIT_ROT` = 0.0
Limit of the control value used as protection from the wind-up - used for rotation.
- float `config.P_ANG_DST` = 0.0
Gaol angle filter constant.
- float `config.P_ANG_THT` = 0.0
Current angle filter constant.
- float `config.KP_FWD` = 0.0
Move forward KP constant.
- float `config.TI_FWD` = 0.000001
Move forward TI constant.
- float `config.TD_FWD` = 0.0
Move forward TD constant.
- float `config.P_FWD_DST` = 0.0
Gaol distance filter constant.
- float `config.P_FWD_CUR` = 0.0
Current distance filter constant.
- float `config.INT_LIMIT_FWD` = 0.0
Limit of the control value used as protection from the wind-up - used for moving forward.

5.1.1 Detailed Description

Values of PID parameters before the update from the dynamic reconfigure module. Advice is to keep current values.

5.1.2 Variable Documentation

5.1.2.1 INT_LIMIT_FWD

```
float config.INT_LIMIT_FWD = 0.0
```

Limit of the control value used as protection from the wind-up - used for moving forward.

Overwritten later by dynamic reconfigure module.

5.1.2.2 INT_LIMIT_ROT

```
float config.INT_LIMIT_ROT = 0.0
```

Limit of the control value used as protection from the wind-up - used for rotation.

Overwritten later by dynamic reconfigure module.

5.1.2.3 KP_FWD

```
float config.KP_FWD = 0.0
```

Move forward KP constant.

Overwritten later by dynamic reconfigure module.

5.1.2.4 KP_ROT

```
float config.KP_ROT = 0.0
```

Rotation KP constant.

Overwritten later by dynamic reconfigure module.

5.1.2.5 P_ANG_DST

```
float config.P_ANG_DST = 0.0
```

Gaol angle filter constant.

Overwritten later by dynamic reconfigure module.

5.1.2.6 P_ANG_THT

```
float config.P_ANG_THT = 0.0
```

Current angle filter constant.

Overwritten later by dynamic reconfigure module.

5.1.2.7 P_FWD_CUR

```
float config.P_FWD_CUR = 0.0
```

Current distance filter constant.

Overwritten later by dynamic reconfigure module.

5.1.2.8 P_FWD_DST

```
float config.P_FWD_DST = 0.0
```

Gaol distance filter constant.

Overwritten later by dynamic reconfigure module.

5.1.2.9 TD_FWD

```
float config.TD_FWD = 0.0
```

Move forward TD constant.

Overwritten later by dynamic reconfigure module.

5.1.2.10 TD_ROT

```
float config.TD_ROT = 0.0
```

Rotation TD constant.

Overwritten later by dynamic reconfigure module.

5.1.2.11 TI_FWD

```
float config.TI_FWD = 0.000001
```

Move forward TI constant.

Overwritten later by dynamic reconfigure module.

5.1.2.12 TI_ROT

```
float config.TI_ROT = 0.000001
```

Rotation TI constant.

Overwritten later by dynamic reconfigure module.

5.2 Values updated during the callback of the odometry

Variables

- float `move_to_point.xInitial` = 0.0
Initial x coordinate from the start of moving forward.
- float `move_to_point.yInitial` = 0.0
Initial y coordinate from the start of moving forward.

5.2.1 Detailed Description

5.3 Values updated during the callback of the odometry

These values are updated during [position_callback](#).

Variables

- [move_to_point.cur_pos](#) = `Point()`
Contains X and Y coordinates of the current position.
- [move_to_point.x](#)
X coordinate of the current position - initialization.
- [move_to_point.y](#)
Y coordinate of the current position - initialization.
- float [move_to_point.theta](#) = 0.0
Represents current angle of the robot.

5.3.1 Detailed Description

These values are updated during [position_callback](#).

5.4 Variables used for debugging purposes

If debugging only rotation/forward, they receive the value from the dynamic reconfigure.

Variables

- float `move_to_point.GOAL_THETA` = 0.0
Goal angle.
- float `move_to_point.GOAL_DIST` = 0.0
Goal distance.

5.4.1 Detailed Description

If debugging only rotation/forward, they receive the value from the dynamic reconfigure.

Chapter 6

Namespace Documentation

6.1 config Namespace Reference

Variables

- float `controller_freq` = 50.0
Controller frequency in Hertz.
- float `rot_speed_limit` = 2.0
Rotation speed limit.
- float `fwd_speed_limit` = 0.7
Speed limit of moving forward.
- float `angle_err_tolerance` = 0.04
Angle error tolerance in degrees.
- float `dist_err_tolerance` = 0.005
Distance error tolerance.
- float `KP_ROT` = 0.0
Rotation KP constant.
- float `TI_ROT` = 0.000001
Rotation TI constant.
- float `TD_ROT` = 0.0
Rotation TD constant.
- float `INT_LIMIT_ROT` = 0.0
Limit of the control value used as protection from the wind-up - used for rotation.
- float `P_ANG_DST` = 0.0
Gaol angle filter constant.
- float `P_ANG_THT` = 0.0
Current angle filter constant.
- float `KP_FWD` = 0.0
Move forward KP constant.
- float `TI_FWD` = 0.000001
Move forward TI constant.
- float `TD_FWD` = 0.0
Move forward TD constant.
- float `P_FWD_DST` = 0.0
Gaol distance filter constant.
- float `P_FWD_CUR` = 0.0
Current distance filter constant.
- float `INT_LIMIT_FWD` = 0.0
Limit of the control value used as protection from the wind-up - used for moving forward.

6.1.1 Detailed Description

Static configuration of the `move_to_point` module

6.2 debug Namespace Reference

Variables

- `pub_dbg_angle_err` = `rospy.Publisher("debug/angle_err", Float32, queue_size = 5)`
Angle error values publisher.
- `pub_dbg_theta` = `rospy.Publisher("debug/theta", Float32, queue_size=5)`
Current angle publisher.
- `pub_dbg_theta_filtr` = `rospy.Publisher("debug/theta_filtr", Float32, queue_size=5)`
Publisher for filtered value of the current value.
- `pub_dbg_ang_to_goal` = `rospy.Publisher("debug/angle_to_goal", Float32, queue_size=5)`
Publisher for the goal angle.
- `pub_dbg_ang_to_goal_filtr` = `rospy.Publisher("debug/angle_to_goal_filtr", Float32, queue_size=5)`
Publisher for the filtered value of the goal angle.
- `pub_dbg_rot` = `rospy.Publisher("debug/rot_vel", Float32, queue_size=5)`
Publisher for the desired rotation velocity.
- `pub_dbg_distance` = `rospy.Publisher("/debug/distance", Float32, queue_size = 5)`
Current distance publisher.
- `pub_dbg_distance_filtr` = `rospy.Publisher("/debug/dist_filtr", Float32, queue_size = 5)`
Filtered distance publisher.
- `pub_dbg_dist_to_goal` = `rospy.Publisher("/debug/dist_to_goal", Float32, queue_size = 5)`
Goal distance publisher.
- `pub_dbg_dist_to_goal_filtr` = `rospy.Publisher("/debug/dist_to_goal_filtr", Float32, queue_size = 5)`
Filtered goal distance publisher.
- `pub_dbg_fwd` = `rospy.Publisher("/debug/dist_velocity", Float32, queue_size = 5)`
Distance velocity publisher.
- `pub_dbg_fwd_rot` = `rospy.Publisher("/debug/fwd_rot", Float32, queue_size = 5)`
Angle error during moving forward - publisher.
- `pub_dbg_fwd_rot_vel` = `rospy.Publisher("/debug/fwd_rot_vel", Float32, queue_size = 5)`
Rotation velocity command during moving forward - publisher.

6.2.1 Detailed Description

Contains debug variables and publisher/subscriber definitions

6.3 fsm Namespace Reference

Classes

- class `FsmRobot`
Finite State Machine class Provides data structure for FSM as well as main methods for normal functioning and events logging.
- class `FsmState`
FSM state class.
- class `FsmStates`
Enumeration containing state machine states definitions.

6.3.1 Detailed Description

Finite State Machine library

6.4 move_to_point Namespace Reference

Functions

- def [angle_error_calc](#) (target_angle, current_angle)
Calculate rotation direction
Positive rotation direction - clockwise
Negative rotation direction - counter clockwise.
- def [dyn_reconf_callback](#) (config, level)
Dynamic reconfigure callback function.
- def [position_callback](#) (msg)
Odometry subscriber callback function.
- def [goal_position_callback](#) (msg)
Callback function for processing goal values.
- def [idle](#) ()
Idle function of the robot state machine.
- def [rotate](#) ()
Rotation function of the robot state machine.
- def [forward](#) ()
State machine functionality for moving forward.

Variables

- float [T](#) = 1.0 / controller_freq
Controller's period in seconds.
- float [xInitial](#) = 0.0
Initial x coordinate from the start of moving forward.
- float [yInitial](#) = 0.0
Initial y coordinate from the start of moving forward.
- [cur_pos](#) = Point()
Contains X and Y coordinates of the current position.
- [x](#)
X coordinate of the current position - initialization.
- [y](#)
Y coordinate of the current position - initialization.
- float [theta](#) = 0.0
Represents current angle of the robot.
- [goal](#) = Point(0, 0, 0)
Goal input coordinates Updated in [goal_position_callback](#).
- float [GOAL_THETA](#) = 0.0
Goal angle.
- float [GOAL_DIST](#) = 0.0
Goal distance.
- [active_goal](#) = Point(0, 0, 0)
Goal coordinates that are under processing.

- float `angle_to_goal_filt` = 0.0
Filtered value of the goal angle.
- float `theta_filt` = 0.0
Filtered value of the current angle.
- bool `POSITIVE` = True
Constant for indicating positive angle.
- bool `NEGATIVE` = False
Constant for indicating negative angle.
- bool `theta_sign` = `POSITIVE`
Variable indicating signess of the current iteration angle: `POSITIVE` or `NEGATIVE`.
- bool `theta_sign_prev` = `POSITIVE`
Variable indicating signess of the angle from the previous iteration: `POSITIVE` or `NEGATIVE`.
- float `goal_distance` = 0.0
Calculated goal distance.
- float `goal_distance_filt` = 0.0
Filtered value of the goal distance.
- float `dist_filt` = 0.0
Filtered value of the desired distance.
- bool `move_fwd_started` = False
Indicates if moving forward started or not.
- float `angle_to_goal_fwd` = 0.0
Used for correcting angle error which accumulates while moving forward.
- `sub_goal_position` = `rospy.Subscriber("/target_position/position", Pose2D, goal_position_callback)`
Goal destination subscriber.
- `sub_odom` = `rospy.Subscriber("/m2xr_diff_drive_controller/odom", Odometry, position_callback)`
Odometry (current position) subscriber.
- `pub_cmd_vel` = `rospy.Publisher("/m2xr_diff_drive_controller/cmd_vel", Twist, queue_size=1)`
cmd_vel publisher Used to publish desired velocity to the next layer of the control.
- `r` = `rospy.Rate(controller_freq)`
Initialization of the speed_controller node.
- `StateIdle` = `FsmState(FsmStates.Idle, idle)`
FSM idle state definition.
- `StateRotation` = `FsmState(FsmStates.Rotating, rotate)`
FSM rotation state definition.
- `StateForward` = `FsmState(FsmStates.Forward, forward)`
FSM moving forward state definition.
- list `StatesList` = [`StateIdle`, `StateRotation`, `StateForward`]
List of permitted states.
- `robot_fsm` = `FsmRobot("M2XR", StatesList, StatesList[0])`
FSM Initialization.
- `srv_dyn_reconf` = `Server(DynRecPIDConfig, dyn_reconf_callback)`
Dynamic reconfigure server initialization.
- `rot_pid` = `Regulator(KP_ROT, TI_ROT, TD_ROT, T, rot_speed_limit, INT_LIMIT_ROT)`
Normal rotation PID regulator initialization.
- `fwd_pid` = `Regulator(KP_FWD, TI_FWD, TD_FWD, T, fwd_speed_limit, INT_LIMIT_FWD)`
Moving forward PID regulator initialization.
- `fwd_pid_rot` = `Regulator(KP_ROT, TI_ROT, TD_ROT, T, rot_speed_limit, INT_LIMIT_ROT)`
Rotation while moving forward PID regulator initialization.

6.4.1 Detailed Description

Implements differential drive robot control

6.4.2 Function Documentation

6.4.2.1 angle_error_calc()

```
def move_to_point.angle_error_calc (
    target_angle,
    current_angle )
```

Calculate rotation direction
Positive rotation direction - clockwise
Negative rotation direction - counter clockwise.

Parameters

<i>target_angle</i>	Angle to be reached [degrees]
<i>current_angle</i>	Current angle of the robot [degrees]

Returns

Error including direction [degrees]

6.4.2.2 dyn_reconf_callback()

```
def move_to_point.dyn_reconf_callback (
    config,
    level )
```

Dynamic reconfigure callback function.

Parameters

<i>config</i>	Contains all dynamic parameters
<i>level</i>	Not used

Returns

config

6.4.2.3 forward()

```
def move_to_point.forward ( )
```

State machine functionality for moving forward.

This state controls robot when moving forward. It filters current distance and desired distance values, calculates an error, and generates desired linear speed calculated in PID routine. Desired rotation speed is then published to the velocity publisher [pub_cmd_vel](#).

6.4.2.4 goal_position_callback()

```
def move_to_point.goal_position_callback (
    msg )
```

Callback function for processing goal values.

Parameters

<i>msg</i>	Message to be processed - contains desired goal position
------------	--

6.4.2.5 idle()

```
def move_to_point.idle ( )
```

Idle function of the robot state machine.

In this state robot is waiting for the new command to arrive.

6.4.2.6 position_callback()

```
def move_to_point.position_callback(
    msg )
```

Odometry subscriber callback function.

Parameters

<i>msg</i>	The message base on Odometry message type
------------	---

6.4.2.7 rotate()

```
def move_to_point.rotate ( )
```


Rotation function of the robot state machine.

This state controls robot rotation. It filters current angle and desired angle values, calculates an error in degrees and generates desired rotation speed calculated in PID routine. Desired rotation speed is then published to the velocity publisher [pub_cmd_vel](#).

6.5 regulator Namespace Reference

Classes

- class [Regulator](#)

Class of the regulator which contains parameters and methods which implement different control algorithms.

6.5.1 Detailed Description

Implements PID regulation algorithms

Chapter 7

Class Documentation

7.1 fsm.FsmRobot Class Reference

Finite State Machine class Provides data structure for FSM as well as main methods for normal functioning and events logging.

Public Member Functions

- def `__init__` (self, `name`, `states_list`, state)
Default constructor for FSM name: Name of the FSM.
- def `switch_state` (self, new_state)
Method used for switching between states of the FSM.
- def `validate_state` (self, state)
Method used for state validation.
- def `default` (self)
Default method of the FSM.
- def `execute` (self)
Method used to execute `current_state` of the FSM.

Public Attributes

- `name`
Name of the FSM.
- `states_list`
List of states.
- `current_state`
State which is currently under the execution.
- `previous_state`
Previous state.

7.1.1 Detailed Description

Finite State Machine class Provides data structure for FSM as well as main methods for normal functioning and events logging.

7.1.2 Constructor & Destructor Documentation

7.1.2.1 `__init__()`

```
def fsm.FsmRobot.__init__ (
    self,
    name,
    states_list,
    state )
```

Default constructor for FSM name: Name of the FSM.

Parameters

<i>name</i>	Desired name of the FSM
<i>states_list</i>	List of permitted states
<i>state</i>	Desired to be current (initial) state

7.1.3 Member Function Documentation

7.1.3.1 `default()`

```
def fsm.FsmRobot.default (
    self )
```

Default method of the FSM.

If FSM is initialized properly, this state must not be executed!

7.1.3.2 `switch_state()`

```
def fsm.FsmRobot.switch_state (
    self,
    new_state )
```

Method used for switching between states of the FSM.

Parameters

<i>new_state</i>	State which FSM will switch to
------------------	--------------------------------

7.1.3.3 validate_state()

```
def fsm.FsmRobot.validate_state (
    self,
    state )
```

Method used for state validation.

It basically checks if state is in the list [states_list](#) of predefined states.

Parameters

<i>state</i>	State to be validated
--------------	-----------------------

The documentation for this class was generated from the following file:

- `/home/djordje/catkin_ws/src/ros_diff_drive/scripts/fsm.py`

7.2 fsm.FsmState Class Reference

FSM state class.

Public Member Functions

- `def __init__ (self, state, method)`
Constructor which contains desired state enumerator and method.

Public Attributes

- [state](#)
state which stores enumeration value from [FsmStates](#)
- [method](#)
method which will be executed once this state is ongoing

7.2.1 Detailed Description

FSM state class.

Contains state enumerator defined [FsmStates](#), as well as the method which shall be executed with this state.


The documentation for this class was generated from the following file:

- `/home/djordje/catkin_ws/src/ros_diff_drive/scripts/fsm.py`


7.3 fsm.FsmStates Class Reference

Enumeration containing state machine states definitions.

Inheritance diagram for fsm.FsmStates:



Collaboration diagram for fsm.FsmStates:



Static Public Attributes

- int **Default** = 0
Default state and should not be used by the user.
- int **Idle** = 1
Waiting for a new command.
- int **Rotating** = 2
State for the robot rotation.
- int **Forward** = 3
State for moving forward.

7.3.1 Detailed Description

Enumeration containing state machine states definitions.

FSM states enumeration

7.3.2 Member Data Documentation

7.3.2.1 Default

```
int fsm.FsmStates.Default = 0 [static]
```

Default state and should not be used by the user.

Used only as initial value of previous_state.

The documentation for this class was generated from the following file:

- /home/djordje/catkin_ws/src/ros_diff_drive/scripts/fsm.py

7.4 regulator.Regulator Class Reference

Class of the regulator which contains parameters and methods which implement different control algorithms.

Public Member Functions

- `def __init__ (self, KP, TI, TD, T, u_limit, ui_limit)`
Constructor of the regulator.
- `def update_params (self, KP, TI, TD, ui_limit)`
Method for updating PID parameters.
- `def pid_positional (self, error)`
Positional PID algorithm method.
- `def pid_incremental (self, error)`
Incremental PID algorithm method.

Public Attributes

- `KP`
KP Gain of the PID.
- `KI`
KI Gain of the PID.
- `KD`
KD Gain of the PID.
- `u_limit`
Limit of the overall control output (only for incremental PID)
- `ui_limit`
Limit of the integral controll output (only for positional PID)
- `err_prev`
Error from the previous iteration.
- `err_p_prev`
Error from the iteration before previous one.

- **u**
Calculated control output.
- **T**
Period between two iteration.
- **KDT**
 *$KD * T$ part of the PID calculation.*
- **KIT**
 *$KI * T$ part of the PID calculation.*
- **Ui**
Backup integral output control value.

7.4.1 Detailed Description

Class of the regulator which contains parameters and methods which implement different control algorithms.

7.4.2 Member Function Documentation

7.4.2.1 update_params()

```
def regulator.Regulator.update_params (
    self,
    KP,
    TI,
    TD,
    ui_limit )
```

Method for updating PID parameters.

Note: Should be used during debugging and PID setup Not intended to be used during normal operation because of the runtime consumption.

7.4.3 Member Data Documentation

7.4.3.1 err_p_prev

```
regulator.Regulator.err_p_prev
```

Error from the iteration before previous one.

Backup.

The documentation for this class was generated from the following file:

- /home/djordje/catkin_ws/src/ros_diff_drive/scripts/regulator.py

Index

- `__init__`
 - `fsm.FsmRobot`, [24](#)
- `angle_error_calc`
 - `move_to_point`, [19](#)
- `config`, [15](#)
- `debug`, [16](#)
- `Default`
 - `fsm.FsmStates`, [27](#)
- `default`
 - `fsm.FsmRobot`, [24](#)
- `dyn_reconf_callback`
 - `move_to_point`, [19](#)
- `err_p_prev`
 - `regulator.Regulator`, [28](#)
- `forward`
 - `move_to_point`, [19](#)
- `fsm`, [16](#)
- `fsm.FsmRobot`, [23](#)
 - `__init__`, [24](#)
 - `default`, [24](#)
 - `switch_state`, [24](#)
 - `validate_state`, [24](#)
- `fsm.FsmState`, [25](#)
- `fsm.FsmStates`, [26](#)
 - `Default`, [27](#)
- `goal_position_callback`
 - `move_to_point`, [20](#)
- `idle`
 - `move_to_point`, [20](#)
- `INT_LIMIT_FWD`
 - Pre initial values of PID regulators, [10](#)
- `INT_LIMIT_ROT`
 - Pre initial values of PID regulators, [10](#)
- `KP_FWD`
 - Pre initial values of PID regulators, [10](#)
- `KP_ROT`
 - Pre initial values of PID regulators, [10](#)
- `move_to_point`, [17](#)
 - `angle_error_calc`, [19](#)
 - `dyn_reconf_callback`, [19](#)
 - `forward`, [19](#)
 - `goal_position_callback`, [20](#)
 - `idle`, [20](#)
 - `position_callback`, [20](#)
 - `rotate`, [20](#)
- `P_ANG_DST`
 - Pre initial values of PID regulators, [10](#)
- `P_ANG_THT`
 - Pre initial values of PID regulators, [10](#)
- `P_FWD_CUR`
 - Pre initial values of PID regulators, [11](#)
- `P_FWD_DST`
 - Pre initial values of PID regulators, [11](#)
- `position_callback`
 - `move_to_point`, [20](#)
- Pre initial values of PID regulators, [9](#)
 - `INT_LIMIT_FWD`, [10](#)
 - `INT_LIMIT_ROT`, [10](#)
 - `KP_FWD`, [10](#)
 - `KP_ROT`, [10](#)
 - `P_ANG_DST`, [10](#)
 - `P_ANG_THT`, [10](#)
 - `P_FWD_CUR`, [11](#)
 - `P_FWD_DST`, [11](#)
 - `TD_FWD`, [11](#)
 - `TD_ROT`, [11](#)
 - `TI_FWD`, [11](#)
 - `TI_ROT`, [11](#)
- `regulator`, [21](#)
- `regulator.Regulator`, [27](#)
 - `err_p_prev`, [28](#)
 - `update_params`, [28](#)
- `rotate`
 - `move_to_point`, [20](#)
- `switch_state`
 - `fsm.FsmRobot`, [24](#)
- `TD_FWD`
 - Pre initial values of PID regulators, [11](#)
- `TD_ROT`
 - Pre initial values of PID regulators, [11](#)
- `TI_FWD`
 - Pre initial values of PID regulators, [11](#)
- `TI_ROT`
 - Pre initial values of PID regulators, [11](#)
- `update_params`
 - `regulator.Regulator`, [28](#)
- `validate_state`

fsm.FsmRobot, [24](#)

Values updated during the callback of the odometry, [12](#),
[13](#)

Variables used for debugging purposes, [14](#)