

Legend

ROS Topic Name
(ROS MSG Type)

ROS Node

ATAK Bridge Communication

ATAK Server

Location to move to
(Latitude, Longitude, Hdng, Alt)

Current robot location.
(Latitude, Longitude, Alt)

Current Object location.
(Latitude, Longitude, Alt)

West Point ATAK Extension

atak_bridge

ROS TF

/goal_location

[atak_msgs/PoseDescription]

/robot_location

[atak_msgs/PoseDescription]

/object_location

[atak_msgs/PoseDescription]

Robot Software

Code Running on the Robot



Android Phone Running ATAK

atak_msgs/PoseDescription

Message Definition

std_msgs/Header header

geometry_msgs/Pose pose

std_msgs/String description