

grid

ALT and alt function very similarly:

- they each unlock special functions
- they each apply pad changes to the entire bank,
eg. hold ALT / alt and press C to assign all pads in that bank to use the Clip buffer, then press 3 to assign all pads in that bank to the third Clip

ALT / alt + %f enables pad focus mode:

- selecting a pad will not trigger sound
- you can modify the pad's parameters while another pad plays

ALT / alt + %r creates a random pad pattern:

- patterns are generated based on [timing] page settings

ALT / alt + %1x returns all pads to 1x rate

ALT / alt + arp clears a held arp pattern

ALT + P clears a stored pad pattern

alt + P toggles pad pattern overdub (when playing)

ALT / alt + rec L1 / L2 / L3 erases audio between the specified Live segment's loop points

ALT / alt + arc P1 / P2 / P3 erases a stored arc pattern

ALT + -> cycles to the previous page

[ALT and alt]

B A N K					1	2	3	%f
					L	C	%r	P
					1/1	arp		
					%1x			
				alt				

M	ALT	rec L1	rec L2	rec L3	arc P1	arc P2	arc P3	->
---	-----	--------	--------	--------	--------	--------	--------	----

note:

ALT + alt toggles a special alt-lock mode, where zilchmo functions are applied to all pads in the bank.