

**CONFIDENTIAL**

# Memory Manager for Linux

User's Manual: Software

R-Car H3/M3/M3N/E3 Series

All information contained in these materials, including products and product specifications, represents information on the product at the time of publication and is subject to change by Renesas Electronics Corp. without notice. Please review the latest information published by Renesas Electronics Corp. through various means, including the Renesas Electronics Corp. website (<http://www.renesas.com>).

## Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. Renesas Electronics disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
2. Renesas Electronics hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of Renesas Electronics products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
4. You shall be responsible for determining what licenses are required from any third parties, and obtaining such licenses for the lawful import, export, manufacture, sales, utilization, distribution or other disposal of any products incorporating Renesas Electronics products, if required.
5. You shall not alter, modify, copy, or reverse engineer any Renesas Electronics product, whether in whole or in part. Renesas Electronics disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
6. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The intended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; industrial robots; etc.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control (traffic lights); large-scale communication equipment; key financial terminal systems; safety control equipment; etc.

Unless expressly designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). Renesas Electronics disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any Renesas Electronics product that is inconsistent with any Renesas Electronics data sheet, user's manual or other Renesas Electronics document.

7. No semiconductor product is absolutely secure. Notwithstanding any security measures or features that may be implemented in Renesas Electronics hardware or software products, Renesas Electronics shall have absolutely no liability arising out of any vulnerability or security breach, including but not limited to any unauthorized access to or use of a Renesas Electronics product or a system that uses a Renesas Electronics product. RENESAS ELECTRONICS DOES NOT WARRANT OR GUARANTEE THAT RENESAS ELECTRONICS PRODUCTS, OR ANY SYSTEMS CREATED USING RENESAS ELECTRONICS PRODUCTS WILL BE INVULNERABLE OR FREE FROM CORRUPTION, ATTACK, VIRUSES, INTERFERENCE, HACKING, DATA LOSS OR THEFT, OR OTHER SECURITY INTRUSION ("Vulnerability Issues"). RENESAS ELECTRONICS DISCLAIMS ANY AND ALL RESPONSIBILITY OR LIABILITY ARISING FROM OR RELATED TO ANY VULNERABILITY ISSUES. FURTHERMORE, TO THE EXTENT PERMITTED BY APPLICABLE LAW, RENESAS ELECTRONICS DISCLAIMS ANY AND ALL WARRANTIES, EXPRESS OR IMPLIED, WITH RESPECT TO THIS DOCUMENT AND ANY RELATED OR ACCOMPANYING SOFTWARE OR HARDWARE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE.
8. When using Renesas Electronics products, refer to the latest product information (data sheets, user's manuals, application notes, "General Notes for Handling and Using Semiconductor Devices" in the reliability handbook, etc.), and ensure that usage conditions are within the ranges specified by Renesas Electronics with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. Renesas Electronics disclaims any and all liability for any malfunctions, failure or accident arising out of the use of Renesas Electronics products outside of such specified ranges.
9. Although Renesas Electronics endeavors to improve the quality and reliability of Renesas Electronics products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Unless designated as a high reliability product or a product for harsh environments in a Renesas Electronics data sheet or other Renesas Electronics document, Renesas Electronics products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of Renesas Electronics products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using Renesas Electronics products in compliance with all these applicable laws and regulations. Renesas Electronics disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. Renesas Electronics products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
12. It is the responsibility of the buyer or distributor of Renesas Electronics products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
13. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
14. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products.

(Note1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its directly or indirectly controlled subsidiaries.

(Note2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.

(Rev.5.0-1 October 2020)

## Corporate Headquarters

TOYOSU FORESIA, 3-2-24 Toyosu,  
Koto-ku, Tokyo 135-0061, Japan

[www.renesas.com](http://www.renesas.com)

## Trademarks

Renesas and the Renesas logo are trademarks of Renesas Electronics Corporation. All trademarks and registered trademarks are the property of their respective owners.

## Contact information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:  
[www.renesas.com/contact/](http://www.renesas.com/contact/).

# CONFIDENTIAL

## Trademark

- Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries.
- Arm is a registered trademark of Arm Limited (or its subsidiaries) in the US and/or elsewhere.
- Other company names and product names mentioned herein are registered trademarks or trademarks of their respective owners.
- Registered trademark and trademark symbols (® and ™) are omitted in this document

# CONFIDENTIAL

## How to Use This Manual

### Purpose and Target Readers

This manual is designed to provide the user with an understanding the functions of Memory Manager for Linux. This manual is written for engineers who use Memory Manager.

Particular attention should be paid to the precautionary notes when using the manual. These notes occur within the body of the text, at the end of each section, and in the Usage Notes section.

The revision history summarizes the locations of revisions and additions. It does not list all revisions. Refer to the text of the manual for details.

Please refer to documents of software and hardware for a target system implementing Memory Manager as necessary. The following documents are related documents. Make sure to refer to the latest versions of these documents. The newest versions of the documents listed may be obtained from the Renesas Electronics Web site.

Document Type	Description	Document Title	Notes
User's manual for Hardware	Hardware specifications (pin assignments, memory maps, peripheral function specifications, electrical characteristics, timing charts) and operation description Note: Refer to the application notes for details on using peripheral functions.	R-Car Series, 3 <sup>rd</sup> Generation User's Manual: Hardware	
User's manual for Software	Description of Memory Manager	Memory Manager for Linux	This manual

# CONFIDENTIAL

## Notation of Numbers and Symbols

This manual uses following notation.

Binary	0bXXXXXXXX (X=0 or 1)
Decimal	XXX (X=0-9)
Hex	0xXXXXXXXX (X=0-9,A-F)

# CONFIDENTIAL

## List of Abbreviations and Acronyms

Abbreviation	Full Form
MMNGR	Memory Manager
CMA	Contiguous Memory Allocator
DTV	Digital Terrestrial Television
SSP	Stream processor
MMP	Multimedia Package
VSP	Video Signal Processor
FDP	Fine Display Processor
FCP	Frame Compression Processor
FCPV	FCP for VSP
FCPF	FCP for FDP
FCNL	Near lossless data compression
IPL	Initial Program Loader

## List of Terminologies

Terms	Explanation
Lossy	FCNL offered by FCPV and FCPF
MMU	Memory Management Unit
IPMMU	MMU for IP
PMB	Privileged space Mapping Buffer

All trademarks and registered trademarks are the property of their respective owners.

# CONFIDENTIAL

## Table of Contents

<b>1.Overview .....</b>	<b>1</b>
1.1 Overview of this Software .....	1
1.2 Configuration of this Software .....	1
1.3 Development Environments .....	4
1.3.1 Hardware Development Environment .....	4
1.3.2 Software Development Environment .....	4
<b>2.Installation Procedures .....</b>	<b>5</b>
2.1 Building the shared library .....	5
2.2 Building the Kernel image and the Kernel module .....	6
2.3 Storing the shared library, the Kernel module and Kernel image. ....	8
2.4 Device tree configuration .....	9
<b>3.Module Configuration .....</b>	<b>10</b>
<b>4.List of API .....</b>	<b>12</b>
<b>5.Sample Sequence .....</b>	<b>13</b>
<b>6.API Specification .....</b>	<b>15</b>
6.1 Allocate Memory Space .....	15
6.2 Free Memory Space .....	18
6.3 Map the Address for H/W IP to the User Space (Debug API) .....	19
6.4 Unmap the Mapping Space (Debug API) .....	21
6.5 Start the export of dmabuf fd .....	22
6.6 End the export of dmabuf fd .....	24
6.7 Start the import of dmabuf fd .....	25
6.8 End the import of dmabuf fd .....	26
<b>7.Header Files .....</b>	<b>27</b>
<b>8.Definition .....</b>	<b>28</b>
8.1 Structure .....	28
8.1.1 Lossy support structure .....	28
8.2 Macros .....	29
8.2.1 Return Value Definition .....	29
8.2.2 Parameter Definition .....	29
8.2.3 Parameter Definition for Lossy mem allocation .....	29
<b>9.Restrictions and Notices .....</b>	<b>30</b>
9.1 Restrictions .....	30
9.2 Notices .....	30
<b>10.Appendix .....</b>	<b>31</b>
10.1 Legacy API .....	31
10.2 Relationship between mem_param and Lossy mem return value .....	32
10.3 IPMMU MMU support .....	33
10.3.1 Enable IPMMU MMU support .....	33
10.3.2 Map CMA areas to IPMMU virtual address space .....	36

10.3.3	Sample memory map.....	38
--------	------------------------	----



## 1. Overview

### 1.1 Overview of this Software

- To bring out the performance of the multimedia H/W IP, the following features for the memory space are required.
  - (1) Not only the space reserved as default CMA area, which is shared by H/W IP and CPU, but also the space reserved as CMA area for MMP, which is used by H/W IP (Video Codec IP) only.
  - (2) The space reserved as CMA area for Lossy compression feature, which is used by HW IP (FDP, VSPI and VSPB).
  - (3) The larger contiguous space.
  - (4) The space reserved as some CMA areas can be located in 32-bit physical address space (legacy area) or 40-bit physical address space (with IPMMU MMU support).
- Therefore Memory Manager (hereafter called in MMNGR) provides the following memory space.
  - (1) The space reserved as default CMA area, which is shared by H/W IP and CPU.
  - (2) The space reserved as CMA area for MMP, which is used by H/W IP (Video Codec IP) only.
  - (3) The space reserved as CMA area for Lossy compression feature, which is used by H/W IP (FDP, VSPI and VSPB).
  - (4) The physical contiguous space over 4MB as reserved CMA area by one allocation request.
  - (5) The physical contiguous space (e.g. the space reserved as CMA area for MMP) can be assigned into 32-bit address space or 40-bit address space.
- MMNGR does not support to provide above memory space directly to Linux Kernel Display Driver via DMA buffer sharing.
- The APIs are provided in the user layer.

### 1.2 Configuration of this Software

This software consists of the following resources.

- Document
- Source code
- Sample application
- Makefile

To use this software, the following additional software, which is not included in this software, is required. Details of this additional software are shown below.

- Kernel module source code
  - This software is distributed in Dual MIT/GPLv2 licenses.
  - Figure 1-2 shows the lists of these source files.





Figure 1-1 Configuration of this software



**Figure 1-2 Kernel module source code not included in this software**

### 1.3 Development Environments

This section describes the development environments for this software.

#### 1.3.1 Hardware Development Environment

**Table 1-1 Hardware specification**

Hardware Name		Remarks
Device	R-Car H3 / M3 / M3N / E3	-
Board	R-CarH3-SiP/M3-SiP System Evaluation Board Salvator-X	-
Board	R-CarH3-SiP/M3-SiP/M3N-SiP System Evaluation Board Salvator-XS	-
Board	R-CarE3 System Evaluation Board Ebisu	-
Board	R-CarE3 System Evaluation Board Ebisu-4D	

#### 1.3.2 Software Development Environment

**Table 1-2 Software specification**

Software Name	Version / Revision	Remarks
R-Car H3/M3/M3N/E3 Linux BSP	-	-

## **2. Installation Procedures**

### **2.1 Building the shared library**

The following item is the procedure for building the shared library of this software.

#### **1) Setting environment variables**

The shared library must be 64-bit version. Follow Yocto Recipe Start-Up Guide to set up the 64-bit SDK.

```
$ source <Yocto SDK script>
```

In addition to the guide, set the following value

```
$ export INCSHARED=$SDKTARGETSYSROOT/usr/local/include
```

#### **2) Building the shared library**

Execute make under libmmngr/mmngr/.

```
$ cd libmmngr/mmngr
$ autoreconf -i
$ ./configure ${CONFIGURE_FLAGS} --prefix=$PWD/tmp
$ make
$ make install includedir=$INCSHARED
```

Note that the CONFIGURE\_FLAGS variable was already set by SDK. Do not overwrite it.

#### **3) Verifying the shared library**

Make sure that the following shared libraries are built under libmmngr/mmngr/tmp/lib.

libmmngr.so.x.x.x ("x.x.x" depends on the version.)

In addition, if you use the dmabuf function of MMNGR, follow 4) and 5).

#### **4) Building the shared library**

Execute make under libmmngr/mmngrbuf.

```
$ cd libmmngr/mmngrbuf/
$ autoreconf -i
$ ./configure ${CONFIGURE_FLAGS} --prefix=$PWD/tmp
$ make
$ make install includedir=$INCSHARED
```

Note that the CONFIGURE\_FLAGS variable was already set by SDK. Do not overwrite it.

#### **5) Verifying the shared library**

Make sure that the following shared libraries are built under libmmngr/mmngrbuf/tmp/lib.

libmmngrbuf.so.x.x.x ("x.x.x" depends on the version.)

## 2.2 Building the Kernel image and the Kernel module

The following is the procedure for building the kernel image and the kernel module that is not included in this software.

The procedure is described for default memory map configuration that all CMA areas are located in 32-bit legacy area. For customized memory map, which moves CMA area for MMP to 40-bit address space, refer to 10.3 for more details.

### 1) Setting environment variables

The kernel module is always 64-bit. Please use 64-bit SDK when compiling kernel module.

To set up SDK, follow Yocto Recipe Start-Up Guide.

```
$ source <Yocto SDK script>
```

In addition to the guide, set the following value.

```
$ export KERNELSRC=(the kernel path in your environment) (for example, $WORK/renesas-bsp)
$ export CP=cp
$ export MMNGR_CONFIG=MMNGR_SALVATORX (*)
$ export MMNGR_SSP_CONFIG=MMNGR_SSP_DISABLE
$ export MMNGR_IPMMU_MMU_CONFIG=IPMMU_MMU_DISABLE
$ export MMNGR_VALIDATE_CONFIG="MMNGR_ADDRESS_VALIDATION"
$ export INCSHARED=$SDKTARGETSYSROOT/usr/local/include
```

\*: This definition depends on your environment

In case target SoCs are H3, M3, M3N, please set as following value:

```
$ export MMNGR_CONFIG=MMNGR_SALVATORX
```

In case target SoC is E3, please set as following value:

```
$ export MMNGR_CONFIG=MMNGR_EBISU
```

### 2) Building the Kernel image

MMNGR uses CMAs (Contiguous Memory Allocator) of the kernel image.

If you change the size of the spaces, perform the following steps.

If you don't need to change them, follow Step.3 only.

#### Step.1

Modify the start address and size of default CMA area (Refer to Yocto Recipe Start-Up Guide).

#### Step.2

Modify the start address and size of CMA area for MMP under node linux,multimedia in device tree

arch/arm64/boot/dts/renesas/xxxx.dts. (H3 Ver.1.x: xxxx.dts means r8a77950-salvator-x.dts, r8a77951-salvator-x.dts, r8a77951-salvator-xs.dts, r8a77951-salvator-xs-4x2g.dts, H3 Ver.2.0: xxxx.dts means r8a77951-salvator-x.dts, r8a77951-salvator-xs.dts, r8a77951-salvator-xs-4x2g.dts, H3 Ver.3.0: xxxx.dts means r8a77951-salvator-x.dts, r8a77951-salvator-xs.dts, r8a77951-salvator-xs-4x2g.dts, M3 Ver.1.x: xxxx.dts means r8a77960-salvator-x.dts, r8a77960-salvator-xs.dts, r8a77960-salvator-xs-4x2g.dts, M3 Ver.2.0: xxxx.dts means r8a77960-salvator-x.dts, r8a77960-salvator-xs.dts, r8a77960-salvator-xs-4x2g.dts, M3 Ver.3.0: xxxx.dts means r8a77961-salvator-x.dts, r8a77961-salvator-xs.dts, r8a77961-salvator-xs-4x2g.dts, M3N : xxxx.dts means r8a77965-salvator-x.dts, r8a77965-salvator-xs.dts, r8a77965-salvator-xs-4x2g.dts, E3 Ver.1.0: xxxx.dts means r8a77990-es10-ebisu.dts, r8a77990-es10-ebisu-4d.dts, r8a77990-es10-ebisu-4d.dts, E3 Ver.1.1: xxxx.dts means r8a77990-es10-ebisu.dts, r8a77990-es10-ebisu-4d.dts, r8a77990-es10-ebisu-4d.dts)

```
mmp_reserved: linux,multimedia@XXXXXXXX {
    compatible = "shared-dma-pool";
    reusable;
    reg = <0x00000000 0xXXXXXXXX 0x0 0xYYYYYYYY>;
};
```

0xXXXXXXXX is start address of CMA area and set to the same value as MM\_OMXBUF\_ADDR.

0xYYYYYYYY is size of CMA area and set to the same value as MM\_OMXBUF\_SIZE.

#### Step.3

Build the kernel image by Yocto bitbake command. Follow Yocto Recipe Start-up Guide to set up Yocto environment.

```
$ bitbake linux-renesas -c compile -f
```

### 3) Building the kernel module

About the space reserved as CMA area for MMP, MMNGR uses MM\_OMXBUF\_ADDR as the start address, and uses MM\_OMXBUF\_SIZE as the size.

If you change the start address or the size of the space reserved as CMA area for MMP, perform the following steps.

If you don't need to change the values, follow Step.2 only.

#### Step.1

Modify the definition in `mmngr_private.h`.  
MM\_OMXBUF\_ADDR => the start address of OMXBUF  
Set the address aligned on 4KB.  
MM\_OMXBUF\_SIZE => the size of OMXBUF.  
Set the size aligned on 4KB.

**Step.2**

Execute make under `mmngr_drv/mmngr/mmngr-module/files/mmngr/drv`.  
`cd mmngr_drv/mmngr/mmngr-module/files/mmngr/drv`  
`$ make`

In addition, please note that E3 does not support DTV (SSP).  
Therefore, the space reserved as CMA area for MMP for DTV (SSP) is not available on E3.

For other SoCs, if you want to use the space reserved as CMA area for MMP for DTV (SSP), perform the following steps.  
About the space reserved as CMA area for MMP for DTV (SSP),  
MMNGR uses MM\_SSPBUF\_ADDR as the start address, and uses MM\_SSPBUF\_SIZE as the size.  
If you don't need to change the values, follow Step.3 only.

**Step.1**

Add the definition for DTV (SSP).  
`$ export MMNGR_SSP_CONFIG=MMNGR_SSP_ENABLE`

**Step.2**

Modify the definition in `mmngr_private.h`.  
MM\_SSPBUF\_ADDR => the start address of SSPBUF.  
Set the address aligned on 4KB.  
MM\_SSPBUF\_SIZE => the size of SSPBUF.  
Set the size aligned on 4KB.

**Note)**

You should change to the proper values in accordance with your DVD solution.  
In addition, don't include 1GB order from MM\_SSPBUF\_ADDR to (MM\_SSPBUF\_ADDR + MM\_SSPBUF\_SIZE - 1).  
Don't overlap the area of OMXBUF, if you use SSPBUF.

**Step.3**

Execute make under `mmngr_drv/mmngr/mmngr-module/files/mmngr/drv`.  
`$ cd mmngr_drv/mmngr/mmngr-module/files/mmngr/drv`  
`$ make`

Set OMXBUF and SSPBUF you use within CMA area for MMP.  
Set the total size of OMXBUF and SSPBUF within the size of CMA area for MMP describing under node `linux,multimedia` in device tree.

**4) Verifying the kernel image and the kernel module**

Make sure that the following kernel image is created at folder `$KERNELSRC/arch/arm64/boot`.

Image

Make sure that the following kernel module is built under `mmngr_drv/mmngr/mmngr-module/files/mmngr/drv`.

`mmngr.ko`

In addition, if you use the `dmabuf` function of MMNGR, follow 5) and 6).

**5) Building the kernel module**

Execute make under `mmngr_drv/mmngrbuf/mmngrbuf-module/files/mmngrbuf/drv`  
`$ cd mmngr_drv/mmngrbuf/mmngrbuf-module/files/mmngrbuf/drv`  
`$ make`

**6) Verifying the kernel module**

Make sure that the following kernel module is built under `mmngr_drv/mmngrbuf/mmngrbuf-module/files/mmngrbuf/drv`.  
`mmngrbuf.ko`





**2.3 Storing the shared library, the Kernel module and Kernel image.**

The following procedure shows the steps storing the shared library, the kernel module and Kernel image that are built at 2.1. and 2.2.

**1) Storing the shared library**

For 64-bit shared library, store libmmngr.so.x.x.x under /usr/lib in the rootfs of the target board.

```
$ cp libmmngr.so.x.x.x (the rootfs of the target board)/usr/lib
```

**2) Storing the kernel module**

Store the kernel module under the directory in the rootfs of the target board.

```
$ mkdir /tmp (/tmp is an example. Therefore change the directory according to your environment.)
```

```
$ cp mmngr.ko /tmp
```

**3) Storing Kernel image**

Store Kernel image (i.e. Image) in the target board according to the Yocto Recipe Start-up guide.

**4) Copying the link to the target rootfs**

Copy the links to the target rootfs of the target board at PC.

For 64-bit shared library,

```
$ cp -d libmmngr.so.x (the rootfs of the target board)/usr/lib
```

```
$ cp -d libmmngr.so (the rootfs of the target board)/usr/lib
```

**5) Install the kernel module at the target board.**

Execute insmod under the directory storing the kernel module at the target board.

```
$ cd /tmp
```

```
$ insmod mmngr.ko
```

In addition, if you use the dmabuf function of MMNGR, follow from 6) to 9).

**6) Storing the shared library.**

For 64-bit shared library, store libmmngrbuf.so.x.x.x under /usr/lib in the rootfs of the target board.

```
$ cp libmmngrbuf.so.x.x.x (the rootfs of the target board)/usr/lib
```

**7) Storing the kernel module.**

Store the kernel module under the directory in the rootfs of the target board.

```
$ cp mmngrbuf.ko /tmp (/tmp is an example. Therefore change the directory according to your environment.)
```

**8) Copying the link to the target rootfs.**

Copy the links to the target rootfs of the target board at PC.

For 64-bit shared library,

```
$ cp -d libmmngrbuf.so.x (the rootfs of the target board)/usr/lib
```

```
$ cp -d libmmngrbuf.so (the rootfs of the target board)/usr/lib
```

**9) Install the kernel module at the target board.**

Execute insmod under the directory storing the kernel module at the target board.

```
$ cd /tmp
```

```
$ insmod mmngrbuf.ko
```

## 2.4 Device tree configuration

Below describes the information of MMNGR nodes in device tree.

1) For MMNGR

**Table 2-1 Information of MMNGR node in device tree**

Name	Contents
compatible	Should contain "renesas,mmngr". It's compatible string for MMNGR kernel module.
memory-region	Should contain "&mmp_reserved" to explicitly assign CMA area for MMP to MMNGR kernel module.  Should contain "&lossy_decompress" to explicitly assign CMA area for Lossy to MMNGR kernel module.

2) For MMNGRBUF

**Table 2-2 Information of MMNGRBUF node in device tree**

Name	Contents
compatible	Should contain "renesas,mmngrbuf". It's compatible string for MMNGRBUF kernel module.

### 3. Module Configuration

The module configuration of MMNGR is as follows.





Figure 3-1 MMNGR module configuration

- MMNGR consists of the interface layer and the driver layer.
  - Interface Layer (in this software)
    - This layer is in the user space and provides API.
  - Driver Layer (out of this software)
    - This layer is in the kernel space and calls the kernel API.
- The execution context of MMNGR is the process or the thread calling MMNGR.
  - That is, MMNGR does not have the process and the thread.

The module configuration of the dmabuf function of MMNGR is as follows.

The modules of the dmabuf function are independent from the above modules.



**Figure 3-2 MMNGR (DMABUF function) module configuration**

- MMNGR consists of the interface layer and the driver layer.
  - Interface Layer (in this software)
    - This layer is in the user space and provides API.
  - Driver Layer (out of this software)
    - This layer is in the kernel space and calls the kernel API.
- The execution context of MMNGR is the process or the thread calling MMNGR.  
That is, MMNGR does not have the process and the thread.

**4. List of API****Table 4-1 List of API**

No	Name	Function
1	mmngr_alloc_in_user_ext()	Allocate the memory space
2	mmngr_free_in_user_ext()	Free the memory space
3	mmngr_debug_map_va_ext()	Map the memory space for H/W IP to the user space. (Debug API for the space reserved as CMA area for MMP)
4	mmngr_debug_unmap_va_ext()	Unmap the memory space mapped to the user space (Debug API for the space reserved as CMA area for MMP)
5	mmngr_export_start_in_user_ext()	Start the export of dmabuf fd.
6	mmngr_export_end_in_user_ext()	End the export of dmabuf fd.
7	mmngr_import_start_in_user_ext()	Start the import of dmabuf fd.
8	mmngr_import_end_in_user_ext()	End the import of dmabuf fd.

5. Sample Sequence




Figure 5-1 MMNGR sample sequence

If you use the dmabuf function of MMNGR, sample sequence is as follows.




Figure 5-2 MMNGR (DMABUF function) sample sequence

## 6. API Specification

### 6.1 Allocate Memory Space

#### **Name**

mmngr\_alloc\_in\_user\_ext

#### **Synopsis**

```
int mmngr_alloc_in_user_ext(
    MMNGR_ID *pid,           (output)
    size_t size,             (input)
    unsigned int *phard_addr, (output)
    void **puser_virt_addr,  (output)
    unsigned int flag,        (input)
    void *mem_param          (input and output)
)
```

#### **Arguments**

MMNGR_ID *pid	The address storing the id of the allocated memory
size_t size	The size of the allocation [Byte]
unsigned int *phard_addr	The address storing the address for H/W IP of the allocated memory.
	It is a virtual address for H/W IP, not actual physical address when IPMMU MMU support is enabled.
void **puser_virt_addr	The address storing the address for CPU of the allocated memory
unsigned int flag	The flag to select the target of the allocation.
	MMNGR_VA_SUPPORT
	The space reserved as default CMA area
	MMNGR_PA_SUPPORT
	The space reserved as CMA area for MMP
	MMNGR_PA_SUPPORT_SSP
	The space reserved as CMA area for MMP for DTV (SSP)
	(This definition is valid, only when MMNGR_SSP_ENABLE is defined.)
	MMNGR_PA_SUPPORT_LOSSY
	The space reserved as CMA area for Lossy Decompression feature.
void *mem_param	The address storing the data buffer, which contains detail information of Lossy memory allocation, request and status of Lossy support.
	The data buffer is a variable with type MM_FUNC struct.

#### **Struct**

-

#### **Return Value**



R_MM_OK	Normal End
R_MM_FATAL	Fatal Error
R_MM_PARE	Parameter Error
	(Condition)
	(1) When an application sets NULL to <i>pid</i> , <i>phard_addr</i> or <i>puser_virt_addr</i> .
	(2) When an application sets 0 to <i>size</i> .
	(3) When an application sets the undefined value at <i>flag</i> .
	(4) When <i>flag</i> is MMNGR_PA_SUPPORT_LOSSY and <i>mem_param</i> is NULL.
	(5) When <i>flag</i> is MMNGR_PA_SUPPORT_LOSSY and content of data buffer pointed by <i>mem_param</i> contains undefined value or unsupported value. Refer to 10.2 for more details.
R_MM_NOMEM	Lack of Memory
	(Condition)
	When MMNGR cannot allocate the space according to <i>size</i> .

### Description

- (1) This function allocates the memory space according to *size*. If *flag* is MMNGR\_PA\_SUPPORT\_LOSSY, the allocation will also refer to *mem\_param*.
- (2) The allocated size is rounded up to 4KB alignment.
- (3) The alignment of the address pointed by *phard\_addr* and *puser\_virt\_addr* is 4KB.
- (4) This function allocates the memory space with CMA.  
According to the specification of CMA, the allocation time may be long, and the size of the total allocation may be smaller than the CMA size defined in device tree.
- (5) MMNGR does not have the defragmentation.
- (6) Only when MMNGR\_VA\_SUPPORT is set to *flag*, the address is set to *puser\_virt\_addr*.
- (7) The space pointed by *puser\_virt\_addr* is the user space and the **non-cache space**.

### Notes

- (1) Allocate the space set to *pid*, *phard\_addr* and *puser\_virt\_addr* in the application.  
The type of the space set to *pid* is MMNGR\_ID.

Example

```
MMNGR_ID id;
unsigned int hard_addr;
void *user_virt_addr;
unsigned int flag = MMNGR_VA_SUPPORT;
mmngr_alloc_in_user_ext(&id, 64 * 1024, &hard_addr,
                        &user_virt_addr, flag, NULL);
```

- (2) Align the address pointed by *phard\_addr* and set the aligned address to H/W IP.
- (3) Set the address *puser\_virt\_addr* to CPU.
- (4) Use the address pointed by *puser\_virt\_addr* in the same process calling this API.
- (5) This function wastes one file descriptor per one allocation.

Therefore, decide the number of the allocation within the maximum of the file descriptor per one process in the application.

- (6) Don't refer to the address pointed by *puser\_virt\_addr*, when the space is allocated with MMNGR\_PA\_SUPPORT, MMNGR\_PA\_SUPPORT\_SSP or MMNGR\_PA\_SUPPORT\_LOSSY.
- (7) Use valid *mem\_param* for Lossy mem allocation. Information about supported Lossy format will be written into buffer pointed by *mem\_param*.

Example

```
unsigned int flag = MMNGR_PA_SUPPORT_LOSSY;
unsigned int conf;
struct MM_FUNC mem_param;
mem_param.func = MM_FUNC_LOSSY_ENABLE;
mem_param.type = MM_FUNC_TYPE_LOSSY_AREA;
mem_param.attr = MM_FUNC_FMT_LOSSY_YUVPLANAR;
mem_param.conf = &conf;
mmngr_alloc_in_user_ext(&id, 64 * 1024, &hard_addr,
                        &user_virt_addr, flag, &mem_param);
if (mem_param.conf == MM_FUNC_STAT_LOSSY_SUPPORT)
    /* Use the allocated mem in hard_addr */
```

- (8) Map the address to the user space with *mmngr\_debug\_map\_va\_ext()* and unmap the mapped address with *mmngr\_debug\_unmap\_va\_ext()*, when you want to refer to the space allocated with MMNGR\_PA\_SUPPORT or MMNGR\_PA\_SUPPORT\_SSP or MMNGR\_PA\_SUPPORT\_LOSSY in the debug.
- (9) Don't call this API at the context of a signal handler.
- (10) Use the address allocated with MMNGR\_PA\_SUPPORT\_SSP to set to DTV (SSP) only.  
That is, use the address allocated with MMNGR\_PA\_SUPPORT\_SSP for the buffer of DTV DEMUX IP only.
- (11) When a device (FDP or VSPI or VSPB) enables Lossy compression feature, a compressed data is required to be stored in a buffer allocated with MMNGR\_PA\_SUPPORT\_LOSSY.  
In addition to this, the image format of a compressed data is required to be equivalent to that of the allocated buffer.
- (12) When IPMMU MMU is enabled, returned value at *phard\_addr* argument is not actual physical address as CPU view. Instead, the address is virtual address for H/W IP. Especially, if flag is set to MMNGR\_PA\_SUPPORT, the virtual address is equal to actual physical address.

**See Also**

-

## 6.2 Free Memory Space

### **Name**

mmngr\_free\_in\_user\_ext

### **Synopsis**

```
int mmngr_free_in_user_ext(
    MMNGR_ID id          (input)
)
```

### **Arguments**

MMNGR_ID <i>id</i>	ID of the allocated memory to be freed.
--------------------	---

### **Struct**

-

### **Return Value**

R_MM_OK	Normal End
R_MM_FATAL	Fatal Error
R_MM_SEQE	Sequence Error (Condition)
	When the space of ID has already been freed. Parameter Error
R_MM_PARE	(Condition)
	(1) When the space of ID has undefined flag value.

### **Description**

(1) This function frees the space of ID.

### **Notes**

- (1) Set ID, which is allocated by mmngr\_alloc\_in\_user\_ext() and is not freed, to *id*.
- (2) Don't call this API at the context of a signal handler.

### **See Also**

-

### 6.3 Map the Address for H/W IP to the User Space (Debug API)

#### Name

mmngr\_debug\_map\_va\_ext

#### Synopsis

```
int mmngr_debug_map_va_ext(
    MMNGR_ID *pid,           (output)
    size_t size,             (input)
    unsigned int hard_addr,   (input)
    void **puser_virt_addr    (output)
    void *mem_param          Do not use
)
```

#### Arguments

MMNGR_ID *pid	The address storing the id of the mapping space
size_t size	The size of the mapping space [Byte]
unsigned int hard_addr	The address for H/W IP to map to the user space. It is a virtual address for H/W IP, not actual physical address when IPMMU MMU support is enabled.
void **puser_virt_addr	The address storing the address for CPU
void *mem_param	Do not use

#### Struct

-

#### Return Value

R_MM_OK	Normal End
R_MM_FATAL	Fatal Error
R_MM_PARE	Parameter Error (Condition) (1) When the application sets NULL to <i>pid</i> or <i>user_virt_addr</i> . (2) When the application sets 0 to <i>size</i> .

#### Description

- (1) This function maps the address for H/W IP to the user space according to *size* and *hard\_addr*.
- (2) The size of the mapping is rounded up to 4KB.
- (3) The alignment of the address pointed by *puser\_virt\_addr* is 4KB.
- (4) The space pointed by *puser\_virt\_addr* is the user space and the **non-cache space**.

#### Notes

- (1) Don't use this function except for the debug.
- (2) Allocate the space set to *pid* and *puser\_virt\_addr* in the application.  
The type of the space set to *pid* is MMNGR\_ID.
- (3) Set *size* and *phard addr* of the space allocated by `mmngr_alloc_in_user_ext()` with MMNGR\_PA\_SUPPORT or MMNGR\_PA\_SUPPORT\_SSP or MMNGR\_PA\_SUPPORT\_LOSSY to *size* and *hard\_addr*.

- (4) Use the address pointed by *puser\_virt\_addr* in the same process calling this API.
- (5) This function wastes one file descriptor per one allocation. Therefore, decide the number of the allocation within the maximum of the file descriptor per one process in the application.
- (6) Don't call this API at the context of a signal handler.
- (7) When IPMMU MMU is enabled, the address in *hard\_addr* will be converted to actual physical address before creating the user space mapping. Therefore, the userspace access can be done normally.

**See Also**

-

## 6.4 Unmap the Mapping Space (Debug API)

### **Name**

mmngr\_debug\_unmap\_va\_ext

### **Synopsis**

```
int mmngr_debug_unmap_va_ext(
    MMNGR_ID id          (input)
)
```

### **Arguments**

MMNGR_ID <i>id</i>	ID of the unmapping space
--------------------	---------------------------

### **Struct**

-

### **Return Value**

R_MM_OK	Normal End
R_MM_FATAL	Fatal Error
R_MM_SEQE	Sequence Error
	(Condition)
	When the space of ID has already been unmapped.

### **Description**

(1) This function unmaps the space of ID.

### **Notes**

- (1) Don't use this function except for the debug.
- (2) Set ID, which is mapped by mmngr\_debug\_map\_va\_ext() and is not unmapped, to *id*.
- (3) Don't call this API at the context of a signal handler.

### **See Also**

-

## 6.5 Start the export of dmabuf fd

### Name

mmngr\_export\_start\_in\_user\_ext

### Synopsis

```
int mmngr_export_start_in_user_ext(
    int *pid,                (output)
    size_t size,             (input)
    unsigned int hard_addr,  (input)
    int *pbuf                (output)
    void *mem_param          Do not use
)
```

### Arguments

int *pid	The address storing the id of the export.
size_t size	The size to connect to dmabuf fd
unsigned int hard_addr	The address for H/W IP to connect to dmabuf fd
	It is a virtual address for H/W IP, not actual physical address when IPMMU MMU support is enabled.
int *pbuf	The address storing dmabuf fd
void *mem_param	Do not use

### Struct

-

### Return Value

R_MM_OK	Normal End
R_MM_FATAL	Fatal Error
R_MM_PARE	Parameter Error
	(Condition)
	(1) When an application sets NULL to <i>pid</i> or <i>pbuf</i> .
	(2) When an application sets 0 to <i>size</i> .

### Description

(1) This function allocates dmabuf fd from the address and the size of the memory space.

### Notes

- (1) Allocate the space set to *pid* and *pbuf* in the application.
- (2) Set the size of the space, which is allocated by `mmngr_alloc_in_user_ext()` and is not freed, to *size*.
- (3) Set the address of the space, which is allocated by `mmngr_alloc_in_user_ext()` and is not freed, to *hard\_addr*.
- (4) Set the size aligned by 4KB to *size*
- (5) Set the address aligned by 4KB to *hard\_addr*.
- (6) This function wastes two file descriptors per one export.  
One is used for ID. The other is used for dmabuf fd.

Therefore, decide the number of the allocation within the maximum of the file descriptor per one process in the application.

- (7) Use dmabuf fd pointed by *pbuf* in the same process calling this API.
- (8) Don't access the space pointed by *hard\_addr* with CPU
- (9) Don't call this API at the context of a signal handler.
- (10) Don't free the space to set to *size* and *hard\_addr* until *mmngr\_export\_end\_in\_user\_ext()* finishes.
- (11) Don't execute *mmap()* for dmabuf fd pointed by *pbuf*.

**See Also**

-



## 6.6 End the export of dmabuf fd

### **Name**

mmngr\_export\_end\_in\_user\_ext

### **Synopsis**

```
int mmngr_export_end_in_user_ext(
    int id                                (input)
)
```

### **Arguments**

int <i>id</i>	ID of export ended
---------------	--------------------

### **Struct**

-

### **Return Value**

R_MM_OK	Normal End
R_MM_FATAL	Fatal Error

### **Description**

(1) This function frees dmabuf fd for id.

### **Notes**

- (1) Set ID, which is started by mmngr\_export\_start\_in\_user\_ext() and is not ended, to *id*.
  - (2) Don't set ID for the dmabuf fd, while dmabuf fd is imported.
  - (3) Don't call this API at the context of a signal handler.
  - (4) In "End the export of dmabuf fd" process, DMA Buffer Sharing framework will call dmabuf\_release() to free the memory allocated for dmabuf only when the refcount becomes 0. The buffer will not be freed by MNGRBUF API (dmabuf\_release() function) but by MMNGR API instead (mmngr\_free\_in\_user\_ext() function) since MMNGR is the one allocated the buffer. Please refer Figure 5.2 for a sample sequence.
- If user allocated the buffer via their own API, please free the memory allocated for dmabuf after "End the export of dmabuf fd" process .

### **See Also**

-

## 6.7 Start the import of dmabuf fd

### Name

mmngr\_import\_start\_in\_user\_ext

### Synopsis

```
int mmngr_import_start_in_user_ext(
    int *pid,                (output)
    size_t *psize,           (output)
    unsigned int *phard_addr, (output)
    int buf                  (input)
    void *mem_param          Do not use
)
```

### Arguments

int *pid	The address storing the id of the import.
size_t *psize	The address storing the size connected to dmabuf fd
unsigned int *phard_addr	The address storing the address for H/W IP connected to dmabuf fd.
	It is a virtual address for H/W IP, not actual physical address when IPMMU MMU support is enabled.
int buf	dmabuf fd
void *mem_param	Do not use

### Struct

-

### Return Value

R_MM_OK	Normal End
R_MM_FATAL	Fatal Error
R_MM_PARE	Parameter Error
	(Condition)
	(1) When an application sets NULL to pid, psize or phard_addr.

### Description

(1) This function gets the address and the size of the memory space from dmabuf fd.

### Notes

- (1) Set the dmabuf fd, which is started by mmngr\_export\_start\_in\_user\_ext() and is not ended, to *buf*.
- (2) Set the dmabuf fd, which is exported by the other software and is not closed, to *buf*.
- (3) Set the dmabuf fd connected to one physical contiguous space only.
- (4) Don't call this API at the context of a signal handler.

### See Also

-

## **6.8 End the import of dmabuf fd**

### ***Name***

mmngr\_import\_end\_in\_user\_ext

### ***Synopsis***

```
int mmngr_import_end_in_user_ext(
    int id                (input)
)
```

### ***Arguments***

int <i>id</i>	ID of import ended
---------------	--------------------

### ***Struct***

-

### ***Return Value***

R_MM_OK	Normal End
R_MM_FATAL	Fatal Error

### ***Description***

(1) This function ends using the address and the size got from dmabuf fd for id.

### ***Notes***

- (1) Set ID, which is started by mmngr\_import\_start\_in\_user\_ext() and is not ended, to id.
- (2) Don't set ID for the dmabuf fd, while the space to connected to dmabuf fd is used.
- (3) Don't call this API at the context of a signal handler.

### ***See Also***

-

## **7. Header Files**

Include `mmngr_user_public.h` in the application, when the application calls the APIs of MMNGR.

Include `mmngr_buf_user_public.h` in the application, when the application calls the APIs of DMABUF function of MMNGR (DMABUF function).

## 8. Definition

### 8.1 Structure

#### 8.1.1 Lossy support structure

The following is described about the member of MM\_FUNC structure.

```
struct MM_FUNC {
    unsigned int func;
    unsigned int type;
    unsigned int attr;
    unsigned int *conf;
};
```

**Table 8-1 Members of MM\_FUNC structure**

Member	Direction	Contents
unsigned int func	Input	Specify Lossy support in memory allocation request.  Two available options are: * MM_FUNC_LOSSY_ENABLE * MM_FUNC_LOSSY_DISABLE
unsigned int type	Input	Specify type of Lossy area.  Two available options are: * MM_FUNC_TYPE_LOSSY_AREA * MM_FUNC_TYPE_LOSSY_SHADOW  NOTE: The supported types are depended on the system configuration.
unsigned int attr	Input	Specify image format storing in Lossy area.  Three available options are: * MM_FUNC_FMT_LOSSY_YUVPLANAR * MM_FUNC_FMT_LOSSY_YUV422INTLV * MM_FUNC_FMT_LOSSY_ARGB8888  NOTE: The supported image formats are depended on the system configuration.
unsigned int *conf	Output	Specify whether the Lossy memory allocation request is supported or not.  User should check the output value before using the allocated buffer.  Two possible output value are: * MM_FUNC_STAT_LOSSY_SUPPORT * MM_FUNC_STAT_LOSSY_NOT_SUPPORT

## 8.2 Macros

### 8.2.1 Return Value Definition

**Table 8-2 List of Return Value Definition**

Definition	Value	Content
R_MM_OK	0	Normal End
R_MM_FATAL	-1	Fatal Error
R_MM_SEQE	-2	Sequence Error
R_MM_PARE	-3	Parameter Error
R_MM_NOMEM	-4	Lack of Memory

### 8.2.2 Parameter Definition

**Table 8-3 List of Parameter Definition**

Definition	Value	Content
MMNGR_VA_SUPPORT	0	The space reserved as default CMA area
MMNGR_PA_SUPPORT	1	The space reserved as CMA area for MMP
MMNGR_PA_SUPPORT_SSP	3	The space reserved as CMA area for MMP for DTV (SSP)
MMNGR_PA_SUPPORT_LOSSY	4	The space reserved as CMA area for Lossy compression feature

### 8.2.3 Parameter Definition for Lossy mem allocation

**Table 8-4 List of Parameter Definition for Lossy mem allocation**

Definition	Value	Content
MM_FUNC_LOSSY_DISABLE	0	The non-Lossy mem allocation is requested. It has same effect as memory request with MMNGR_PA_SUPPORT.
MM_FUNC_LOSSY_ENABLE	1	The Lossy mem allocation is requested.
MM_FUNC_TYPE_LOSSY_AREA	1	The type of Lossy area is a Lossy area in visible physical memory.
MM_FUNC_TYPE_LOSSY_SHADOW	2	The type of Lossy area is a Lossy area in shadow physical mem.
MM_FUNC_FMT_LOSSY_YUVPLANAR	1	The image format in Lossy Area is YUV Planar.
MM_FUNC_FMT_LOSSY_YUV422INTLV	2	The image format in Lossy Area is YUV 422 Interleave.
MM_FUNC_FMT_LOSSY_ARGB8888	3	The image format in Lossy Area is ARGB8888.
MM_FUNC_STAT_LOSSY_NOT_SUPPORT	0	The requested Lossy mem alloc is not supported.
MM_FUNC_STAT_LOSSY_SUPPORT	1	The requested Lossy mem alloc is supported.

## **9. Restrictions and Notices**

### **9.1 Restrictions**

- For Lossy areas, only support up to 3 Lossy areas, each area has different image format (1 area for YUV Planar, 1 area for YUV 422 interleave and 1 area for ARGB8888).
- For Lossy areas, does not support type of Lossy area in shadow physical mem (In case of MM\_FUNC\_TYPE\_LOSSY\_SHADOW).
- When IPMMU MMU is enabled, the first 1GB DDR physical address space in legacy area (0x40000000 - 0x80000000 on H3/M3/M3N/E3) should be mapped straight-forwardly in virtual address space for H/W IP.

### **9.2 Notices**

- It depends on the number, the requested size and the order of memory allocation, a memory allocation may fail even if the total amount of un-used memory is enough. This situation is almost same as when fragmentation occurs.
- Default CMA area should be kept in legacy 32-bit address space.
- For Lossy mem allocation support, need corresponding IPL support and Linux kernel support.
  - On E3 Ver.1.0 + Ebisu-2D (1GB DDR): not support Lossy compression feature.
  - On E3 Ver.1.x + Ebisu-4D (2GB DDR): support Lossy compression feature.
- When IPMMU MMU is enabled and mmngr\_alloc\_in\_user\_ext() is called, returned value at phard\_addr argument is not actual physical address as CPU view. Instead, the address is virtual address for H/W IP.
- On M3N and E3, there's no 40-bit address space. IPMMU MMU will support physical address space in legacy area.
- In “End the export of dmabuf fd” process, DMA Buffer Sharing framework will call dmabuf\_release() to free the memory allocated for dmabuf only when the refcount becomes 0. The buffer will not be freed by MMNGRBUF API (dmabuf\_release() function) but by MMNGR API instead (mmngr\_free\_in\_user\_ext() function) since MMNGR is the one allocated the buffer. Please prefer Figure 5.2 for a sample sequence. If user allocated the buffer via their own API, please free the memory allocated for dmabuf after “End the export of dmabuf fd” process.

## 10. Appendix

### 10.1 Legacy API

Using the following legacy APIs is NOT recommended because we only support them to keep the compatibility of software developed in Gen2 platform.

**Table 10-1 List of Legacy API**

No	Name	Function	Difference with Gen2 API
1	mmngr_alloc_in_user()	Allocate the memory space	Using pphy_addr is prohibited. It returns 0xffffffffffff (64bit).
2	mmngr_free_in_user()	Free the memory space	-
3	mmngr_debug_map_va()	Map the memory space for H/W IP to the user space. (Debug API for the space reserved as CMA area for MMP)	-
4	mmngr_debug_unmap_va()	Unmap the memory space mapped to the user space (Debug API for the space reserved as CMA area for MMP)	-
5	mmngr_export_start_in_user()	Start the export of dmabuf fd.	-
6	mmngr_export_end_in_user()	End the export of dmabuf fd.	-
7	mmngr_import_start_in_user()	Start the import of dmabuf fd.	-
8	mmngr_import_end_in_user()	End the import of dmabuf fd.	-



## 10.2 Relationship between mem\_param and Lossy mem return value

Below table shows the relationship between Lossy request data in MM\_FUNC struct passing via mem\_param parameter and memory allocation return value.

**Table 10-2 Relationship between mem\_param and Lossy mem return value**

Case	Return value	conf (in MM_FUNC structure)
- mem_param is NULL	R_MM_PARE	(not set)
- mem_param is valid. - However, specify type is MM_FUNC_TYPE_LOSSY_SHADOW.		(not set)
- mem_param is valid. - However, specify undefined memory allocation request, i.e. neither MM_FUNC_LOSSY_DISABLE nor MM_FUNC_LOSSY_ENABLE		(not set)
- mem_param is valid. - However, specify undefined image format. i.e. an undefined format, neither YUVPLANAR, YUV422INTLV nor ARGB8888.		(not set)
- mem_param is valid. - Specify a defined image format i.e. YUVPLANAR, YUV422INTLV or ARGB8888 - However, the system does NOT support that format.		MM_FUNC_STAT_LOSSY_NOT_SUPPORT
- mem_param is valid. - Specify a defined image format. i.e. YUVPLANAR, YUV422INTLV or ARGB8888 - The system supports that format. - However, the memory allocation fails.	R_MM_NOMEM	MM_FUNC_STAT_LOSSY_SUPPORT
- mem_param is valid. - Specify a defined image format. i.e. YUVPLANAR, YUV422INTLV or ARGB8888 - The system supports that format. - Moreover, the memory allocation is OK.	R_MM_OK	MM_FUNC_STAT_LOSSY_SUPPORT

## 10.3 IPMMU MMU support

### 10.3.1 Enable IPMMU MMU support

Below shows the procedure to enable IPMMU MMU support, and can support moving the CMA area for MMP, CMA area for Lossy compression feature to 40-bit physical address space.

#### 1) Notices for IPMMU MMU support.

MMNGR will manage below registers:

- In IPMMU Main Memory (IPMMU-MM) (8 registers for 8<sup>th</sup> page table):
  - o IMCTRn, IMTTBCRn, IMTTUBR0n, IMTTLBR0n, IMMAIR0n, IMELARn, IMEUARn, IMSTRn
- In IPMMU cache (3 registers corresponding to each IPMMU master):
  - o IMCTRn, IMUCTRn, IMSCTLR.

On M3N and E3, CMA areas will be kept in legacy areas when IPMMU MMU is enabled.

#### 2) Customize CMA areas' definitions in kernel source code

##### CMA area for MMP

Modify the start address and size of CMA area for MMP under node linux,multimedia in device tree arch/arm64/boot/dts/renesas/xxx.dts. (H3 Ver.1.x: xxx.dts means r8a77950-salvator-x.dts, H3 Ver.2.0: xxx.dts means r8a77951-salvator-x.dts, r8a77951-salvator-xs.dts, H3 Ver.3.0: xxx.dts means r8a77951-salvator-xs-4x2g.dts, M3 Ver.1.x: xxx.dts means r8a77960-salvator-x.dts, r8a77960-salvator-xs.dts, M3 Ver.3.0: xxx.dts means r8a77961-salvator-xs-2x4g.dts, M3N : xxx.dts means r8a77965-salvator-x.dts, r8a77965-salvator-xs.dts, E3 Ver.1.0: xxx.dts means r8a77990-es10-ebisu.dts, r8a77990-es10-ebisu-4d.dts, E3 Ver.1.1: xxx.dts means r8a77990-ebisu.dts, r8a77990-ebisu-4d.dts)

```
mmp_reserved: linux,multimedia@AAAAAAAA {
    compatible = "shared-dma-pool";
    reusable;
    reg = <0xZ 0XXXXXXXX 0x0 0YYYYYYYY>;
};
```

0xZ is the first 8-bit in 40-bit physical start address.  
 0xZ = 0x6 means the physical start address will begin with 0x06\_XXXXXXXX.  
 For H3, its value can be 0x0, 0x5, 0x6 or 0x7. For M3, its value can be 0x0 or 0x6.  
 For M3N, its value must be 0x0. For E3, its value must be 0x0.

0XXXXXXXX is last 32-bit in 40-bit physical address.  
 0YYYYYYYY is size of CMA area.  
 0AAAAAAAA is 40-bit physical address, which has:  
 - The first 8-bit in 40-bit physical address is same as 0xZ  
 - The last 32-bit in 40-bit physical address is same as 0XXXXXXXX

##### CMA area for Lossy compression feature

Modify the start address and size of CMA area for Lossy under node linux,lossy\_decompress in device tree.

```
lossy_decompress: linux,lossy_decompress@0xAAAAAAAA {
    no_map;
    reg = <0xZ 0XXXXXXXX 0x0 0YYYYYYYY>;
};
```

##### Default CMA area

When CMA areas (i.e. CMA area for MMP, CMA area for Lossy) are moved to 40-bit address space, we can expand either default CMA area or kernel heap in legacy area.

For example, in the case of moving CMA area for MMP to 40-bit address space:

- Default CMA area can increase +256 MB.
- Kernel heap in legacy area can increase +256 MB.

To modify the start address and size of default CMA area, refer to Yocto Recipe Start-Up Guide.

If you do not use the space reserved as CMA area for MMP for DTV (SSP), follow 4), 5) and 6)

### 3) Use the space reserved as CMA area for MMP for DTV (SSP)

The configuration for the space reserved as CMA area for MMP for DTV (SSP) is same in both IPMMU enabled and disabled environment

To modify the configuration, refer to chapter 2.2, then follow "3) Building the kernel module".

For example, in order to support the space reserved as CMA area for MMP for DTV (SSP) in 40-bit address space:

- Refer to 2) in this chapter, to modify the start address and size of CMA area for MMP in 40-bit address space.
- In `mmngr_private.h`, set `MM_SSPBUF_ADDR` within CMA area for MMP (40-bit address space).
- In `mmngr_private.h`, set `MM_SSPBUF_SIZE` and `MM_OMXBUF_SIZE` so that their total size also within the size of CMA area for MMP.
- Export the definition for DTV (SSP).

### 4) Enable IPMMU devices in kernel source code

Enable the selected IPMMU devices, which have IPMMU MMU support in device tree.

`arch/arm64/boot/dts/renesas/xxxx.dtsi`. (H3 Ver.1.x: `xxxx.dtsi` means `r8a77950.dtsi`,  
H3 Ver.2.0: `xxxx.dtsi` means `r8a77951.dtsi`,  
H3 Ver.3.0: `xxxx.dtsi` means `r8a77951.dtsi`,  
M3 Ver.1.x: `xxxx.dtsi` means `r8a77960.dtsi`,  
M3 Ver.3.0: `xxxx.dtsi` means `r8a77961.dtsi`,  
M3N: `xxxx.dtsi` means `r8a77965.dtsi`,  
E3 Ver.1.0: `xxxx.dtsi` means `r8a77990-es10.dtsi`,  
E3 Ver.1.1: `xxxx.dtsi` means `r8a77990.dtsi`)

H3 Ver.1.x: enable node `ipmmu_vp0`, `ipmmu_vc0`, `ipmmu_vc1`, `ipmmu_sy` (\*).  
H3 Ver.2.0: enable node `ipmmu_vp0`, `ipmmu_vp1`, `ipmmu_vc0`, `ipmmu_vc1`, `ipmmu_ds1` (\*).  
H3 Ver.3.0: enable node `ipmmu_vp0`, `ipmmu_vp1`, `ipmmu_vc0`, `ipmmu_vc1`, `ipmmu_ds1` (\*).  
M3 Ver.1.x: enable node `ipmmu_vc0`, `ipmmu_vi`, `ipmmu_ds1` (\*).  
M3 Ver.3.0: enable node `ipmmu_vc0`, `ipmmu_vi`, `ipmmu_ds1` (\*).  
M3N: enable node `ipmmu_vc0`, `ipmmu_vp0`, `ipmmu_ds1` (\*).  
E3 Ver.1.0: enable node `ipmmu_vc0`, `ipmmu_vp0`.  
E3 Ver.1.1: enable node `ipmmu_vc0`, `ipmmu_vp0`.

\*: When supporting CMA area for MMP for DTV (SSP), you need to enable these nodes.

Below is example of enabling node `ipmmu_vp0` for H3 Ver.2.0.

```
ipmmu_vp0: mmu@fe990000 {
    compatible = "renesas,ipmmu-mmu-r8a7795";
    ..., <snip> ,
    status = "disabled";
};
```

The property "status" is set "disabled" by default. Please change to "okay" to enable IPMMU MMU.  
i.e. `status = "okay";`

MMNGR driver uses the 8th non-secure page table (8th MMU context or MMU number 7) of 8 MMU contexts and `ipmmu-vmesa` driver uses the remaining MMU contexts.  
Therefore, sharing MMU resources between MMNGR driver and `ipmmu-vmesa` driver is necessary.

Sharing resources is unnecessary when `ipmmu-vmesa` driver is disabled. The confirmation can be done by checking Kernel Configuration. (\*1)

Device Drivers --->

[ ] IOMMU Hardware Support ---> (\*1): The driver is disabled when it's not selected.

When `ipmmu-vmesa` driver is enabled (\*2), to reserve the 8th MMU context for MMNGR, make following setting (\*3)

in Kernel Configuration.

Device Drivers --->

[\*] IOMMU Hardware Support ---> (\*2) The driver is enabled when it's selected.

--- IOMMU Hardware Support

[\*] Renesas VMSA-compatible IPMMU

(7) Input MMU number of MMU's really used (\*3) Change the value from 8 to 7.

In case of making the 8th MMU context reservation for MMNGR, the resource assignment is below.

- MMUn (n = 0 to 6) contexts are for ipmmu-vmesa driver
- MMUn (n = 7) context is for MMNGR driver

Re-build the kernel image by Yocto bitbake command. Follow Yocto Recipe Start-up Guide to set up Yocto environment.

\$ bitbake linux-renesas -c compile -f

#### 5) Building the kernel module

To enable IPMMU MMU support in MMNGR, need to change the environment variable.

\$ export MMNGR\_IPMMU\_MMU\_CONFIG=IPMMU\_MMU\_SUPPORT\_1GB\_PGTABLE

Execute make under mmngr\_drv/mmngr/mmngr-module/files/mmngr/drv.

\$ cd mmngr\_drv/mmngr/mmngr-module/files/mmngr/drv

\$ make

#### 6) Verifying the kernel image and the kernel module

Make sure that the following kernel module is built under mmngr\_drv/mmngr/mmngr-module/files/mmngr/drv.

mmngr.ko

### 10.3.2 Map CMA areas to IPMMU virtual address space

Below shows the guideline how to properly map each CMA area to the IPMMU virtual address space.

The physical address of CMA areas should follow below policy in order to create a correct IPMMU PA-VA mapping table.

- Map up to 4GB CMA area to the IPMMU virtual address space.
- Default CMA should be in Legacy area.  
i.e. within 0x40000000 - 0x80000000 (H3), 0x40000000 - 0xC0000000 (M3), 0x40000000 - 0xC0000000 (M3N), 0x40000000 - 0xC0000000 (E3).
- The size of CMA for MMP or CMA for Lossy should be within 1GB and located in a 1GB fixed physical address space.
- All of three CMA areas (or two of them) can co-exist in one entry only when the total size is within 1GB.
- Depend on the availability of physical address space, the mapping table can be customized.

The default PA-VA mapping tables for H3 Ver.1.x, 2.0, 3.0, M3 Ver.1.x, 3.0, M3N and E3 are showed as below.

**Table 10-3 PA-VA mapping table for H3 Ver.1.x, 2.0, 3.0**

	Physical address	Virtual address
1 <sup>st</sup> Entry (*1)	0x0_4000_0000	0x4000_0000
2 <sup>nd</sup> Entry	0x5_0000_0000	0x8000_0000
3 <sup>rd</sup> Entry	0x6_0000_0000	0xC000_0000
4 <sup>th</sup> Entry (*2)	0x7_0000_0000	0x0000_0000

**Table 10-4 PA-VA mapping table for M3 Ver.1.x, 3.0**

	Physical address	Virtual address
1 <sup>st</sup> Entry (*1)	0x0_4000_0000	0x4000_0000
2 <sup>nd</sup> Entry	0x0_8000_0000	0x8000_0000
3 <sup>rd</sup> Entry	0x6_0000_0000	0xC000_0000
4 <sup>th</sup> Entry (*2)	0x6_4000_0000	0x0000_0000

**Table 10-5 PA-VA mapping table for M3N**

	Physical address	Virtual address
1 <sup>st</sup> Entry (*1)	0x0_4000_0000	0x4000_0000
2 <sup>nd</sup> Entry	0x0_8000_0000	0x8000_0000
3 <sup>rd</sup> Entry	0x0000_0000	0x0000_0000
4 <sup>th</sup> Entry	0x0000_0000	0x0000_0000

**Table 10-6 PA-VA mapping table for E3**

	Physical address	Virtual address
1 <sup>st</sup> Entry (*1)	0x0_4000_0000	0x4000_0000
2 <sup>nd</sup> Entry	0x0_8000_0000	0x8000_0000
3 <sup>rd</sup> Entry	0x0000_0000	0x0000_0000
4 <sup>th</sup> Entry	0x0000_0000	0x0000_0000

NOTE:

- Each entry has a 1GB fixed physical address space.

- The address map of 2<sup>nd</sup> Entry, 3<sup>rd</sup> Entry and 4<sup>th</sup> Entry can be adjusted based on available physical address space.
- \*1: The first 1GB DDR physical address space in legacy area should be equal to a virtual address space from H/W IP.  
i.e, 0x40000000 - 0x80000000 (H3/M3/M3N/E3) should be mapped straight-forwardly.
- \*2: Take care that this 1GB physical address space starts with virtual address space with 0.

The necessary translation tables for each CMA area will be calculated automatically based on the following table entries defined in mmngr\_private.h.

```
/* Table entries for H3 */
#define H3_IPMMU_ADDR_SECTION_0 0x0700000000ULL
#define H3_IPMMU_ADDR_SECTION_1 0x0040000000ULL
#define H3_IPMMU_ADDR_SECTION_2 0x0500000000ULL
#define H3_IPMMU_ADDR_SECTION_3 0x0600000000ULL

/* Table entries for M3 */
#define M3_IPMMU_ADDR_SECTION_0 0x0640000000ULL
#define M3_IPMMU_ADDR_SECTION_1 0x0040000000ULL
#define M3_IPMMU_ADDR_SECTION_2 0x0080000000ULL
#define M3_IPMMU_ADDR_SECTION_3 0x0600000000ULL


/* Table entries for M3N */
#define M3N_IPMMU_ADDR_SECTION_0 0
#define M3N_IPMMU_ADDR_SECTION_1 0x0040000000ULL
#define M3N_IPMMU_ADDR_SECTION_2 0x0080000000ULL
#define M3N_IPMMU_ADDR_SECTION_3 0

/* Table entries for E3 */
#define M3N_IPMMU_ADDR_SECTION_0 0
#define M3N_IPMMU_ADDR_SECTION_1 0x0040000000ULL
#define M3N_IPMMU_ADDR_SECTION_2 0x0080000000ULL
#define M3N_IPMMU_ADDR_SECTION_3 0
```

These table entries are defined based on each entry's DDR physical address in Table 10-3, Table 10-4, Table 10-5 and Table 10-6. Therefore, if you need to change the default PA-VA mapping table, update the table entries in mmngr\_private.h with appropriate DDR physical address according to your configurations.

### 10.3.3 Sample memory map

Below shows H3 sample memory map with the default PA-VA mapping table in Table 10-3 when IPMMU is enabled. Depend on CMA areas' configuration in device tree, the location of CMA areas can be changed from the default memory map.



**Figure 10-1 Sample memory map (IPMMU enabled)**

# CONFIDENTIAL

Revision History		Memory Manager for Linux User's Manual: Software	
Rev.	Date	Description	
		Page	Summary
v0.1	Oct. 2015	-	New creation
v0.2	Nov. 2015	-	Modified typographical errors
		3	Fig1-2: Added ChangeHistory.txt to "mmngr" and "mmngrbuf" dir.
		22, 25	Changed an API parameter name from "data" to "mem_param".
v0.3	Apr. 2016	-	Update format of header and footer. Add caption for all Figures and Tables. Update List of Abbreviations and Acronyms for Lossy compression feature. Add List of Terminologies for Lossy compression feature.
		1	Add description of Lossy mem allocation.
		7	Add requirement for total size of OMXBUF and SSPBUF.
		10	Fig3-1: add the block of CMA for Lossy mem allocation
		15,16, 17, 19	Add description about CMA for Lossy mem allocation in MMNGR API(s).
		28	Add section 8.1 Lossy support structure
		29	Add Table 8 4 List of Parameter Definition for Lossy mem allocation.
		30	Add Restriction and Notice for Lossy mem allocation. Update Notices for CMA area in non-support IPMMU environment.
		32	Add section 10.2 Relationship between mem_param and Lossy mem return value.
v0.4	Aug. 2016	-	Update List of Terminologies.
		1	Add IPMMU PMB support.
		2	Fig1-1: change the name of MIT license file
		5, 6, 8	Remove 32-bit library description.
		9	Add section 2.4 Device tree configuration
		33,34	Add section 10.3 Enable IPMMU PMB support.
v0.5	Jan. 2017	3	Add new common header files to Figure 1-2.
		5, 6, 7	Add new environment variable INCSHARED, remove KERNELDIR variable
		6, 33	Add information about H3 Ver.1.x dts Add label mmp_reserved to the example of MMP CMA area
		9	Update description for memory-region.
		34	Correct guideline to enable IPMMU devices in kernel source code. From edit dts file to edit dtsi file
		34	Update example of enabling node ipmmu_vp for H3 (Ver.1.x)
		15, 17, 25, 30	Add notice for value of phard_addr when IPMMU PMB is enabled
		19, 20, 22	Add notice for value of hard_addr when IPMMU PMB is enabled
		33, 34	Add customize CMA areas' definitions guide for CMA area for Lossy compression feature
		34	Update notice about default CMA area when CMA area for MMP is moved to 40-bit address space



## CONFIDENTIAL

Revision History		Memory Manager for Linux User's Manual: Software	
Rev.	Date	Description	
		Page	Summary
v0.6	Mar. 2017	1, 17	Clarify the supported VSP devices as VSPI and VSPB
		4	Table 1-2: Update BSP name (add "M3")
		6, 33, 34	Use Ver. for SoC revision, e.g. H3 Ver.1.x
		6, 33	Add information about H3 Ver.2.0 dts
		34	Update information about enabling ipmmu_vi node for M3 Add information about enabling ipmmu nodes for H3 Ver.2.0
v0.7	Jun. 2017	-	Update List of Terminologies.
		1, 6, 15, 17, 19, 20, 22, 25, 30, 33 - 35	Use IPMMU (MMU mode) instead of IPMMU (PMB mode). All description of IPMMU (PMB mode) are removed.
		19, 22, 25	Change the explanation of mem_param from "T.B.D" to "Do not use".
		4	Add information about XS board support
		30	Add Restriction when IPMMU MMU is enabled
		6, 33	Add DT file information about XS board for M3 SoC
		33	Notice about the registers managed by MMNGR Remove the description about shadow area in customize CMA areas' definitions example
		33	Remove the requirements when customize the CMA areas when IPMMU enabled
		34	Add kernel configuration to share IPMMU MMU resources between MMNGR and other BSP drivers
		34	Update the example of enabling node ipmmu_vp0 for H3 for Ver.2.0
		34	Add IPMMU-DS1 and IPMMU-SY support Add notice about using the space reserved as CMA area for MMP for DTV (SSP) when IPMMU is enabled
		36, 37	Add guideline to map CMA to IPMMU virtual address space. Add sample memory map when IPMMU is enabled
v1.00	Aug. 2017	-	Update document format
v1.01	Nov. 2017	4, 30	Add information about M3N support
		6	Add DT file information for M3N SoC
		30	Add Notice when IPMMU MMU is enabled on M3N
		33-34	Update IPMMU MMU support description for M3N
		36-37	Add guideline to map CMA to IPMMU virtual address space for M3N
v1.50	Jan. 2018	32	Add new case: specify undefined memory allocation request in requesting Lossy data
v1.51	Mar. 2018	4, 6, 7, 30, 33, 34	Add information about E3 support
		30	Add Notice when IPMMU MMU is enabled on E3
		36-37	Add guideline to map CMA to IPMMU virtual address space for E3

## CONFIDENTIAL

Revision History		Memory Manager for Linux User's Manual: Software	
Rev.	Date	Description	
		Page	Summary
v1.52	Apr. 2018	6, 33, 34, 36	Add information about H3 Ver.3.0 support
		30, 36, 37	Update Restrictions and Notices about IPMMU mapping.
		30	Update Notices about space reserved as CMA area for Lossy compression feature on R-Car E3
v1.53	Jun. 2018	47, 48	Revise H3 SoC revision information
v1.54	Oct. 2018	24, 30	Add notice about buffer handling in "End the export of dmabuf fd" API
v2.00	Dec. 2018	-	Update Address List
		4	Update hardware environment
		6, 33	Add information about Ebisu-4D board for E3 SoC
		6, 33	Update unit address in DT examples
		24, 30	Update notice about buffer handling in "End the export of dmabuf fd" API
v2.01	Apr. 2019	-	Update Address List
		1	Clarify support status regarding directly DMA buffer-sharing between MMNGR and Linux Kernel Display Driver
		6, 33, 34, 36	Update information about R-Car E3 Ver.1.0 and Ver.1.1
		6, 33, 34, 36	Update information about R-Car M3 Ver.3.0 and Ver.1.x
		30	Update Notices about Lossy compression feature support on R-Car E3
v2.50	Apr. 21, 2021	-	Update Address List
		6, 33, 34	Add Kernel v5.10 support
v3.00	Dec. 10, 2021	All	Add Kernel v5.10.41 support
V3.1.0	Dec. 25, 2023	-	Add Kernel v5.19.194 support for H3, M3, M3N, E3.

# **CONFIDENTIAL**

---

Memory Manager for Linux  
User's Manual: Software

Publication Date:   Rev.0.1     Oct. 30, 2015  
                          Rev.3.1.0   Dec. 25, 2023

Published by:       Renesas Electronics Corporation

---



## SALES OFFICES

## Renesas Electronics Corporation

<http://www.renesas.com>

Refer to "<http://www.renesas.com/>" for the latest and detailed information.

### **Renesas Electronics Corporation**

TOYOSU FORESIA, 3-2-24 Toyosu, Koto-ku, Tokyo 135-0061, Japan

### **Renesas Electronics America Inc. Milpitas Campus**

1001 Murphy Ranch Road, Milpitas, CA 95035, U.S.A.

Tel: +1-408-432-8888, Fax: +1-408-434-5351

### **Renesas Electronics America Inc. San Jose Campus**

6024 Silver Creek Valley Road, San Jose, CA 95138, USA

Tel: +1-408-284-8200, Fax: +1-408-284-2775

### **Renesas Electronics Canada Limited**

9251 Yonge Street, Suite 8309 Richmond Hill, Ontario Canada L4C 9T3

Tel: +1-905-237-2004

### **Renesas Electronics Europe GmbH**

Arcadiastrasse 10, 40472 Düsseldorf, Germany

Tel: +49-211-6503-0, Fax: +49-211-6503-1327

### **Renesas Electronics (China) Co., Ltd.**

Room 101-T01, Floor 1, Building 7, Yard No. 7, 8th Street, Shangdi, Haidian District, Beijing 100085, China

Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

### **Renesas Electronics (Shanghai) Co., Ltd.**

Unit 301, Tower A, Central Towers, 555 Langao Road, Putuo District, Shanghai 200333, China

Tel: +86-21-2226-0888, Fax: +86-21-2226-0999

### **Renesas Electronics Hong Kong Limited**

Unit 1601-1611, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong

Tel: +852-2265-6688, Fax: +852 2886-9022

### **Renesas Electronics Taiwan Co., Ltd.**

13F, No. 363, Fu Shing North Road, Taipei 10543, Taiwan

Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

### **Renesas Electronics Singapore Pte. Ltd.**

80 Bendemeer Road, #06-02 Singapore 339949

Tel: +65-6213-0200, Fax: +65-6213-0300

### **Renesas Electronics Malaysia Sdn.Bhd.**

Unit No 3A-1 Level 3A Tower 8 UOA Business Park, No 1 Jalan Pengaturcara U1/51A, Seksyen U1, 40150 Shah Alam, Selangor, Malaysia

Tel: +60-3-5022-1288, Fax: +60-3-5022-1290

### **Renesas Electronics India Pvt. Ltd.**

No.777C, 100 Feet Road, HAL 2nd Stage, Indiranagar, Bangalore 560 038, India

Tel: +91-80-67208700

### **Renesas Electronics Korea Co., Ltd.**

17F, KAMCO Yangjae Tower, 262, Gangnam-daero, Gangnam-gu, Seoul, 06265 Korea

Tel: +82-2-558-3737, Fax: +82-2-558-5338



ルネサスエレクトロニクス株式会社

■営業お問合せ窓口

<http://www.renesas.com>

※営業お問合せ窓口の住所は変更になることがあります。最新情報につきましては、弊社ホームページをご覧ください。

ルネサス エレクトロニクス株式会社 〒135-0061 東京都江東区豊洲3-2-24（豊洲フォレシア）

■技術的なお問合せおよび資料のご請求は下記へどうぞ。  
総合お問合せ窓口：<https://www.renesas.com/contact/>

# Memory Manager for Linux User's Manual: Software