

CONFIDENTIAL

Table of Contents

1. Overview	1
1.1 Overview.....	1
1.2 Function	1
1.2.1 Supported pin	1
1.2.2 Connected device	3
1.3 Reference	4
1.3.1 Standard.....	4
1.3.2 Related document	4
1.4 Restrictions	4
2. Terminology.....	5
3. Operating Environment.....	6
3.1 Hardware Environment	6
3.2 Module Configuration.....	7
3.3 State Transition Diagram	9
4. External Interface.....	10
4.1 sysfs interface.....	10
4.2 Interface specification	15
4.2.1 Setting GPIO pin	16
4.2.2 GPIO pin is set as input pin	16
4.2.3 GPIO pin is set as output pin	17
4.2.4 The state of GPIO pin get high or low	17
4.2.5 The state of GPIO pin is set as high or low	18
4.2.6 Get number of irq in GPIO pin	18
4.3 Definitions	19
4.3.1 Definitions of the GPIO Pins (R-Car H3/M3/M3N)	19
4.3.2 Definitions of the GPIO Pins (R-Car E3)	19
4.3.3 Definitions of the GPIO Pins (R-Car V3U).....	19
4.3.4 Definitions of the GPIO Pins (R-Car V3H).....	20
4.3.5 Definitions of the GPIO Pins (R-Car D3)	20
4.3.6 Get definitions of the GPIO Pins.....	20
5. Integration	21
5.1 Directory Configuration.....	21
5.2 Integration Procedure.....	21
5.2.1 Kernel configuration	21
5.3 Option Setting	21
5.3.1 Module parameters.....	21
5.3.2 Kernel parameters	21