

Tuning Methods

Date: 2026-01-12

Measure SWR and impedance with a VNA at the feed point.

Trim the wire in small increments to move resonance upward.

Add length or use a loading coil to move resonance downward.

Adjust matching transformer taps or tuner settings as needed.

Re-check after rain or temperature changes.