

NextBASIC Unimplemented Features (Updated 12 Feb 2018)

This document lists the as-yet-unimplemented features of NextOS/NextBASIC, as at the current version of NextOS (**v1.96**). These are planned to be present by the cased machines release (by v2.00).

This should be read in conjunction with the other documents:

- NextBASIC file-related commands and features
- NextBASIC new commands and features
- NextOS Editor features
- NextOS API

Unimplemented features

Drive images (C:/NEXTOS/CPM-*.P3D and C:/NEXTOS/DRV-*.P3D) are not yet automatically mapped, and cannot be manually mounted.

+3 floppy disk images (*.DSK) cannot yet be mounted.

Spanish language version of the ROMs is not yet available.

CP/M loader option not yet implemented.

The **.install** dot command doesn't yet support allocation of additional 8K banks for driver usage.

Unimplemented commands

POINT *x,y,var*

DRAW *x,y* (Not yet implemented for layer 1 or layer 2 modes)

DRAW *x,y,z* (Not yet implemented for layer 1 or layer 2 modes)

CIRCLE *x,y,r* (Not yet implemented for layer 1 or layer 2 modes)

BANK *n* **LINE** *x,y*

BANK *n* **LIST**

BANK *n* **LIST** *l*

BANK *n* **MERGE**

BANK *n* **GOTO** *l*

BANK *n* **GOSUB** *l*

BANK *n* **RESTORE** *l*

MOVE *drive\$=path\$*

Unimplemented dot commands

.defrag

.mkdata

.mkswap

.mkdsk