

Reset Procedures

- RA-1070** - With the unit powered on, press and hold the Listening PHONO and Recording OFF front panel buttons simultaneously.
- RC-1082** - With the unit powered on, press and hold the Listening PHONO and Recording OFF front panel buttons simultaneously.
- RC-1090** - With the unit powered on, press and hold the Listening PHONO and Recording OFF front panel buttons simultaneously.
- RDV-1040** - With the unit unplugged, press and hold the STOP and PLAY buttons simultaneously, then reconnect the power cord and release the two buttons. The front panel should read 'JC 0'. Press and release the PAUSE button. The Progressive LED will illuminate and the front display will change to 'JC 00'. Power down the unit using the STANDBY button to complete the reset.
- RDV-1045** - With the unit unplugged, press and hold the STOP and PLAY buttons simultaneously, then reconnect the power cord and release the two buttons. The front panel should read 'TEST 1U10'. Press and release the >>| button. The front display will change to 'TEST 1U4 0' and then change again to 'TEST 1U4 00'. Power down the unit using the STANDBY button to complete the reset.
- RDV-1050** - With the unit unplugged, press and hold the STOP and PLAY buttons simultaneously, then reconnect the power cord and release the two buttons. The front panel should read 'JC 0'. Press and release the PAUSE button. The front display will change to 'JC 00'. Power down the unit using the STANDBY button to complete the reset.
- RDV-1060** - Select the DEFAULTS option from the PREFERENCES Menu of the On Screen Display.
- RDV-1080** - With the unit unplugged, press and hold the STOP and PLAY buttons simultaneously, then reconnect the power cord and release the two buttons. The front panel should read 'TEST 1U'. Press and release the TRACK>>| button, followed by the PAUSE button. Wait approximately 6 seconds for the DVD-Audio LED to illuminate, then power down the unit using the STANDBY button to complete reset.
- RDV-1092** - Select the RESTORE DEFAULTS option from the SYSTEM SETUP Menu of the On Screen Display.
- RDV-1093** - Select the RESTORE DEFAULTS option from the SYSTEM SETUP Menu of the On Screen Display.

- RSDX-02** - With the unit unplugged, press and hold the STOP and DVD buttons simultaneously, then reconnect the power cord and release the two buttons. The front panel should read 'TEST --', and change to 'TEST JC'. Press and release the PAUSE button. The INPUTATT icon on the top right of display should illuminate. Power down the unit using the STANDBY button to complete reset.
- RSP-1066** - Select the FACTORY DEFAULT option from the DEFAULT Menu of the On Screen Display.
- RSP-1068** - Select the FACTORY DEFAULT option from the DEFAULT Menu of the On Screen Display.
- RSP-1069** - Select the FACTORY DEFAULT option from the DEFAULT Menu of the On Screen Display.
- RSP-1098** - Select the FACTORY DEFAULT option from the DEFAULT Menu of the On Screen Display.
- RSX-1055** - Select the FACTORY DEFAULT option from the DEFAULT Menu of the On Screen Display.
- RSX-1056** - Select the FACTORY DEFAULT option from the DEFAULT Menu of the On Screen Display.
- RSX-1057** - Select the FACTORY DEFAULT option from the DEFAULT Menu of the On Screen Display.
- RSX-1058** - Select the FACTORY DEFAULT option from the DEFAULT Menu of the On Screen Display.
- RSX-1065** - Select the FACTORY DEFAULT option from the DEFAULT Menu of the On Screen Display.
- RSX-1067** - Select the FACTORY DEFAULT option from the DEFAULT Menu of the On Screen Display.
- RT-1080** - (North American tuning frequencies) - Power off the unit. With the unit powered off, press and hold the MEMORY and 9 buttons on the front panel simultaneously. While holding these buttons, power the unit on from the front panel button.
- RT-1084** - If the unit is not currently in HD Radio/AM/FM mode, press the SIRIUS / HD button on the front panel until the unit is in this mode. Then press the SETUP button on the front panel, and press the Down button until "01 Factory default" is highlighted. Press the ENTER button. The display will read "Set Tune default" and NO and YES will be present. Press the Up key so that YES is blinking and press ENTER to reset the unit.

- RX-1050 -** Power off the unit. Press and hold the SPEAKER B, TUNE/PRESET, and MONO front panel buttons simultaneously, and power the unit on. When properly reset, the unit should power on to the Tuner input at FM frequency 87.5.
- RX-1052 -** With the unit on press and hold the SPEAKER B, TUNE/PRESET, and MONO front panel buttons simultaneously. The CD and VID 3 buttons on the front panel will act as the UP/DOWN cursor to cycle through the selections. Choose either "BAND USA" or "BAND EUR". The VID 2 and VID 4 buttons on the front panel will act as the LEFT/RIGHT cursor to cycle through the selections. After making the desired selection use the CD or VID 3 buttons on the front panel to cycle through the selections until the word "SAVE" is displayed on the front panel of the unit. Then use the VID 2 or VID 4 buttons on the front panel to cycle through the options until "SAVE YES" is displayed ("SAVE NO" will cancel the prior actions). The "SAVE YES" option will save the new settings and exit the menu.