

(All Cars) (Special Note)

1	2		3	4					5	6		7	8	
9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
24	25		26	27	28	29		30	31	32	33		34	35

Mirage [C225)

Light blue connector (large) (35)

- 1 ETV+ thr control act motor +
- 2 ETV- thr control act motor -
- 3 LHFL liner air fuel ratio senso pin 2
- 4 OHRL rear o2 hearer
- 5 SGT Grank position sensor
- 6 SGC cam position sensor
- 7 ALTG Alt G
- 8 CIL1 Ign 1
- 9 INJ1 Injector 1
- 10 INJ2 Injector 2
- 11 PURG; Evaporate purge solenoid
- 12
- 13
- 14 MAP MAP sensor
- 15 5V sensor supply 5V
- 16 SENG sensor supply 0V
- 17 TPSE tps hall supply 0V
- 18 DGND Cam sensor ground
- 19 TPSS tps hall supply 5V
- 20 K/S Knock sensor
- 21 ALTF Alt feild
- 22 ALTL Alt L
- 23 CIL2 BiGN 2
- 24 INJ 3 Injector 3
- 25 OCV oil feed control vale
- 26 ORLE o2 sensor rear Supply 0v
- 27 O2RL o2 sensor rear
- 28 WTS water temp sensor
- 29 ATS MAS Intake air temp
- 30 TPMS tps sensor Main
- 31 TPSS tps sensor sub
- 32
- 33 K/S Knock sensor 0v
- 34 OPSW Oil pressure Switch
- 35 CIL3 IGN3

Mirage

71	72	73	74							75	76	77
78	79	80	81	82	83	84	85	86	87	88	89	
90	91		92	93	94		95	96		97	98	

Stratos [C227)

- 71 P/VT Evaporate vent solenoid (CCV)
 72 FP/R fuel pump relay
 73
 74
 75 DIAG obd pin7
 76 FMB
 77 BACK Backup power source
 78
 79
 80
 81 FDFD HEATER CONTROL PANEL (DEFFOGGER SWITCH)
 82 F/TM fuel tank temp
 83 F/PR fuel tank diff press sensor
 84 BFAN hearer resistor blower switch
 85
 86
 87 FPRE & ACTE fuel tank diff press sensor supply 0V
 88 HEATER CONTROL PANEL (A/C SWITCH)
 89 IGN Ignition position
 90
 91
 92 FPR5 fuel tank diff press sensor supply 5V
 93 SW- clock spring
 94 - clock spring
 95 AC/T Fin Thermo Sensor
 96
 97 ST kos ecu Immobilizer) or ignition switch st
 98

Mirage

Key colours

L	blue
G	Green
W	White
Y	Yellow
B	Black
BR	Brown
R	Red
O	Orange
LG	Light Green
V	violet
P	Pink
TRP	transparent
SI	silver
SB	Sky Blue

KEY

E/C	enging control
A/T	Automatic Transmission
I/D	Instrument display
D/C	Diagnostic Connector
N/C	Not connected
A/C	Air Con
E/T	electronic Throttle

41	42	43					44	45	46
47	48	49	50	51	52	53	54	55	56
58	59		60	61	62	63		64	65

Mirage [C226)

Light blue connector (small) (26)

- 41
42
43
44
45
46
47
48
49
50
51
52
53 LEFL liner air fuel ratio senso 5 (ground)
54 LSFw liner air fuel ratio sensor pin 4
55 ASF MAS output
56 ASF5 MAS sensor supply 5V
57
58
59
60
61
62 LRL liner air fuel ratio senso pin 6
63 LPFL liner air fuel ratio senso pin 1
64 ASFE MAS sensor supply 0V
65
66

Mirage

101	102		103	104					105	106	107	
108	109	110	111	112	113	114	115	116	117	118	119	120
121	122	123		124	125		126	127	128		129	130

Stratos [C228

Green connector (30)

- 101 CANH Can Hi
- 102 CANL Can lo
- 103 STRL CLUTCH INT SW M/T; N/P SW CVT
- 104 AC/R A/C compressor relay
- 105 F/HI cooling fan relay high
- 106 BAT1 MFI relay return power source
- 107
- 108 F/LO cooling fan relay low
- 109 C/RL throttle control actuator relay
- 110 C/R MFI relay
- 111 APS accelerator position sensor MAIN
- 112 APS5 accelerator position sensor supply 5V
- 113 APSE accelerator position sensor supply 0V
- 114 AC/P AC pressure sensor
- 115 BVS brake vacuum sensor
- 116 BV55 APC5 brake vacuum and AC pressure Supply 5v
- 117 BVSE APCE brake vacuum and AC pressure Supply 0v
- 118 STCD
- 119 gnbd ground
- 120 gnde ground
- 121 BRK Stop lamp switch
- 122
- 123 APSS accelerator position sensor SUB
- 124 AP5 accelerator position sensor supply 5V
- 125 APE accelerator position sensor supply 0V
- 126
- 127
- 128 CLTC1 CLUTCH INTERLOCK SWITCH
- 129 RSB throttle control actuator relay return power source
- 130 rsg ground

Mirage