

Variable	Value
BluOS.IP	192.168.10.133
BluOS.OSDAPI	5
BluOS.Version	v3.20.52
DSP.Board	AM230
DSP.Version	v1.29
Main.Action	MenuClose
Main.Amp.Back	Back
Main.Amp.Clip	No
Main.Amp.Overheat	No
Main.Audio.Channels	2/0.0
Main.Audio.CODEC	PCM
Main.Audio.Delay	39.5
Main.Audio.Lock	Yes
Main.Audio.Rate	48
Main.Audyssey	Off
Main.Audyssey.ADV	Off
Main.Audyssey.DEQ	Off
Main.Audyssey.Offset	0
Main.AutoStandby	Off
Main.AutoTrigger	Main
Main.Bass	0
Main.Brightness	2
Main.Build	T778_PG536M_NONE
Main.CEC.ARC	Auto
Main.CEC.Audio	On
Main.CEC.Power	Off
Main.CEC.Switch	On
Main.CenterDialog	0
Main.ControlStandby	On
Main.Dirac	1
Main.Distance.BackLeft	0
Main.Distance.BackRight	0
Main.Distance.Center	0
Main.Distance.Left	0
Main.Distance.Right	0
Main.Distance.Sub	0
Main.Distance.SurroundLeft	0
Main.Distance.SurroundRight	0
Main.Distance.UOM	Feet
Main.Distance.User1Left	0
Main.Distance.User1Right	0
Main.Distance.User2Left	0
Main.Distance.User2Right	0
Main.Dolby.CenterSpread	On
Main.Dolby.CenterWidth	3
Main.Dolby.Dimension	0

NAD T-778 RS232 Commands

Main.Dolby.DRC	Auto
Main.Dolby.Panorama	Off
Main.DTS.CenterGain	0.2
Main.DTS.DialogControl	0
Main.DTS.DRC	100
Main.EnhancedBass	Off
Main.EnhancedStereo.Back	On
Main.EnhancedStereo.Center	On
Main.EnhancedStereo.Front	On
Main.EnhancedStereo.Surround	On
Main.EnhancedStereo.User1	On
Main.EnhancedStereo.User2	On
Main.Fan.Status	1000,1000,OK
Main.Fan.Test	Off
Main.IR.Channel	0
Main.Language	Unknown
Main.LCD.DarkMode	Off
Main.LCD.Display	On
Main.LCD.FrontView.BluOS	3
Main.LCD.FrontView.Other	1
Main.Level.BackLeft	0
Main.Level.BackRight	0
Main.Level.Center	0
Main.Level.Left	0
Main.Level.Right	0
Main.Level.Sub	0
Main.Level.SurroundLeft	0
Main.Level.SurroundRight	0
Main.Level.User1Left	0
Main.Level.User1Right	0
Main.Level.User2Left	0
Main.Level.User2Right	0
Main.LipSyncDelay	0
Main.ListeningMode	EnhancedStereo
Main.ListeningMode.Analog	EnhancedStereo
Main.ListeningMode.Dolby.Stereo	DolbySurround
Main.ListeningMode.Dolby.Surround	DolbySurround
Main.ListeningMode.DTS.Stereo	NeuralX
Main.ListeningMode.DTS.Surround	NeuralX
Main.ListeningMode.PCM.Stereo	EnhancedStereo
Main.ListeningMode.PCM.Surround	None
Main.Model	T778
Main.Mute	Off
Main.OSD.TempDisplay	On
Main.Power	Off
Main.Serial	K217T77806396
Main.Sleep	0

NAD T-778 RS232 Commands

Main.Source	3
Main.Speaker.Back.Config	Small
Main.Speaker.Back.Frequency	80
Main.Speaker.Back.Mode	Stereo
Main.Speaker.Center.Config	Small
Main.Speaker.Center.Frequency	80
Main.Speaker.Front.Config	Small
Main.Speaker.Front.Frequency	80
Main.Speaker.Sub	On
Main.Speaker.Surround.Config	Small
Main.Speaker.Surround.Frequency	80
Main.Speaker.User1.Config	Off
Main.Speaker.User1.Frequency	80
Main.Speaker.User1.Mode	DolbyFront
Main.Speaker.User2.Config	Off
Main.Speaker.User2.Frequency	80
Main.Speaker.User2.Mode	DolbyFront
Main.Temp.Back	32
Main.Temp.Center	33
Main.Temp.Front	32
Main.Temp.Height	33
Main.Temp.PSU	41
Main.Temp.Surround	31
Main.ToneDefeat	Off
Main.Treble	0
Main.Trigger1.Delay	0
Main.Trigger1.Out	Main
Main.Trigger2.Delay	0
Main.Trigger2.Out	Zone2
Main.Trigger3.Delay	0
Main.Trigger3.Out	Source
Main.Trim.Center	0
Main.Trim.Height	0
Main.Trim.Sub	0
Main.Trim.Surround	0
Main.Version	v2.24
Main.Video.3D	No
Main.Video.ARC	No
Main.Video.Bits	36
Main.Video.Color	BT.2020 4:2:0
Main.Video.HDR	Yes
Main.Video.Lock	Yes
Main.Video.Resolution	3840x2160p60
Main.VideoMode	NTSC
Main.Volume	-53
Main.Volume.Max	5
Main.Volume.Min	-98

NAD T-778 RS232 Commands

Preset1.Audyssey	Off
Preset1.Audyssey.ADV	Off
Preset1.Audyssey.DEQ	Off
Preset1.Audyssey.Offset	0
Preset1.Bass	0
Preset1.Brightness	3
Preset1.CenterDialog	0
Preset1.Dirac	0
Preset1.Distance.BackLeft	0
Preset1.Distance.BackRight	0
Preset1.Distance.Center	0
Preset1.Distance.Left	0
Preset1.Distance.Right	0
Preset1.Distance.Sub	0
Preset1.Distance.SurroundLeft	0
Preset1.Distance.SurroundRight	0
Preset1.Distance.UOM	Feet
Preset1.Distance.User1Left	0
Preset1.Distance.User1Right	0
Preset1.Distance.User2Left	0
Preset1.Distance.User2Right	0
Preset1.Dolby.CenterSpread	On
Preset1.Dolby.CenterWidth	3
Preset1.Dolby.Dimension	0
Preset1.Dolby.DRC	Auto
Preset1.Dolby.Panorama	Off
Preset1.DTS.CenterGain	0.2
Preset1.DTS.DialogControl	0
Preset1.DTS.DRC	100
Preset1.EnhancedBass	Off
Preset1.EnhancedStereo.Back	On
Preset1.EnhancedStereo.Center	On
Preset1.EnhancedStereo.Front	On
Preset1.EnhancedStereo.Surround	On
Preset1.EnhancedStereo.User1	On
Preset1.EnhancedStereo.User2	On
Preset1.LCD.DarkMode	Off
Preset1.LCD.Display	On
Preset1.LCD.FrontView.BluOS	3
Preset1.LCD.FrontView.Other	1
Preset1.Level.BackLeft	0
Preset1.Level.BackRight	0
Preset1.Level.Center	0
Preset1.Level.Left	0
Preset1.Level.Right	0
Preset1.Level.Sub	0
Preset1.Level.SurroundLeft	0

NAD T-778 RS232 Commands

Preset1.Level.SurroundRight	0
Preset1.Level.User1Left	0
Preset1.Level.User1Right	0
Preset1.Level.User2Left	0
Preset1.Level.User2Right	0
Preset1.LipSyncDelay	0
Preset1.ListeningMode	None
Preset1.ListeningMode.Analog	None
Preset1.ListeningMode.Dolby.Stereo	PLIIMusic
Preset1.ListeningMode.Dolby.Surround	PLIIMovie
Preset1.ListeningMode.DTS.Stereo	NEO6Music
Preset1.ListeningMode.DTS.Surround	NEO6Cinema
Preset1.ListeningMode.PCM.Stereo	None
Preset1.ListeningMode.PCM.Surround	None
Preset1.Name	Preset 1
Preset1.OSD.TempDisplay	On
Preset1.Setup.Display	No
Preset1.Setup.DSPOptions	Yes
Preset1.Setup.ListeningMode	Yes
Preset1.Setup.PictureControls	No
Preset1.Setup.Speaker	No
Preset1.Setup.ToneControls	Yes
Preset1.Setup.Video	No
Preset1.Speaker.Back.Config	Small
Preset1.Speaker.Back.Frequency	80
Preset1.Speaker.Back.Mode	Stereo
Preset1.Speaker.Center.Config	Small
Preset1.Speaker.Center.Frequency	80
Preset1.Speaker.Front.Config	Small
Preset1.Speaker.Front.Frequency	80
Preset1.Speaker.Sub	On
Preset1.Speaker.Surround.Config	Small
Preset1.Speaker.Surround.Frequency	80
Preset1.Speaker.User1.Config	Off
Preset1.Speaker.User1.Frequency	80
Preset1.Speaker.User1.Mode	DolbyFront
Preset1.Speaker.User2.Config	Off
Preset1.Speaker.User2.Frequency	80
Preset1.Speaker.User2.Mode	DolbyFront
Preset1.ToneDefeat	Off
Preset1.Treble	0
Preset2.Audyssey	Off
Preset2.Audyssey.ADV	Off
Preset2.Audyssey.DEQ	Off
Preset2.Audyssey.Offset	0
Preset2.Bass	0
Preset2.Brightness	3

Preset2.CenterDialog	0
Preset2.Dirac	0
Preset2.Distance.BackLeft	0
Preset2.Distance.BackRight	0
Preset2.Distance.Center	0
Preset2.Distance.Left	0
Preset2.Distance.Right	0
Preset2.Distance.Sub	0
Preset2.Distance.SurroundLeft	0
Preset2.Distance.SurroundRight	0
Preset2.Distance.UOM	Feet
Preset2.Distance.User1Left	0
Preset2.Distance.User1Right	0
Preset2.Distance.User2Left	0
Preset2.Distance.User2Right	0
Preset2.Dolby.CenterSpread	On
Preset2.Dolby.CenterWidth	3
Preset2.Dolby.Dimension	0
Preset2.Dolby.DRC	Auto
Preset2.Dolby.Panorama	Off
Preset2.DTS.CenterGain	0.2
Preset2.DTS.DialogControl	0
Preset2.DTS.DRC	100
Preset2.EnhancedBass	Off
Preset2.EnhancedStereo.Back	On
Preset2.EnhancedStereo.Center	On
Preset2.EnhancedStereo.Front	On
Preset2.EnhancedStereo.Surround	On
Preset2.EnhancedStereo.User1	On
Preset2.EnhancedStereo.User2	On
Preset2.LCD.DarkMode	Off
Preset2.LCD.Display	On
Preset2.LCD.FrontView.BluOS	3
Preset2.LCD.FrontView.Other	1
Preset2.Level.BackLeft	0
Preset2.Level.BackRight	0
Preset2.Level.Center	0
Preset2.Level.Left	0
Preset2.Level.Right	0
Preset2.Level.Sub	0
Preset2.Level.SurroundLeft	0
Preset2.Level.SurroundRight	0
Preset2.Level.User1Left	0
Preset2.Level.User1Right	0
Preset2.Level.User2Left	0
Preset2.Level.User2Right	0
Preset2.LipSyncDelay	0

Preset2.ListeningMode	None
Preset2.ListeningMode.Analog	None
Preset2.ListeningMode.Dolby.Stereo	PLIIMusic
Preset2.ListeningMode.Dolby.Surround	PLIIMovie
Preset2.ListeningMode.DTS.Stereo	NEO6Music
Preset2.ListeningMode.DTS.Surround	NEO6Cinema
Preset2.ListeningMode.PCM.Stereo	None
Preset2.ListeningMode.PCM.Surround	None
Preset2.Name	Preset 2
Preset2.OSD.TempDisplay	On
Preset2.Setup.Display	No
Preset2.Setup.DSPOptions	Yes
Preset2.Setup.ListeningMode	Yes
Preset2.Setup.PictureControls	No
Preset2.Setup.Speaker	No
Preset2.Setup.ToneControls	Yes
Preset2.Setup.Video	No
Preset2.Speaker.Back.Config	Small
Preset2.Speaker.Back.Frequency	80
Preset2.Speaker.Back.Mode	Stereo
Preset2.Speaker.Center.Config	Small
Preset2.Speaker.Center.Frequency	80
Preset2.Speaker.Front.Config	Small
Preset2.Speaker.Front.Frequency	80
Preset2.Speaker.Sub	On
Preset2.Speaker.Surround.Config	Small
Preset2.Speaker.Surround.Frequency	80
Preset2.Speaker.User1.Config	Off
Preset2.Speaker.User1.Frequency	80
Preset2.Speaker.User1.Mode	DolbyFront
Preset2.Speaker.User2.Config	Off
Preset2.Speaker.User2.Frequency	80
Preset2.Speaker.User2.Mode	DolbyFront
Preset2.ToneDefeat	Off
Preset2.Treble	0
Preset3.Audyssey	Off
Preset3.Audyssey.ADV	Off
Preset3.Audyssey.DEQ	Off
Preset3.Audyssey.Offset	0
Preset3.Bass	0
Preset3.Brightness	3
Preset3.CenterDialog	0
Preset3.Dirac	0
Preset3.Distance.BackLeft	0
Preset3.Distance.BackRight	0
Preset3.Distance.Center	0
Preset3.Distance.Left	0

NAD T-778 RS232 Commands

Preset3.Distance.Right	0
Preset3.Distance.Sub	0
Preset3.Distance.SurroundLeft	0
Preset3.Distance.SurroundRight	0
Preset3.Distance.UOM	Feet
Preset3.Distance.User1Left	0
Preset3.Distance.User1Right	0
Preset3.Distance.User2Left	0
Preset3.Distance.User2Right	0
Preset3.Dolby.CenterSpread	On
Preset3.Dolby.CenterWidth	3
Preset3.Dolby.Dimension	0
Preset3.Dolby.DRC	Auto
Preset3.Dolby.Panorama	Off
Preset3.DTS.CenterGain	0.2
Preset3.DTS.DialogControl	0
Preset3.DTS.DRC	100
Preset3.EnhancedBass	Off
Preset3.EnhancedStereo.Back	On
Preset3.EnhancedStereo.Center	On
Preset3.EnhancedStereo.Front	On
Preset3.EnhancedStereo.Surround	On
Preset3.EnhancedStereo.User1	On
Preset3.EnhancedStereo.User2	On
Preset3.LCD.DarkMode	Off
Preset3.LCD.Display	On
Preset3.LCD.FrontView.BluOS	3
Preset3.LCD.FrontView.Other	1
Preset3.Level.BackLeft	0
Preset3.Level.BackRight	0
Preset3.Level.Center	0
Preset3.Level.Left	0
Preset3.Level.Right	0
Preset3.Level.Sub	0
Preset3.Level.SurroundLeft	0
Preset3.Level.SurroundRight	0
Preset3.Level.User1Left	0
Preset3.Level.User1Right	0
Preset3.Level.User2Left	0
Preset3.Level.User2Right	0
Preset3.LipSyncDelay	0
Preset3.ListeningMode	None
Preset3.ListeningMode.Analog	None
Preset3.ListeningMode.Dolby.Stereo	PLIIMusic
Preset3.ListeningMode.Dolby.Surround	PLIIMovie
Preset3.ListeningMode.DTS.Stereo	NEO6Music
Preset3.ListeningMode.DTS.Surround	NEO6Cinema

Preset3.ListeningMode.PCM.Stereo	None
Preset3.ListeningMode.PCM.Surround	None
Preset3.Name	Preset 3
Preset3.OSD.TempDisplay	On
Preset3.Setup.Display	No
Preset3.Setup.DSPOptions	Yes
Preset3.Setup.ListeningMode	Yes
Preset3.Setup.PictureControls	No
Preset3.Setup.Speaker	No
Preset3.Setup.ToneControls	Yes
Preset3.Setup.Video	No
Preset3.Speaker.Back.Config	Small
Preset3.Speaker.Back.Frequency	80
Preset3.Speaker.Back.Mode	Stereo
Preset3.Speaker.Center.Config	Small
Preset3.Speaker.Center.Frequency	80
Preset3.Speaker.Front.Config	Small
Preset3.Speaker.Front.Frequency	80
Preset3.Speaker.Sub	On
Preset3.Speaker.Surround.Config	Small
Preset3.Speaker.Surround.Frequency	80
Preset3.Speaker.User1.Config	Off
Preset3.Speaker.User1.Frequency	80
Preset3.Speaker.User1.Mode	DolbyFront
Preset3.Speaker.User2.Config	Off
Preset3.Speaker.User2.Frequency	80
Preset3.Speaker.User2.Mode	DolbyFront
Preset3.ToneDefeat	Off
Preset3.Treble	0
Preset4.Audyssey	Off
Preset4.Audyssey.ADV	Off
Preset4.Audyssey.DEQ	Off
Preset4.Audyssey.Offset	0
Preset4.Bass	0
Preset4.Brightness	3
Preset4.CenterDialog	0
Preset4.Dirac	0
Preset4.Distance.BackLeft	0
Preset4.Distance.BackRight	0
Preset4.Distance.Center	0
Preset4.Distance.Left	0
Preset4.Distance.Right	0
Preset4.Distance.Sub	0
Preset4.Distance.SurroundLeft	0
Preset4.Distance.SurroundRight	0
Preset4.Distance.UOM	Feet
Preset4.Distance.User1Left	0

NAD T-778 RS232 Commands

Preset4.Distance.User1Right	0
Preset4.Distance.User2Left	0
Preset4.Distance.User2Right	0
Preset4.Dolby.CenterSpread	On
Preset4.Dolby.CenterWidth	3
Preset4.Dolby.Dimension	0
Preset4.Dolby.DRC	Auto
Preset4.Dolby.Panorama	Off
Preset4.DTS.CenterGain	0.2
Preset4.DTS.DialogControl	0
Preset4.DTS.DRC	100
Preset4.EnhancedBass	Off
Preset4.EnhancedStereo.Back	On
Preset4.EnhancedStereo.Center	On
Preset4.EnhancedStereo.Front	On
Preset4.EnhancedStereo.Surround	On
Preset4.EnhancedStereo.User1	On
Preset4.EnhancedStereo.User2	On
Preset4.LCD.DarkMode	Off
Preset4.LCD.Display	On
Preset4.LCD.FrontView.BluOS	3
Preset4.LCD.FrontView.Other	1
Preset4.Level.BackLeft	0
Preset4.Level.BackRight	0
Preset4.Level.Center	0
Preset4.Level.Left	0
Preset4.Level.Right	0
Preset4.Level.Sub	0
Preset4.Level.SurroundLeft	0
Preset4.Level.SurroundRight	0
Preset4.Level.User1Left	0
Preset4.Level.User1Right	0
Preset4.Level.User2Left	0
Preset4.Level.User2Right	0
Preset4.LipSyncDelay	0
Preset4.ListeningMode	None
Preset4.ListeningMode.Analog	None
Preset4.ListeningMode.Dolby.Stereo	PLIIMusic
Preset4.ListeningMode.Dolby.Surround	PLIIMovie
Preset4.ListeningMode.DTS.Stereo	NEO6Music
Preset4.ListeningMode.DTS.Surround	NEO6Cinema
Preset4.ListeningMode.PCM.Stereo	None
Preset4.ListeningMode.PCM.Surround	None
Preset4.Name	Preset 4
Preset4.OSD.TempDisplay	On
Preset4.Setup.Display	No
Preset4.Setup.DSPOptions	Yes

Preset4.Setup.ListeningMode	Yes
Preset4.Setup.PictureControls	No
Preset4.Setup.Speaker	No
Preset4.Setup.ToneControls	Yes
Preset4.Setup.Video	No
Preset4.Speaker.Back.Config	Small
Preset4.Speaker.Back.Frequency	80
Preset4.Speaker.Back.Mode	Stereo
Preset4.Speaker.Center.Config	Small
Preset4.Speaker.Center.Frequency	80
Preset4.Speaker.Front.Config	Small
Preset4.Speaker.Front.Frequency	80
Preset4.Speaker.Sub	On
Preset4.Speaker.Surround.Config	Small
Preset4.Speaker.Surround.Frequency	80
Preset4.Speaker.User1.Config	Off
Preset4.Speaker.User1.Frequency	80
Preset4.Speaker.User1.Mode	DolbyFront
Preset4.Speaker.User2.Config	Off
Preset4.Speaker.User2.Frequency	80
Preset4.Speaker.User2.Mode	DolbyFront
Preset4.ToneDefeat	Off
Preset4.Treble	0
Preset5.Audyssey	Off
Preset5.Audyssey.ADV	Off
Preset5.Audyssey.DEQ	Off
Preset5.Audyssey.Offset	0
Preset5.Bass	0
Preset5.Brightness	3
Preset5.CenterDialog	0
Preset5.Dirac	0
Preset5.Distance.BackLeft	0
Preset5.Distance.BackRight	0
Preset5.Distance.Center	0
Preset5.Distance.Left	0
Preset5.Distance.Right	0
Preset5.Distance.Sub	0
Preset5.Distance.SurroundLeft	0
Preset5.Distance.SurroundRight	0
Preset5.Distance.UOM	Feet
Preset5.Distance.User1Left	0
Preset5.Distance.User1Right	0
Preset5.Distance.User2Left	0
Preset5.Distance.User2Right	0
Preset5.Dolby.CenterSpread	On
Preset5.Dolby.CenterWidth	3
Preset5.Dolby.Dimension	0

Preset5.Dolby.DRC	Auto
Preset5.Dolby.Panorama	Off
Preset5.DTS.CenterGain	0.2
Preset5.DTS.DialogControl	0
Preset5.DTS.DRC	100
Preset5.EnhancedBass	Off
Preset5.EnhancedStereo.Back	On
Preset5.EnhancedStereo.Center	On
Preset5.EnhancedStereo.Front	On
Preset5.EnhancedStereo.Surround	On
Preset5.EnhancedStereo.User1	On
Preset5.EnhancedStereo.User2	On
Preset5.LCD.DarkMode	Off
Preset5.LCD.Display	On
Preset5.LCD.FrontView.BluOS	3
Preset5.LCD.FrontView.Other	1
Preset5.Level.BackLeft	0
Preset5.Level.BackRight	0
Preset5.Level.Center	0
Preset5.Level.Left	0
Preset5.Level.Right	0
Preset5.Level.Sub	0
Preset5.Level.SurroundLeft	0
Preset5.Level.SurroundRight	0
Preset5.Level.User1Left	0
Preset5.Level.User1Right	0
Preset5.Level.User2Left	0
Preset5.Level.User2Right	0
Preset5.LipSyncDelay	0
Preset5.ListeningMode	None
Preset5.ListeningMode.Analog	None
Preset5.ListeningMode.Dolby.Stereo	PLIIMusic
Preset5.ListeningMode.Dolby.Surround	PLIIMovie
Preset5.ListeningMode.DTS.Stereo	NEO6Music
Preset5.ListeningMode.DTS.Surround	NEO6Cinema
Preset5.ListeningMode.PCM.Stereo	None
Preset5.ListeningMode.PCM.Surround	None
Preset5.Name	Preset 5
Preset5.OSD.TempDisplay	On
Preset5.Setup.Display	No
Preset5.Setup.DSPOptions	Yes
Preset5.Setup.ListeningMode	Yes
Preset5.Setup.PictureControls	No
Preset5.Setup.Speaker	No
Preset5.Setup.ToneControls	Yes
Preset5.Setup.Video	No
Preset5.Speaker.Back.Config	Small

Preset5.Speaker.Back.Frequency	80
Preset5.Speaker.Back.Mode	Stereo
Preset5.Speaker.Center.Config	Small
Preset5.Speaker.Center.Frequency	80
Preset5.Speaker.Front.Config	Small
Preset5.Speaker.Front.Frequency	80
Preset5.Speaker.Sub	On
Preset5.Speaker.Surround.Config	Small
Preset5.Speaker.Surround.Frequency	80
Preset5.Speaker.User1.Config	Off
Preset5.Speaker.User1.Frequency	80
Preset5.Speaker.User1.Mode	DolbyFront
Preset5.Speaker.User2.Config	Off
Preset5.Speaker.User2.Frequency	80
Preset5.Speaker.User2.Mode	DolbyFront
Preset5.ToneDefeat	Off
Preset5.Treble	0
Source1.AnalogGain	0
Source1.DigitalAudioFormat	HDMI
Source1.DigitalAudioInput	1
Source1.Enabled	Yes
Source1.Name	HTPC
Source1.Preset	0
Source1.TriggerOut	0
Source1.VideoFormat	HDMI
Source1.VideoInput	1
Source10.Name	Local
Source11.Name	Local
Source2.AnalogAudioFormat	Off
Source2.AnalogAudioInput	1
Source2.AnalogGain	0
Source2.DigitalAudioFormat	HDMI
Source2.DigitalAudioInput	2
Source2.Enabled	Yes
Source2.Name	Apple TV
Source2.Preset	0
Source2.TriggerOut	0
Source2.VideoFormat	HDMI
Source2.VideoInput	2
Source3.AnalogAudioFormat	Off
Source3.AnalogAudioInput	1
Source3.AnalogGain	0
Source3.DigitalAudioFormat	HDMI
Source3.DigitalAudioInput	3
Source3.Enabled	Yes
Source3.Name	Tivo
Source3.Preset	0

Source3.TriggerOut	0
Source3.VideoFormat	HDMI
Source3.VideoInput	3
Source4.AnalogAudioFormat	Stereo
Source4.AnalogAudioInput	2
Source4.AnalogGain	0
Source4.DigitalAudioFormat	Off
Source4.DigitalAudioInput	1
Source4.Enabled	Yes
Source4.Name	Radio
Source4.Preset	0
Source4.TriggerOut	0
Source4.VideoFormat	HDMI
Source4.VideoInput	3
Source5.AnalogAudioFormat	Off
Source5.AnalogAudioInput	1
Source5.AnalogGain	0
Source5.DigitalAudioFormat	Optical
Source5.DigitalAudioInput	2
Source5.Enabled	Yes
Source5.Name	LG TV
Source5.Preset	0
Source5.TriggerOut	0
Source5.VideoFormat	Off
Source5.VideoInput	1
Source6.AnalogAudioFormat	Off
Source6.AnalogAudioInput	1
Source6.AnalogGain	0
Source6.DigitalAudioFormat	BluOS
Source6.DigitalAudioInput	1
Source6.Enabled	Yes
Source6.Name	BluOS
Source6.Preset	0
Source6.TriggerOut	0
Source6.VideoFormat	BluOS
Source6.VideoInput	1
Source7.AnalogAudioFormat	Stereo
Source7.AnalogAudioInput	1
Source7.AnalogGain	0
Source7.DigitalAudioFormat	Off
Source7.DigitalAudioInput	1
Source7.Enabled	Yes
Source7.Name	Sonos
Source7.Preset	0
Source7.TriggerOut	0
Source7.VideoFormat	Off
Source7.VideoInput	1

Source8.AnalogAudioFormat	Off
Source8.AnalogAudioInput	1
Source8.AnalogGain	0
Source8.DigitalAudioFormat	HDMI
Source8.DigitalAudioInput	6
Source8.Enabled	Yes
Source8.Name	Front Input
Source8.Preset	0
Source8.TriggerOut	0
Source8.VideoFormat	HDMI
Source8.VideoInput	6
Source9.AnalogAudioFormat	Off
Source9.AnalogAudioInput	1
Source9.AnalogGain	0
Source9.DigitalAudioFormat	Off
Source9.DigitalAudioInput	1
Source9.Enabled	No
Source9.Name	Source 9
Source9.Preset	0
Source9.TriggerOut	0
Source9.VideoFormat	Off
Source9.VideoInput	1
Zone2.Mute	Off
Zone2.Power	On
Zone2.Source	7
Zone2.Volume	0
Zone2.Volume.Max	16
Zone2.Volume.Min	-95
Zone2.VolumeControl	Fixed
Zone2.VolumeFixed	0