

***No separate state for setting
cnt_up high, ZERO does it***

***No separate state for clearing
the counter, LOAD_F0 does it***

2-Point High-Pass FIR Filter Controller State Transition Diagram

