



AsteRx SB ProDirect

User Manual



User Manual Revision 1.1
Applicable to version 4.7.2 of the AsteRx SB ProDirect firmware
July 13, 2020

© Copyright 2000-2020 Septentrio NV/SA. All rights reserved.

Septentrio
Greenhill Campus, Interleuvenlaan 15i
3001 Leuven, Belgium

<http://www.septentrio.com>
Phone: +32 16 300 800
Fax: +32 16 221 640
 @Septentrio

Contents

1	Introduction	4
1.1	USER NOTICES	4
1.1.1	CE Notice	4
1.1.2	ROHS/WEEE Notice	4
1.1.3	Safety information	5
1.1.4	Support	6
2	AsteRx SB ProDirect Overview	7
2.1	PHYSICAL AND ENVIRONMENTAL SPECIFICATIONS	7
2.2	ASTERX SB PRODIRECT DESIGN	8
2.2.1	Front Panel	8
2.2.2	Rear Panel	8
3	Configuring the AsteRx SB Pro Direct	9
3.1	CONNECTING TO THE ASTERX SB PRODIRECT	9
3.1.1	Powering the AsteRx SB ProDirect	9
3.1.2	Connecting to the web interface via Ethernet	10
3.1.3	Connecting to the web interface via USB	11
3.1.4	Connecting via COM	12
3.2	HOW TO CONFIGURE THE ASTERX SB PRODIRECT FOR RTK	13
3.2.1	How to configure the AsteRx SB ProDirect in RTK rover mode via Ethernet	13
3.3	HOW TO CONFIGURE THE ASTERX SB PRODIRECT FOR ATTITUDE	15
4	Common Receiver Operations	20
4.1	HOW TO CONFIGURE SBF AND NMEA OUTPUT	20
4.1.1	Output over a serial COM connection	20
4.1.2	Output over Ethernet	24
4.2	HOW TO LOG DATA	28
4.2.1	Internal logging	28
4.3	DOWNLOADING LOGGED DATA FROM THE RECEIVER	31
Appendix A	Rear-panel port descriptions	32
A.1	PWR-COM2&3/USB	32
A.2	COM1-GPIO	33
A.3	ETH	34
A.4	MAIN ANT / AUX ANT (TNC)	34

1 Introduction

1.1 User Notices

1.1.1 CE Notice



The AsteRx SB ProDirect complies with the European Radio Equipment Directive (RED) 2014/53/EU and IEC 62368-1.

With regards to EMC, the AsteRx SB ProDirect receiver is declared as class A, suitable for residential or business environment. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

1.1.2 ROHS/WEEE Notice



The AsteRx SB ProDirect is compliant with the latest WEEE, RoHS and REACH directives. For more information see www.septentrio.com/en/environmental-compliance.

1.1.3 Safety information



Statement 1: The power supply provided by Septentrio (if any) should not be replaced by another. If you are using the receiver with your own power supply, it must have a double isolated construction and must match the specifications of the provided power supply.



Statement 2: Ultimate disposal of this product should be handled according to all national laws and regulations.



Statement 3: The equipment and all the accessories included with this product may only be used according to the specifications in the delivered release note, manual or other documents delivered with the receiver.

1.1.4 Support

For first-line support please contact your AsteRx SB ProDirect dealer.

Additional documentation can be found in the following manuals:

- **The AsteRx SB ProDirect Reference Guide** (available from the Support section of the Septentrio website) includes information on the receiver operation, the full list of receiver commands and a description of the format and contents of all SBF (Septentrio Binary Format) blocks.
- **The RxTools Manual** covers the RxTools software suite, including RxControl and RxLogger.
- **The Knowledge Base** on the Septentrio website contains a large number of articles and application notes which cover a wide array of technical and less technical topics. The Knowledge Base is part of Septentrio's Support Portal which can be accessed through the support section of the Septentrio website (see below).

The Septentrio website has a dedicated Support section (<http://www.septentrio.com/support>), where the User Manual, the Firmware Reference Guide and the latest officially supported Firmware version are readily available for download.

In case the AsteRx SB ProDirect does not behave as expected and you need to contact Septentrio's Technical Support department, you should attach a short SBF log file containing the support blocks and a Diagnostic Report of the receiver.



<http://www.septentrio.com>

Headquarters

Septentrio NV
Greenhill Campus
Interleuvenlaan 15i,
3001 Leuven,
Belgium

Phone: +32 16 300 800
Fax: +32 16 221 640
sales@septentrio.com

2 AsteRx SB ProDirect Overview

The AsteRx SB ProDirect is a multi-frequency, multi-constellation GNSS receiver offering precise and solid GNSS heading. Delivering precise positioning, 2D orientation and being IP68 compliant, this housed GNSS solution is ideal for rapid integration into machine control or safety applications.

The AsteRx SB ProDirect is designed to be used as a dual antenna GNSS receiver for a wide array of different systems but it can also be used as a single antenna receiver for systems which do not require heading.

2.1 Physical and Environmental Specifications

Size:	102 x 36 x 118 mm (4.0 x 1.4 x 4.6 in)
Weight:	497 g (1.1 lb)
Input voltage:	5 to 36 V DC
Power consumption:	1.00 W typical (single antenna) 1.35 W typical (dual antenna)
Operating temperature:	-30 °C to +65 °C (-22 °F to +149 °F)
Storage temperature:	-40 °C to +75 °C (-40 °F to +167 °F)
Ingress Protection:	IP68
Humidity	MIL-STD-810G, Method 507.5, Procedure I
Dust	MIL-STD-810G, Method 510.5, Procedure I
Shock	MIL-STD-810G, Method 516.6, Procedure I/II
Vibration	MIL-STD-810G, Method 514.6, Procedure I

2.2 AsteRx SB ProDirect design

2.2.1 Front Panel

The AsteRx SB ProDirect's front panel features the two antenna TNC connectors for the Main and Aux antennas.



Figure 2-1: The front panel of the AsteRx SB ProDirect

2.2.2 Rear Panel

Figure 2-2 shows the layout of the rear-panel connectors of the AsteRx SB ProDirect. The rear panel has three connectors: a 7-pin female PWR-COM2/3/USB socket, a 7-pin female COM1-GPIO socket and a 4-pin female ETH socket. A full description of the connector PIN layout of the rear panel ports can be found in Appendix A.



Figure 2-2: The rear panel of the AsteRx SB ProDirect

3 Configuring the AsteRx SB Pro Direct

3.1 Connecting to the AsteRx SB ProDirect

3.1.1 Powering the AsteRx SB ProDirect

The AsteRx SB ProDirect can be powered in a number of different ways. The first method is to power the receiver by supplying 5 to 36 VDC via the open-ended power cable connected to PIN 1 of the rear-panel 7-pin female PWR-COM2&3/USB socket.

You may also power the AsteRx SB ProDirect by connecting an appropriate USB cable to the same 7-pin female PWR-COM2&3/USB socket, using either the recommended Septentrio USB adapter or the USB socket of a PC as shown in Figure 3-1.



Figure 3-1: Connecting the receiver through USB using the rear panel PWR-COM2&3/USB socket

The AsteRx SB can also be powered through the ETH socket using power over Ethernet (PoE). All of the rear-panel ports and their pin assignments are described in more detail in Appendix A.

3.1.2 Connecting to the web interface via Ethernet

Step 1: Connect the Power and Ethernet cables

Connect the Ethernet cable to the connector labeled 'ETH' on the rear panel of the receiver as shown in Figure 3-2 and make sure it is connected to a LAN network. Then connect the power cable to the receiver and make sure the correct input voltage is applied (between 5 and 36 V DC). Note that in case the receiver is powered over Ethernet, connecting a power cable is not necessary.



Figure 3-2: Rear panel Ethernet socket

Step 2: Open a web browser and connect to the AsterX SB ProDirect

By default, the AsterX SB ProDirect has the hostname 'http://asterxsb-xxxxxxx', where xxxxxxx are the 7 digits of the serial number of the receiver board inside the AsterX SB ProDirect. This hostname can be used on a local area network to connect to the AsterX SB ProDirect if the IP address assigned by the DHCP server is unknown. The hostname can be found on a sticker on the bottom of the receiver housing. Figure 3-3 shows a screenshot of an Ethernet connection to a receiver with serial number 3034022 using 'http://asterxsb-3034022'.




Figure 3-3: Connecting to the Web Interface via Ethernet

3.1.3 Connecting to the web interface via USB

Step 1: Connect the combined Power/USB cable

Connect the combined Power/USB cable to the 7-pin female PWR-COM2&3/USB socket on the rear panel of the receiver as shown in Figure 3-4 and make sure it is connected to a LAN network. Then connect the power cable to the receiver and make sure the correct input voltage is applied (between 4.5 and 36 V DC).



Figure 3-4: Rear panel 7-pin PWR-COM2&3/USB socket

Step 2: Open a web browser and connect to the AsterX SB ProDirect

Once connected via USB, the AsterX SB ProDirect can be reached using the default Ethernet-over-USB IP address 192.168.3.1 as shown in Figure 3-5. Note that this address cannot be changed.



Figure 3-5: Connecting to the Web Interface via USB

3.1.4 Connecting via COM

In case you do not have an appropriate USB cable, Ethernet cable or LAN network available, you may still connect to the receiver using one of the receiver's COM ports and RxControl.

Step 1: Connect the Power and COM cables

Connect the COM cable to the connector labeled 'COM1-GPIO' on the rear panel of the receiver as shown in Figure 3-6 and connect the other end to a computer. It may be necessary to use a serial-to-USB converter. Now connect the power cable to the receiver and make sure the correct input voltage is applied (between 4.5 and 36 V DC).



Figure 3-6: Rear panel COM 1 socket

Step 2: Open RxControl and connect to the AsterX SB ProDirect

Once connected, open RxControl on the computer to which the receiver is connected and follow the sequence of steps described in Figure 3-7 to open a connection to the AsterX SB ProDirect. Note that RxControl is part of the RxTools software suite which can be freely downloaded from the Septentrio website.




Figure 3-7: Connecting to the receiver via COM using RxControl. Select 'Serial Connection' and choose 'Create New'. Next, choose the correct serial port, define a name for the connection and press Finish.

3.2 How to configure the AsteRx SB ProDirect for RTK

The AsteRx SB ProDirect can use correction data to calculate a cm-level RTK position. The AsteRx SB ProDirect can obtain this correction data in several ways: over the internet via NTRIP, using a serial or USB connection or via Ethernet. The example below shows how to set up configure the receiver for RTK using using TCP/IP in a closed network.

3.2.1 How to configure the AsteRx SB ProDirect in RTK rover mode via Ethernet

Step 1: Enable RTK positioning mode

Ensure that RTK is enabled as a positioning mode. This can be done in the GNSS Position tab by checking the 'RTK' box in the 'Position Mode' field as shown in Figure 3-8.




Figure 3-8: Ensure that RTK is enabled as a positioning mode

Step 2: Configure the Ethernet connection

On the **IP Ports** window of the rover receiver, click on **+ New IP Receive Connection** as shown in Figure 3-9 to start configuration sequence. The **Port** and **TCPAddress** should match the port and IP address of the Base station receiver.




Figure 3-9: In the **IP Ports** window, click on **+ New IP Receive Connection** to configure the connection with the base station

Step 3: Verifying the configuration

If the Base station and rover receivers have been configured correctly then the Communication Ethernet window should appear similar to the window shown in 3-10.




Figure 3-10: Ethernet tab of the **rover receiver** showing a fixed RTK position and reception of RTCMv3 diff corr on receiver port IPR1

3.3 How to configure the AsteRx SB ProDirect for Attitude

With two antennas connected to the AsteRx SB ProDirect, the receiver can calculate Heading and either Pitch or Roll. This section details how to configure the AsteRx SB ProDirect in a two-antenna setup.

Step 1: Connect a second antenna

Connect a second antenna to the front panel connector labelled **AUX ANT** as indicated in Figure 3-11.



Figure 3-11: Auxiliary antenna connector on front panel

Step 2: Configure attitude settings

The attitude settings of the AsteRx SB ProDirect can be configured in the **GNSS, Attitude** window as shown in Figure 3-12.




Figure 3-12: GNSS Attitude window when two antennas are connected

GNSS Attitude field

The recommended settings for a Heading setup are **MultiAntenna** mode with attitude calculated using **Fixed** ambiguities as shown. These settings are configured by default.

Antenna Location and Antenna Offset

The AsteRx SB ProDirect assumes that the main and auxiliary antennas are placed along the longitudinal axis of the vehicle with the auxiliary in front of the main antenna. If the antennas cannot be placed in such a configuration, the reported heading and pitch may be biased. The default settings in the **Antenna Offset** and **Antenna Location** fields shown in Figure 3-13 can be altered to compensate for these biases.

In many cases the antenna baseline will not align perfectly with the vehicle's longitudinal axis or its perpendicular and in these circumstances the provided attitude offset value can also be used to compensate for small angular deviations. Note that, in order to ensure the integrity of the solution, offsets greater than 5 degrees from the longitudinal axis or its perpendicular are not recommended.

An increase in angle between the antenna baseline and the vehicle's longitudinal axis in the clockwise direction corresponds to a positive change in the value of the heading offset. To better explain this, a few examples of possible setups are given below in Figure 3-13.




Figure 3-13: Examples of a number of antenna setups and the corresponding heading offsets. a.) The default setup for which the angle between the antenna baseline and the longitudinal axis is 0 and no heading offset needs to be set. b.) a slight deviation (5 degrees) from the longitudinal axis in the clockwise direction is reflected by a positive increase in the heading offset. c.) An alternative antenna configuration where the antennas are placed perpendicular to the longitudinal axis. d.) An alternative antenna configuration where the antennas are placed perpendicular to the longitudinal axis with a small deviation.

The examples above all relate to a heading offset but the antenna orientation can also be characterized by a vertical offset. Vertical offsets can be compensated for by adjusting the Pitch offset. This may be necessary in cases where the antenna baseline is not exactly parallel to the longitudinal axis of the vehicle or in situations where the two antenna ARPs

may not be exactly at the same height in the vehicle reference frame. Since pitch is defined as the right-handed rotation about the vehicle Y axis, a situation where the main antenna is mounted lower than the aux antenna (assuming the default antenna setup) will result in a positive pitch as shown in Figure 3-14.




Figure 3-14: Visual representation of the effect of vertical offset between the two antennas on the Pitch offset. Assuming the default antenna configuration, the aux antenna being mounted higher will result in a positive value for the pitch.

Step 3: Attitude information in SBF and NMEA data

Details on how to output SBF and NMEA data can be found in Section 4.1.

SBF

Attitude information is contained in the SBF blocks *AuxAntPositions*, *AttEuler*, *AttCovEuler* and *EndOfAtt*. These blocks are selected automatically when checking the 'Attitude' box when configuring SBF output via the **NMEA/SBF Out** window as Figure 3-15 shows.




Figure 3-15: SBF blocks containing attitude information

NMEA

You can output the attitude information from the AsteRx SB ProDirect in NMEA format by selecting the standard NMEA HDT sentence or the Septentrio proprietary HRP sentence as shown in Figure 3-16.




Figure 3-16: NMEA sentences containing attitude information

4 Common Receiver Operations

4.1 How to configure SBF and NMEA output

The AsteRx SB ProDirect can output position and GNSS data in both standard NMEA format and Septentrio's proprietary compact binary format SBF. The following sections detail how to configure connections to other devices in order to send data.

SBF and NMEA can also be logged on the internal 16 GB disk of the AsteRx SB ProDirect. Section 4.2.1 and 4.3 detail how to log data on the receiver and how to download data logged on the receiver.

4.1.1 Output over a serial COM connection

The AsteRx SB ProDirect can be connected via a serial COM cable to an RS-232 compatible secondary device.

Step 1: Configure the serial COM port

The COM port of the AsteRx SB ProDirect should be configured with the same baud rate and flow control setting of the coupled device. These settings can be configured via the **Communication/Serial Port** tab as shown in Figure 4-1. In this example, COM3 is set with a speed of 19200 baud.




Figure 4-1: Configure the baud rate and flow control of the AsteRx SB ProDirect

Step 2: Configure data output

NMEA

In the **NMEA/SBF Out** tab, clicking on **New NMEA Stream** will guide you through the steps needed to configure NMEA output as shown in Figures 4-2 and 4-3.




Figure 4-2: Selecting to output NMEA data on COM3




Figure 4-3: Selecting to output the GGA and ZDA NMEA message every second

SBF

By clicking **New SBF stream** in the **NMEA/SBF Out** window, a second output stream can be configured. In the example shown in Figures 4-4 and 4-5 the PVTCartesian SBF data block will be output over COM1 once per second.




Figure 4-4: Selecting to output SBF data on COM1





Figure 4-5: Selecting to output the PVTCartesian SBF block every second

Having configured the data output and clicked on **Ok**, the **NMEA/SBF Out** page will now display a summary of all data output as shown in Figure 4-6.



Figure 4-7 shows the actual data output. NMEA is in ASCII and is thus readable unlike SBF which is formatted in binary. In this example, the serial COM was connected to a PC via a USB adapter which maps the serial connection to a virtual COM9 of the PC.



4.1.2 Output over Ethernet

SBF and NMEA data can be sent over an Ethernet connection from the AsteRx SB ProDirect.

Step 1: Configure an IP connection on the AsteRx SB ProDirect

The Ethernet port settings can be configured by selecting **IP Ports** from the **Communication** menu. In the example shown in Figure 4-8, port 600 has been configured as connection IPS1 in **TCP2Way** mode so data can be received as well as transmitted over the connection. When choosing a port number, avoid conflicts with other applications such as the commands port (28784), the webserver port (80), the FTP port (21) as well as the default NTRIP port (2101) and the NTP port (123).

Note that a new IP port can also be configured by following the sequence of settings for NMEA output described in **Step 2**.





Figure 4-8: Configuring the TCP/IP server port setting for data output

Step 2: Configure output of NMEA messages

In the **NMEA/SBF Out** window, click on **New NMEA stream** and follow the sequence of windows to configure the data you want to output. In the example shown in Figure 4-9, the NMEA GGA message will be output every second. Ensure that the previously configured IPS1 port is selected for output as highlighted.



The screenshot shows the NMEA/SBF Out configuration window with the following components:

- Navigation Bar:** Overview, GNSS, Communication, Corrections, **NMEA/SBF Out**, Logging, Admin.
- Data Streams:** A box containing an icon of a data stream.
- NMEA/SBF Output Streams:** A box stating "There are currently no data streams defined." with buttons for "+ New NMEA stream" and "+ New SBF stream".
- Advanced Settings:** A section with "Default" and "Ok" buttons.
- New NMEA Output:** A dialog box for selecting the connection type. The "IP server" option is selected.
- New NMEA Output:** A dialog box for selecting the connection/port. The "IPS1: TCP 2-Way Server on port 600" option is selected.
- NMEA/SBF Output Streams:** A table showing the configured stream:

Port	Description	Type	Messages	Interval
IPS1	TCP 2-Way Server on port 600	NMEA	GGA	1 sec
- Advanced Settings:** A section with "Default" and "Ok" buttons.
- New NMEA Output:** A dialog box for selecting messages to output. The "GGA" message is selected, and the interval is set to "1 sec".

Figure 4-9: Outputting NMEA GGA over the configured IPS1 connection

Similar steps can be followed to output SBF messages.

Step 3: Configure Data Link to listen for NMEA output

The screenshots in Figure 4-10 show how the Septentrio GUI tool Data Link can be configured to listen for the AsteRx SB ProDirect GGA output.

Click on the **TCP/IP Client** button to configure the connection. In the highlighted fields insert the IP address or hostname of the receiver and the port number configured in **Step 1**. Click on **Connect**.




Figure 4-10: Configure the TCP/IP connection settings in Data Link

The info line at the bottom of the window should indicate that a connection has been made. Click on the **Show Data** button to display the GGA data coming from the receiver as in Figure 4-11.




Figure 4-11: The **Show data** window of Data Link showing the NMEA GGA message coming from the AsteRx SB ProDirect


4.2 How to log data

The AsteRx SB ProDirect has 16 GB of memory for internal data logging.

4.2.1 Internal logging

Step 1: Defining the Disk Full action

When setting up a logging session for the first time, it is a good idea to define what you would like to happen when the internal memory is full. This can be configured in the **Advanced** tab of the main page of the **Logging** menu as shown in Figure 4-12. There are two options, either the receiver stops logging when the memory is full or it continues logging by making space for new files by deleting the oldest files. The default setting is 'Stop logging in all sessions'.



The screenshot shows the web interface of the AsteRx SB ProDirect receiver. At the top, there is a navigation bar with tabs: Overview, GNSS, Communication, Corrections, NMEA/SBF Out, Logging, and Admin. The Logging tab is selected. Below the navigation bar, there is a section for Disk Usage showing a pie chart for the Internal Disk (13.7 GB) with 0% used (112.0 KB) and 100% free (13.7 GB). Below this, there is a section for Enable Logging with a radio button set to 'off'. The main content area has three tabs: General, Advanced, and Disk Contents. The Advanced tab is selected. Under the Advanced tab, there is a section for Marker and Station Parameters with fields for Marker name (SEPT), Marker number (Unknown), Marker type (Unknown), Station code, Monument index (0), Receiver index (0), and Country code. Below this, there is a section for Disk Full Action with a dropdown menu set to 'StopLogging'. Below that, there is a section for Global File Naming Options with a radio button set to 'on'. At the bottom, there is a section for USB Mass-Storage Device Configuration with a radio button set to 'off'. At the very bottom, there are buttons for Default and Ok.

Figure 4-12: Selecting what you wish to happen when the internal 16 GB memory is full

Step 2: Configuring a logging session

To define a new logging session, press **New NMEA Stream** or **New SBF Stream** as shown in Figure 4-13.




Figure 4-13: Defining a new logging session

You can then follow the sequence of steps shown in Figure 4-14, selecting the various configuration settings for the logging session. In the **Edit SBF Stream** window, the messages required for RINEX generation have been selected as well as those useful for the Support department for diagnosing problems. SBF messages can also be selected individually. In the **SBF Logging Parameters** field you can select the naming convention. The **IGS** options names files according to IGS convention but files can also be freely named using either **Filename** or **Incremental** options. After you have finished configuring the log session, do not forget to enable logging and press Ok.




Figure 4-14: Follow the sequence of windows to fully configure the logging session

Step 3: Verifying the configuration

When you have finished configuring the logging session, the **Log Sessions** window will show a summary of the defined logging sessions as in Figure 4-15. An estimate of the daily size of data generated with the current logging configuration is also given.






Figure 4-15: A summary of the newly defined logging sessions showing the expected amount of data generated daily

4.3 Downloading logged data from the receiver

Data files logged by the AsteRx SB ProDirect can be downloaded using the web interface using the **Disk Contents** tab on the main page of the **Logging** menu. Individual files can be downloaded by clicking on the green download arrow  next to the file name as shown in Figure 4-16. Obsolete files can be deleted by clicking the  button.




Figure 4-16: Downloading logged files

A Rear-panel port descriptions

A.1 PWR-COM2&3/USB




Figure A-1: Solder view of the 7-pin female PWR-COM2&3/USB socket on the rear panel of the AsterX SB ProDirect

The 7-pin connector type is an ODU MINI-SNAP F Circular Connector Series S40F1C-P07MCD0-500S.

PIN #	Colour	COM mode	USB mode	Comment
1	Red	PWR	Not connected	5-36 VDC input (1.3A) Pink wire with Red heat-shrink tube
2	Black	GND	GND	Ground Brown wire with Black heat-shrink tube
3	Green	RxD3	USB D-	EITHER Serial COM3 receive line OR Negative USB 2.0 FS device node. Selection is done via pin 7.
4	Yellow	TxD3	Not connected	Serial COM3 transmit line
5	Grey	RxD2	USB D+	EITHER Serial COM2 receive line OR Positive USB 2.0 FS device node. Selection is done via pin 7.
6	White	TxD2	Not connected	Serial COM2 transmit line
7	Blue	Not connected	VBus	4.4-5.25 V input. If present , USB-mode is selected. If not present , UART Serial COM mode is selected.

A.2 COM1-GPIO




Figure A-2: Solder view of the 7-pin female COM1-GPIO socket on the rear panel of the AsterX SB ProDirect

The 7-pin connector type is an ODU MINI-SNAP F Circular Connector Series S40F1C-P07MCD0-500S.

PIN #	Colour	Name	Comment
1	Pink	EVENTA	First EVENT input (Max. V_{IL} = 1V, Min. V_{IH} = 2V, Max. V_{IH} = 24V, Internal delay to detection < 1 μ s, 15 K Ω pull-down)
2	Black	GND	Ground Brown wire with Black heat-shrink tube COM1 Clear to Send.
3	Green	COM1 CTS/ EVENTB	This also connects to the second event EVENTB input. It has the same electrical specifications as EVENTA (see pin 1).
4	Yellow	COM1 RTS/ PPS_OUT	COM1 Request To Send or PPS_OUT (PPS_OUT low = 0V, PPS_OUT high = 5V). PPS_OUT polarity is consistent with command line reference of OEM module.
5	Grey	RxD1	Serial COM1 receive line
6	White	TxD1	Serial COM1 transmit line
7	Red	5V OUT	5V +/- 5%, 300 mA DC output Blue wire with Red heat-shrink tube

A.3 ETH




Figure A-3: Solder view of the 4-pin female ETH socket on the rear panel of the AsteRx SB ProDirect

The 4-pin connector type is an ODU MINI-SNAP F Circular Connector Series S40F1C-P04MFG0-5000.

PIN #	Name	Description
1	TXP	Ethernet TX+
2	TXN	Ethernet TX-
3	RXP	Ethernet RX+
4	RXN	Ethernet RX-

A.4 MAIN ANT / AUX ANT (TNC)

Connect an active GNSS antenna to these connectors. The gain at the connectors (antenna gain minus cable losses) must be in the range 15 to 50dB.

By default, the receiver provides a 3.3V DC supply on both the MAIN and AUX connectors to feed the antennas. The supplied antenna voltage can be changed to 5V DC with the command `setAntennaVoltage`. The maximum supported current is 200mA.



Never inject a DC voltage into the MAIN or AUX connectors as it may damage the receiver. When using a splitter to distribute the antenna signal to several receivers, make sure that no more than one output of the splitter passes DC. Use DC-blocks otherwise.

