



AMBO TONY METER

AT COMMANDS

Revision – 0.1

Contact Information:

AMBO Technology

New Taipei City, Taiwan

Website: www.ambo.com.tw

Email: tyrone@ambo.com.tw

Phone: +886-2-3234-0520

Contents

AT Command Syntax	3
Module Operation	3
Energy Management	4
RESETWH - Resets Energy Counter	4
READ - Reads AC parameters.....	4
TOTAL – Total Power	5
Load Management	5
RELAY – Controlling Relays	5
STORED – Getting the Stored Relay Status	5
TIMEOUTCTL – Controlling Relays with Timeout	6
ENABLE – Enabling/Disabling a Channel.....	6
ADC – Setting ADC Channel	7
RELAYPINS – Changing Relay Pin(s).....	8
POLARITY – Control Signal Polarity	8
RELAYCNT – Counting the Number of Relay Switching.....	9
ONDELAY and OFFDELAY - Relay Time Compensation	9
OVERLOAD – Setting the Overload Protection Threshold.....	10
NOLOAD – Setting No-load Protection Threshold	10
UNDERVOLT – Setting Under-Voltage Threshold	11
OVERVOLT – Setting Over-Voltage Threshold	11
IO – Controlling GPIO pins	12
IOCLEAR – Clearing the Setting of a GPIO.....	12
RESDETECT – Enable Residual Current Detection	12
RESVAL – Reading Residual Current.....	13
FREQ – Getting the Frequency	13
Module Management.....	13
ID – Getting the Identify Number.....	13
UGAIN – Voltage Calibration Factors	14
IGAIN – Current Calibration Factors	14
ZEROCROSS – Enable zero-cross output.....	15
RESSEN – Residual Sensitivity	15
AUTOCALIB – Start Auto-calibration Process	15

REBOOT – Reboot the Module.....	15
URC (Unsolicited Result Code)	15
+SYSSTART – System Start	15
+RESIDUALALERT – Residual Current Detected.....	16
+UNDERVOLTALERT and +OVERVOLTALERT – Voltage Alerts	16
+NOLOADALERT and +OVERLOADALERT – Current Alerts	16
+TIMEOUTNOTIFY – Notify Timeout	16
Error Codes	16
Example Setting.....	17
Revision History.....	19

AT Command Syntax

Each AT command starts with "AT+" and ends with <CR><LF> (0x0D and 0x0A). There are three types of commands:

- Write command **AT+<x>=<...>**: This command sets user-definable parameters.
- Read command **AT+<x>?<...>**: This command gets parameters or statuses. It also provides an optional parameter to indicate which channel to get.
- Execution command **AT+<x>**: This command executes a function of the module.

Depend on the requested command, the meter may or may not return a response. If there is a response, it starts with +<x>: where <x> is the requested command. If the command does not need any specific reply, the meter returns **OK** instead.

If there is something wrong when the module is executing the command, it sends back an error message. The format of an error message is **ERROR:<reason>**.

The module also provides URC (Unsolicited Result Code) to notify users whenever an event occurs on the loads, and it needs users' attention.

Module Operation

For providing more flexible in the PCB design process, the module uses logical channels (in this document, we use "channel" for logical channels) to manage loads. Current sense channels and residual sense channels can be freely assigned to one of the logical channels, as long as they do not conflict with the others. Each channel has an independent set of configurations. The settings of the channels are:

- Current sense channel
- Residual sense channel
- Control pin(s)
- Thresholds.

There are 4 logical channels in each module, and they are enumerated from 0 to 3. Figure 1 shows the operation of each channel.




Figure 1: Tony Meter operation

Energy Management

RESETWH - Resets Energy Counter

Reset the energy counter of a logical channel. The “**channel**” parameter is a number from 0 to 3.

Syntax:

AT+RESETWH=<channel>\r\n

READ - Reads AC parameters

This command reads AC parameters of a logical channel. The “**channel**” parameter is a number from 0 to 3.

Syntax:

AT+READ?<channel>\r\n

Response:

+READ:<channel>,<voltage>,<current>,<power>,<energy>\r\n

The scale factors for the parameters are 100, 1000, 100, and 1, respectively. And, the units of them are V, A, W, and Wh, respectively.

Example:

+READ:0,22000,5000,110000,10

The response means the module is running with 220.00 V, the current of the channel 0 is 5A, and the power is 1100W. The energy counter for this channel is 10Wh.

TOTAL – Total Power

This command reads total parameters from all channels.

Syntax:

AT+TOTAL?\r\n

Response:

+TOTAL:<voltage>,<current>,<power>,<energy>\r\n

The format of the values in the response is the same as the **READ** command.

Load Management

RELAY – Controlling Relays

Users cannot call this command on a disabled channel.

Syntax:

AT+RELAY=<channel>,<level>\r\n

Each module has an embedded EEPROM to store the last relay status. Users can get these statuses by using the query form of this command.

Syntax:

AT+RELAY?\r\n

Response:

+RELAY:<channel 0>,<channel 1>,<channel 2>,<channel 3>\r\n

Example:

+RELAY:0,1,1,0\r\n

The response means relay 0 and relay 3 is off, relay 1 and relay 2 is on.

STORED – Getting the Stored Relay Status.

When a user controls a load, the status of the load is stored in a built-in EEPROM. The user can read these values to restore the last status if necessary.

Syntax:

AT+STORED?\r\n

Response:

+STORED:<channel 0>,<channel 1>,<channel 2>,<channel 3>\r\n

Example:

+STORED:0,1,1,0\r\n

TIMEOUTCTL – Controlling Relays with Timeout

This command sets a channel to a state and toggles it after a delay. If users control the relay during the interval, the scheduled command is canceled. The maximum time for this command is 518400 seconds (one week).

Syntax:

AT+TIMEOUTCTL=<channel>,<level>,<timeout in seconds>\r\n

Syntax:

AT+TIMEOUTCTL?<channel>\r\n

Response:

+TIMEOUTCTL:<channel>,<level>,<remain time in seconds>\r\n

Example:

AT+TIMEOUTCTL=0,1,10\r\n

AT+TIMEOUTCTL=0,0,10\r\n

The first command turns on the relay of channel 0 and turns it off after 10 seconds. The second command turns off the relay of channel 1 and turns it on after 10 seconds.

ENABLE – Enabling/Disabling a Channel

Enabling or disabling a channel. In this command, “1” means enabling, and “0” means disabling. When users call this command, the module enables this channel if all settings are valid, and the settings do not conflict with other enabled channels. The module returns an error code if there is any problem.

Syntax:

AT+ENABLE=<channel>,<0/1>\r\n

Users can check which channels are enabled by using the query form.

Syntax:

AT+ENABLE?\r\n

Response:

+ENABLE:<channel 0>,<channel 1>,<channel 2>,<channel 3>\r\n

Example:

+ENABLE:0,1,1,0

The response means channel 1 and channel 2 are enabled; channel 0 and channel 3 are disabled.

ADC – Setting ADC Channel

This command assigns a high-accuracy ADC to a channel. Users cannot call this command if the channel is enabled. Users can reverse the current of the ADC channel by setting the **reverse** parameter to 1, as shown in Figure 2.




Figure 2: The reverse parameter.

Syntax:

AT+ADC=<channel>,<adc channel>,<reverse>\r\n

Users can check the ADC channel of a control channel by using the query form.

Syntax:

AT+ADC?<channel>\r\n

Response:

+ADC:<channel>,<adc channel>,<reverse>\r\n

Example:




Figure 3: A sample of current sensing connections.

For the connection in Figure 3, users should use the following commands to configure the module. Note that we need to enable the “reverse” parameter of the channel 3 because the CHAN_3_IN signal is connected to I1N.

AT+ADC=0,3,0\r\n

AT+ADC=1,2,0\r\n

AT+ADC=2,1,0\r\n

AT+ADC=3,0,1\r\n

RELAYPINS – Changing Relay Pin(s)

This command assigns a pin (or pins for 2-coil latching relays). Depending on the coil type, this command may require 2 or 3 parameters. Users cannot call this command if the channel is enabled.

Number	Type
0	Non-latching coil
1	1-coil latching
2	2-coil latching

Syntax:

AT+RELAYPINS=<channel>,<coil type>,<pin 1>[,<pin 2>]\r\n

Example:

AT+RELAYPINS=1,0,2\r\n

AT+RELAYPINS=0,2,6,7\r\n

In the example, the channel 1 controls a non-latching relay (type 0) with pin 2, and channel 0 controls a 2-coil latching relay with pin 6 and pin 7.

Users can check which pin is using by using the query form.

Syntax:

AT+RELAYPINS?<channel>\r\n

Response:

+RELAYPINS:<channel>,<coil type>,<pin 1>[,<pin 2>]\r\n

Example:

AT+RELAY?1\r\n

+RELAYPINS:1,0,2\r\n

POLARITY – Control Signal Polarity

Sometimes, users need to invert the polarity of the control signal to compatible with their designs. The users can reverse the logic level of control by this command. Users cannot call this command if the channel

is enabled. By default, the activated state is logic 1, and the inactive state is logic 0. Figure 4 shows examples circuit for the two types of the parameter. Note that IO6 and IO13 are open-drain pins; they do not work with the left circuit in Figure 4.




Figure 4: Sample applications for the polarity parameter.

Syntax:

AT+POLARITY=<channel>,<0/1>\r\n

Users can also query this parameter by using its query form.

Syntax:

AT+POLARITY?<channel>\r\n

Response:

+POLARITY:<channel>,<0/1>\r\n

RELAYCNT – Counting the Number of Relay Switching

Users can check how many times a relay change its state.

Syntax:

AT+RELAYCNT?<channel>\r\n

Response:

+RELAYCNT:<channel>,<count>\r\n

ONDELAY and OFFDELAY - Relay Time Compensation

When a relay changes its state, it takes a small amount of time (several milliseconds) to switch to the new state. The time varies between relay parts. Therefore, users must tune these parameters to get an

accurate result. The number is represented in sixth-millisecond blocks. For example, if the set time is 2 milliseconds, the parameter is 12.

Syntax:

AT+ONDELAY=<channel>,<set time>\r\n

AT+OFFDELAY=<channel>,<reset time>\r\n

Users can check these parameters by using their query form.

Syntax:

AT+ONDELAY?<channel>\r\n

AT+OFFDELAY?<channel>\r\n

Response:

+ONDELAY:<channel>,<set time>\r\n

+OFFDELAY:<channel>,<reset time>\r\n

OVERLOAD – Setting the Overload Protection Threshold

Set the overload protection limit for the module. The module switches off the relay if the current of a channel exceeds this value for the “**delay time**”. Users can disable this feature by setting the current threshold to the rating current.

Syntax:

AT+OVERLOAD=<channel>,<current in mA>,<delay time in ms>\r\n

Users can check these parameters by using its query form.

Syntax:

AT+OVERLOAD?<channel>\r\n

Response:

+OVERLOAD=<channel>,<current in mA>,<delay time in ms>\r\n

NOLOAD – Setting No-load Protection Threshold

Set the no-load protection threshold for the module. The module switches off a relay if the current of the channel is under a threshold after the “**delay time**”. Users can disable this feature by setting the current threshold to 0 mA.

Syntax:

AT+NOLOAD=<channel>,<current in mA>,<delay time in ms>\r\n

Users can check these parameters by using its query form.

Syntax:

AT+NOLOAD?<channel>\r\n

Response:

+NOLOAD=<channel>,<current in mA>,<delay time in ms>\r\n

UNDERVOLT – Setting Under-Voltage Threshold

Set the under-voltage protection threshold for the module. The module switches off all relays if the voltage is smaller than a threshold after the “**delay time**”. Users can disable this feature by setting the threshold to 0V.

Syntax:

AT+UNDERVOLT=<threshold>,<delay time in ms>\r\n

Syntax:

AT+UNDERVOLT?\r\n

Response:

+UNDERVOLT:<threshold>,<delay time in ms>\r\n

Example:

AT+UNDERVOLT=20000,1000\r\n

After executing the command, the module sends a **+UNDERVOLT** alert if the voltage is smaller than 200V for 1s.

OVERVOLT – Setting Over-Voltage Threshold

Set the over-voltage protection threshold for the module. The module switches off all relays if the voltage is bigger than a threshold after the “**delay time**”. Users can disable this feature by setting the threshold to a large value. The default threshold is 400V.

Syntax:

AT+OVERVOLT=<threshold>,<delay time in ms>\r\n

Syntax:

AT+OVERVOLT?\r\n

Response:

+OVERVOLT:<threshold>,<delay time in ms>\r\n

Example:

AT+OVERVOLT=30000,1000\r\n

After executing the command, the module sends a **+OVERVOLT** alert if the voltage is larger than 300V for 1s.

IO – Controlling GPIO pins

Users can control the output of unassigned IO pins. If the pin is busy, the module returns the **USED-PIN** code.

Syntax:

AT+IO=<pin>,<logic>\r\n

IOCLEAR – Clearing the Setting of a GPIO

Clear the setting of a specific GPIO pin. After executing this command, the pin becomes high-impedance input.

Syntax:

AT+IOCLEAR=<pin>\r\n

RESDETECT – Enable Residual Current Detection

This command enables the ADC feature of the pins from IO8 to IO11. If the pin is busy, the module returns the **USED-PIN** code. The “**adc pin**” parameter is a number from 0 to 3. The “**thresh**” is the RMS of residual current.

Syntax:

AT+RESDETECT=<channel>,<adc pin>,<gain>,<thresh>\r\n

Users also can check which channel is enabled by using the query form.

Syntax:

AT+RESDETECT?<channel>\r\n

Response:

+RESDETECT:<channel>,<gain>,<thresh>\r\n

Example:




Figure 5: An example of a residual current detection circuit.

Suppose we want to turn off our load at channel 0 if the residual current is larger than 30 mA and have the circuit like Figure 5. The ratio of the current transformer (CT) is 2000:1, the resistor is 13 ohms, the gain factor of the op-amp is 20, and the ADC pin is 1. The command should be:

AT+RESDETECT=0,1,130,30\r\n

Where the gain is: $\frac{1}{2000} \times 13 \times 20 \times 1000 = 130$.

RESVAL – Reading Residual Current

This command reads the residual current of a channel. The “**channel**” parameter is a number from 0 to 3. The value returned by this command depends on the **gain** parameter of the **RESDETECT** command. By default, the **gain** parameter is 1.

Syntax:

AT+RESVAL?<channel>\r\n

Response:

+RESVAL:<channel><current in mA>\r\n

Example:

+RESVAL:0,10

The response means that the residual current of channel 0 is 10 mA.

FREQ – Getting the Frequency

This command gets the current frequency of the voltage signal. The scale factor of the frequency is 100.

Syntax:

AT+FREQ?\r\n

Response:

+FREQ:<frequency>\r\n

Example:

+FREQ:5000\r\n

The response means the frequency of the voltage signal is 50 Hz.

Module Management

ID – Getting the Identify Number

This command gets the unique 128-bit ID number of the module. The result of this command is in the hexadecimal format.

Syntax:

AT+ID?\r\n

Response:

+ID:<id number in hexadecimal>\r\n

Example:

+ID:F151000054EA00260025200331534E42\r\n

UGAIN – Voltage Calibration Factors

This command gets the calibration factors of the voltage measurement.

Syntax:

AT+UGAIN=<factor 1>,<factor 2>,<factor 3>\r\n

Users can check these factors by using the query form.

Syntax:

AT+UGAIN?\r\n

Response:

+UGAIN:<factor 1>,<factor 2>,<factor 3>\r\n

Examples:

+UGAIN:2072134208,1752,-4992\r\n

IGAIN – Current Calibration Factors

This command gets the calibration factors of the current measurement.

Syntax:

AT+IGAIN=<channel>,<factor 1>,<factor 2>,<factor 3>\r\n

Users can check these factors by using the query form.

Syntax:

AT+IGAIN?<channel>\r\n

Response:

+IGAIN:<channel>,<factor 1>,<factor 2>,<factor 3>\r\n

Example:

+IGAIN:0,1289960380,1024,143409\r\n

ZEROCROSS – Enable zero-cross output

If users want to control their loads, the module can send out zero-cross pulses to help them control the relays precisely. If the pin is busy, the module returns the **USED-PIN** code. The pin generates a square-wave signal. The frequency of the signal is half of the mains frequency.

Syntax:

AT+ZEROCROSS=<pin>\r\n

RESSEN – Residual Sensitivity

This command sets the sensitivity level of the module. The more sensitivity, the quicker the module reacts to the residual current, but the probability of false alarms also larger. There are three levels of sensitivity. They are enumerated from 0 to 2. The default sensitivity is level 1.

Syntax:

AT+RESSEN=<level>\r\n

Users can check the sensitivity level by using the query form.

Syntax:

AT+RESSEN?\r\n

AUTOCALIB – Start Auto-calibration Process

This command starts the auto-calibration process of the module. Once this mode is activated, users can only stop it by resetting the module or the wait for the calibration success. **Users should not use this command.**

Syntax:

AT+AUTOCALIB\r\n

REBOOT – Reboot the Module

When a module receives this command, it resets immediately and does not give any feedback.

Syntax:

AT+REBOOT\r\n

URC (Unsolicited Result Code)

+SYSSTART – System Start

Syntax:

+SYSSTART\r\n

The module sends this code every time it finishes the boot-up process. If users receive this message, the users can start to set the module's parameter. If the users receive this URC during the module operation, probably, there are problems in the system.

+RESIDUALALERT – Residual Current Detected

Syntax:

+RESIDUAL:<channel>\r\n

The module sends this code if there is a leakage current on a channel.

+UNDERVOLTALERT and +OVERVOLTALERT – Voltage Alerts

Syntax:

+UNDERVOLTALERT\r\n

+OVERVOLTALERT\r\n

The module sends this code if the voltage is larger or smaller than a predefined range. The range can be set by **OVERVOLTALERT** and **UNDERVOLTALERT** command.

+NOLOADALERT and +OVERLOADALERT – Current Alerts

Syntax:

+NOLOADALERT:<channel>\r\n

+OVERLOADALERT:<channel>\r\n

The module sends this code if the current of a channel is larger or smaller than a predefined range. The range can be set by **NOLOADALERT** and **OVERLOADALERT** commands.

+TIMEOUTNOTIFY – Notify Timeout

Syntax:

+TIMEOUTNOTIFY:<channel>,<state>\r\n

The module sends this code if a deadline of **+TIMEOUTCTL** is met.

Error Codes

Table 1: Error codes

Error string	Problems	Resolve
NOT-FOUND	The command is wrong.	Users should check the input commands.
TOO-LONG	The line is too long to process (more than 128 bytes).	Make sure all commands end with “\r\n”.
INVALID-PARAM	The parameters for the requested command are invalid.	Users should check the parameters.
INVALID-CHARACTER	The command contains an invalid character.	If the module sends this code rapidly without any input, users should check the serial port connection.

		<p>If the module sends this code after executing a command, retry the command.</p> <p>If the error code appears frequently, users should check the serial port connection.</p>
RELAY-CONTROL-FAILED	The module cannot control the relay because the module cannot detect zero-crosses.	Replace another module.
USED-PIN	The module cannot assign a function to a defined pin.	Check the settings.
DENIED	The module does not allow to execute the command.	<p>If users receive this error after executing a RELAY, a RELAYPINS, or an ADC command, make sure the channel is disabled.</p> <p>If users receive this error after an IOCLEAR command, make sure the parameter is not one of the pins the serial port (IO4 and IO5).</p>

Example Setting

Table 2 shows the commands to set up an application. In which, the module control 4 2-coil latching relays, the current buffers invert the outputs of the control pins, and the relays take 2ms to change state.

Table 2: An example setting

AT+ENABLE=0,0 AT+ENABLE=1,0 AT+ENABLE=2,0 AT+ENABLE=3,0 AT+ADC=0,3,0 AT+ADC=1,2,0 AT+ADC=2,1,0 AT+ADC=3,0,0 AT+RELAYPINS=0,2,12,13 AT+RELAYPINS=1,2,10,11 AT+RELAYPINS=2,2,8,9 AT+RELAYPINS=3,2,6,7	<p>Disable all channels to prevent unexpected conflicts.</p> <p>Channel 0 uses I3 without reverse. Channel 1 uses I2 without reverse. Channel 2 uses I1 without reverse. Channel 3 uses I0 without reverse. Channel 0 controls a 2-coil latching relay. Pin 12 energizes the set coil, and pin 13 energizes the reset coil. Channel 1 controls a 2-coil latching relay. Pin 10 energizes the set coil, and pin 11 energizes the reset coil. Channel 2 controls a 2-coil latching relay. Pin 8 energizes the set coil, and pin 9 energizes the reset coil. Channel 3 controls a 2-coil latching relay. Pin 6 energizes the set coil, and pin 7 energizes the reset coil.</p>
--	---

AT+POLARITY=0,1 AT+POLARITY=1,1 AT+POLARITY=2,1 AT+POLARITY=3,1 AT+ONDELAY=0,12 AT+ONDELAY=1,12 AT+ONDELAY=2,12 AT+ONDELAY=3,12 AT+OFFDELAY=0,12 AT+OFFDELAY=1,12 AT+OFFDELAY=2,12 AT+OFFDELAY=3,12 AT+ENABLE=0,1 AT+ENABLE=1,1 AT+ENABLE=2,1 AT+ENABLE=3,1	<p>A coil is energized when the control pin is 0 and de-energized when the control pin is 1.</p> <p>Relays take approximately 2 milliseconds to close.</p> <p>Relays take approximately 2 milliseconds to open.</p> <p>Enable all channels, apply the configurations.</p>
--	---

Revision History

Version	Date	Description
0.1	13/01/2016	First version