

# **DGUI \***

Version 2, Revision 5, 20-Jan-2024

## **USER GUIDE FOR THE GUI ACCOMPANYING THE BEAM DYNAMICS CODE DYNAC**

Modified and maintained by:  
E. Tanke

Contact:  
E. Tanke, e-mail: [dynacatgithub@gmail.com](mailto:dynacatgithub@gmail.com)

DYNAC WEBSITE  
<https://github.com/dynac-source>

\* See Software License Agreement on next page

## Software License Agreement

### NOTICE TO USERS:

This End User License Agreement (the "Agreement") is a legally binding agreement between you (either an individual or an entity, the "User"), and the DYNAC main developer (currently Eugene Tanke) regarding a) the DYNAC software (the "Software" or the "Program", which includes scripts and the DYNAC Graphical User Interface (DGUI) software), and b) all successor upgrades, revisions, patches, fixes, modifications, copies, additions or maintenance releases of the Software, if any, licensed to you by the DYNAC main developer (collectively, the "Updates"), and c) related user documentation and explanatory materials or files provided in written, "online" or electronic form (the "Documentation" and together with the Software and Updates, the "PRODUCT" or the "Distribution Package").

CAREFULLY READ THE FOLLOWING LEGAL AGREEMENT. USE OF THE PRODUCT PROVIDED WITH THIS AGREEMENT CONSTITUTES YOUR ACCEPTANCE OF THESE TERMS. IF YOU DO NOT AGREE TO THE TERMS OF THIS AGREEMENT, DO NOT INSTALL AND/OR USE THE PRODUCT. YOUR USE OF THE PRODUCT IS CONDITIONED UPON COMPLIANCE WITH THE TERMS OF THIS AGREEMENT.

### 1. Intellectual property rights

The DYNAC Program and associated software ("PRODUCT") is owned by the DYNAC main developer. Your possession, installation or use of the PRODUCT does not transfer to you any title to the intellectual property in the PRODUCT, and you will not acquire any rights in the PRODUCT except as expressly set forth in this Agreement.

The DYNAC Program and associated software is freeware and as such the authors cannot be held accountable for any problems and or costs arising from its usage. As freeware, DYNAC and associated software may be used for commercial goals, with the exception of commercializing DYNAC PRODUCT, parts of the DYNAC Program and/or associated software itself.

### 2. Scope of the License

You are granted a non-exclusive license to use the PRODUCT as set forth herein. You can use the PRODUCT as set forth in the Agreement for non-commercial purposes in non-business, non-commercial environment. As freeware, DYNAC and associated software may be used for commercial goals, with the exception of commercializing DYNAC, parts of DYNAC and/or associated software itself.

The Software may be freely distributed, but no person or company may charge a fee for the distribution of the PRODUCT without written permission from the DYNAC main developer.

### 3. Limited warranties

The DYNAC main developer DOES NOT WARRANT THAT THE SOFTWARE IS FIT FOR ANY PARTICULAR PURPOSE. The DYNAC main developer DISCLAIMS ALL OTHER WARRANTIES WITH RESPECT TO THE SOFTWARE, EITHER EXPRESS OR IMPLIED. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES OR LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY MAY LAST, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU.

### 4. Legality statement

The program that is licensed to you is absolutely legal and you can use it provided that you are the legal owner of all files or data you are going to use with our software or have permission from the legitimate owner to perform these acts. Any illegal use of our software will be solely your responsibility. Accordingly, you affirm that you have the legal right to access all data, information and files.

You further attest that the data and/or files will not be used for any illegal purpose.

### 5. Final provisions

All rights not expressly granted here are reserved by the DYNAC main developer.

# INDEX

- 1 INTRODUCTION**
- 2 INSTALLATION**
  - 2.1 Installation of python3.10**
    - 2.1.1 MAC Specifics**
    - 2.1.2 Linux Specifics**
    - 2.1.3 Windows Specifics**
  - 2.2 Installation of DGUI**
    - 2.2.1 Updating DGUI**
  - 2.3 Testing DGUI**
- 3 PREPARING FOR EASE OF USE**
  - 3.1 MAC**
  - 3.2 Linux**
  - 3.3 Windows**
- 4 USER INTERFACE**
  - 4.1 MAIN WINDOW MENU BAR**
  - 4.2 VISUALIZING STORED PARTICLE DISTRIBUTIONS**
  - 4.3 DYNAC PROGRAM EXECUTION**
  - 4.4 PLOTS BASED ON THE DYNAC INPUT FILE**
  - 4.5 PLOTTING WITH THE GUI**
  - 4.6 WORKING WITH PROJECT DIRECTORIES**
- 5 GLOSSARY**
- 6 KNOWN ISSUES**

## 1 INTRODUCTION

To give an alternative to DYNAC program execution and data analysis from the command line in a shell, a Graphical User Interface (GUI) has been written. Like for the DYNAC code itself, the GUI (called DGUI) can be used on three different operating systems (linux, MAC and Windows). DGUI V1 was based on the DISLIN graphics package, whereas DGUI V2 is based on python3. The intent is to stay with a python-based GUI. This User Guide (UG) will walk you through the steps to get started.

With DGUI, the user can:

- select a particle distribution file (.dst) and plot it, plot its concomitant profiles or plot both
- select a DYNAC input file and subsequently execute the DYNAC code with this file with the DYNAC binary of choice
- start the “plotit” facility (see DYNAC UG) to plot the graphs requested in the DYNAC input file
- plot RMS emittances as a function of the longitudinal coordinate z
- plot beam energy and phase as a function of the longitudinal coordinate z
- plot beam size (extremes and or RMS) as a function of the longitudinal coordinate z
- plot the beam centroid (horizontal and vertical) and transmission
- plot horizontal and vertical dispersion as a function of the longitudinal coordinate z
- plot beam losses as a function of the longitudinal coordinate z

In addition, graph limits can be changed and the graphs can be copied and/or saved as files.

Functionality will be added over time to the GUI, whereby user input is very much encouraged.

## 2 INSTALLATION

Prior to installing the DYNAC GUI, one will need to ensure one has the appropriate Python version and Python libraries installed. This is covered in section 2.1 below.

This chapter covers the entire initial installation of the graphics software components. For installation of DGUI updates, and assuming python3.10 and the python3.10 libraries needed by DGUI are already installed on your system, you can skip section 2.1.

### 2.1 Installation of python3.10

This section describes how to install python3.10, with specifics given for three different operating systems.

In what follows, shell/terminal commands are marked in magenta text, output to the shell terminal is marked in blue. At the time of release of this UG, functionality of DGUI V2R5 had been successfully tested with python versions 3.8, 3.9 and 3.10 on linux mint 20 (Uma), windows (11) and MAC (Big Sur).

#### 2.1.1 MAC Specifics

One of the GUI buttons invokes gnuplot with an x11 terminal. Check that the x11 terminal works properly with gnuplot (see also DGS00006 in chapter 6.2).

##### 2.1.1.1 Python installation

To verify if python3 is installed and operable, open a terminal window and type

`python3 -V`

and you should then see something like the following:

Python 3.10.4

The actual version will depend on the version of python you installed but has to be a Python 3 version (not a Python 2 version).

If python3 is not installed, download python3 from <https://www.python.org/downloads/> and follow instructions for installation.

##### 2.1.1.2 Installation of Python libraries required by DGUI

To install these Python libraries; one can use the pip3 facility. Make sure pip3 is up to date with:

`pip3 install --upgrade pip`

Install the required libraries:

```
pip3 install numpy
pip3 install matplotlib
pip3 install pandas
pip3 install pyqtgraph
pip3 install pyqt5
pip3 install scipy
pip3 install lmfit
pip3 install colorcet
```

Alternatively, and depending on your python installation, you can use commands like

```
python3 -m pip install pyqt5
```

If the system complains about insufficient privileges, you may need to insert **sudo -H** in front of the offending command, e.g.

```
sudo -H pip3 install matplotlib
```

### 2.1.2 Linux Specifics

#### 2.1.2.1 Python installation

To verify if python3 is installed and operable, open a terminal window and type

```
python3 -V
```

or, depending on your installation, for instance

```
python3.10 -V
```

and you should then see something like the following:

[Python 3.10.4](#)

The actual version will depend on the version of python you installed but has to be a Python 3 version (not a Python 2 version).

If python3 is not installed, download python3 from <https://www.python.org/downloads/> and follow instructions for installation.

#### 2.1.2.2 Installation of Python libraries required by DGUI

To install these Python libraries; one can use the pip facility. You can check the version of pip with:

```
python3.10 -m pip --version
```

Install the required libraries:

```
python3.10 -m pip install numpy
python3.10 -m pip install matplotlib
python3.10 -m pip install pandas
python3.10 -m pip install pyqtgraph
python3.10 -m pip install pyqt5
python3.10 -m pip install scipy
python3.10 -m pip install lmfit
python3.10 -m pip install colorcet
```

If the system complains about insufficient privileges, you may need to insert **sudo -H** in front of the offending command, e.g.

```
sudo -H python3.10 -m pip install matplotlib
```

### 2.1.3 Windows Specifics

#### 2.1.3.1 Python installation

To verify if python3 is installed and operable, open a DOS window and type

```
python -V
```

and you should then see something like the following:

[Python 3.10.4](#)

The actual version will depend on the version of python you installed but has to be a Python 3 version (not a Python 2 version).

If python3 is not installed, download python3 from <https://www.python.org/downloads/windows> and follow instructions for installation. As an example, one can use the Windows X86-64 executable installer.

#### 2.1.3.2 Installation of Python libraries required by DGUI

To install these Python libraries; one can use the pip facility. Make sure pip is up to date with:

```
pip install --upgrade pip
```

or if this gives you an error, you will be prompted with an alternative command. This may require using a DOS window with administrative privileges.

Install the “wheel” library:

```
pip install wheel
```

and install these required libraries:

```
pip install pyqtgraph
```

```
pip install pyqt5
```

```
pip install scipy
```

```
pip install lmfit
```

```
pip install colorcet
```

Also install these required libraries:

```
pip install pandas
```

```
pip install kiwisolver
```

```
pip install matplotlib
```

or download these last 3 libraries from <http://www.lfd.uci.edu/~gohlke/pythonlibs/> and install them, e.g.

```
pip install pandas-0.24.2-cp37-cp37m-win32.whl
```

The actual version number may be a more recent one than the ones listed here. Note that kiwisolver has to be installed before matplotlib.

If numpy was not installed when pyqtgraph was installed, then download it also from

<http://www.lfd.uci.edu/~gohlke/pythonlibs/> and install:

```
pip install numpy-1.13.0+mkl-cp36-cp36m-win32.whl
```

Again, the actual version number may be a more recent one than the one listed here.

## 2.2 Installation of DGUI

This UG, as well as other required files will be automatically installed if the full DYNAC package (V6R19 or newer, V7R2 is recommended) was obtained from the DYNAC webpage and successfully installed. You will then need to **rename the example *dgui.ini* file** you got **from the DYNAC web site to *dgui.ini***.

If, instead, you are only wanting to update an existing DGUI, then proceed to section 2.2.1.

The `dgui.py` script and the `dgui.ini` file will be located in the `dynac/dgui` folder (or `dynac\dgui` folder for windows). The first line in the `dgui.ini` file needs to be the path to the `dynac` executable, e.g.

`/Users/yourname/dynac/bin`

for linux or MAC and as an example for windows:

`C:\dynac\bin`

Following these mandatory lines in the `dgui.ini` file, the user can set preferred options. The lines with these options are not mandatory.

The default program to open the User Guide PDFs is Acrobat. On linux it may be of interest to change this to Evince or xreader (see section 4.1.3).

PDFVIEWER acrobat

PDFVIEWER evince

PDFVIEWER xreader

By default, when making density plots, the colormap (called “default” in the list below) that was available in DGUI V2R1 will be used. This can be changed by the user with the following entry in `dgui.ini`:

`COLORMAP my_preferred_colormap`

Here `my_preferred_colormap` is the colormap of your preference, but it needs to be one of the following:

`gnuplot2_r`

`gist_earth_r`

`gist_stern`

`viridis`

`nipy_spectral`

`jet`

`diverging_rainbow_bgymr_45_85_c67`

`rainbow_bgymr_35_85_c72`

`linear_tritanopic_krjcw_5_98_c46`

`linear_worb_100_25_c53`

`linear_wcmr_100_45_c42`

`linear_kryw_5_100_c67`

`linear_kryw_0_100_c71`

`default`

By default, when plotting profiles related to distribution files, raw data is being used. One can change this to plotting fitted data, whereby a Gaussian fit is used (see section 4.2.3).

PROFILES raw

PROFILES fitted

### 2.2.1 Updating DGUI

This section applies if you wish to update the existing DGUI software on your system.

In view of updating to DGUI V2R5 from older DGUI revisions, it is suggested to create a new sub-folder (e.g. named Archive) inside the `dynac/dgui` folder (`dynac\dgui` for windows). Rename the existing `dgui.py` (e.g. by appending `Version_Revision` to it) and move it to Archive. Likewise, in the `dynac/help` folder (`dynac\help` for Windows) create a new sub-folder (e.g. named Archive). Rename the existing UG (e.g. `DGUI_V2R4.pdf`) and move it to Archive.

Then download this UG (V2R5) to the `dynac/help` directory from the DYNAC website:

<https://github.com/dynac-source>

and the `dgui.py` script to the `dynac/dgui` directory. If not installed yet, also download the `dynicon.png` to the `dynac/bin` directory.

### 2.3 Testing DGUI

DGUI V2R5 requires python3.8 or newer. Check the version of python by typing one of the following (depending on operating system):

`python3.10 -V`

or

`python3 -V`

or

`python -V`

If you do not have python3 installed, then follow the instructions in section 2.1. If python3.8 or newer is successfully installed, you will need to add libraries that DGUI requires, if they are not installed already. Section 2.1 has instructions on how to add these.

Open a terminal window and go to the dgui directory. Run the DGUI executable by typing:

`python3 dgui.py -v`

or

`python3.10 dgui.py -v`

for MAC or Linux, or

`python dgui.py -v`

for Windows.

You should then see the text “DGUI” and the version and revision numbers and date, e.g.

DGUI V2R5 20-Jan-2024

The available options available at the startup of DGUI can be looked at by typing

`python3 dgui.py -h`

or

`python3.10 dgui.py -h`

for MAC or Linux, or

`python dgui.py -h`

for Windows.

You should then see the text DGUI and the version number, e.g.

usage: dgui.py [-h] [-v] [--version] [-p P]

DGUI V2R5 20-Jan-2024

optional arguments:

<code>-h, --help</code>	show this help message and exit
<code>-v</code>	show DGUI version number and exit
<code>--version</code>	show DGUI version number and exit
<code>-p P</code>	here P is the path to the location of dgui.py; no space between -p and the path! -pP is mandatory if none of the other optional arguments are used

Finally, for MAC or Linux, start DGUI by typing

`python3 dgui.py -ppath_to_dgui`

or

`python3.10 dgui.py -ppath_to_dgui`

Instead, for Windows type

`python dgui.py -ppath_to_dgui`

where `path_to_dgui` is the path to the location where dgui.py is stored. **There should be no space between “-p” and the path\_to\_dgui and no leading tilde ~ character in the path name.**

You should now obtain a window similar to the one in Fig.1.






Figure 1: DGUI window (this one for Windows 10, similar ones for MAC and linux)

Now click on “File” in the menu bar and select “Close DGUI”. Also, Ctrl-Q on Windows or command-Q on MAC will close DGUI.

### 3 PREPARING FOR EASE OF USE

The following steps are recommended for ease of use of the GUI and are OS dependent.

#### 3.1 MAC

Make an alias such that one can start DGUI without having to give the arguments each time you start the GUI. As an example, for the C-shell, something like the following line can be added in the .cshrc file (this file is located in the top directory):

```
alias dg 'python3 /path_to_dynac/dynac/dgui/dgui.py -ppath_to_dgui'
```

Of course, the paths need to be replaced by the appropriate ones in this example. **Again, there should be no space between “-p” and the path\_to\_dgui and no leading tilde ~ character in the path names.** Then either type

```
source .cshrc
```

or open a new shell/terminal window. You can now start DGUI by typing

```
dg
```

from any directory.

If you normally use the bash shell, you will need to edit .bashrc instead.

You can also make a shortcut, for instance on the desktop:

- In the folder of your preference, create a shell script file with the following contents:  

```
python3 /path_to_dynac/dynac/dgui/dgui.py -ppath_to_dgui
```

 whereby one needs to replace `path_to_dynac` and `path_to_dgui` by what applies and save the file with .sh as extension (in what follows, the file name dgsc.sh is assumed)
- Change the access mode to allow execution, e.g.  

```
chmod a+x dgsc.sh
```
- From the MAC **Applications**, run **Automator**
- Under **Choose a type for your document:** choose **Application** and click on **Choose**
- Type **run** in the Actions search box
- Double click **Run Shell Script**
- In the text box under “Run Shell Script” type the path to and name of your shell script, e.g.  

```
/home/william/dgsc.sh
```
- Next click **File** on the menu bar and select **Save...**
- Give the short cut a name and behind Where: select Desktop
- Next to **File Format:** select **Application**
- Click on **Save**

#### 3.2 LINUX

Make an alias such that one can start DGUI without having to give the arguments each time you start the GUI. As an example, for the bash-shell, something like the following line can be added in the .bashrc file (this file is located in the top directory):

```
alias dg='python3.10 /path_to_dynac/dynac/dgui/dgui.py -ppath_to_dgui'
```

Of course, the paths need to be replaced by the appropriate ones in this example. **Again, there should be no space between “-p” and the path\_to\_dgui and no leading tilde ~ character in the path names.** Then either type

```
source .bashrc
```

or open a new shell/terminal window. You can now start DGUI by typing

```
dg
```

from any directory.

If you normally use the C shell, you will need to edit .cshrc instead.

### 3.3 WINDOWS

Assuming you have added the `dynac\bin` directory to your Windows PATH, the following will make it such that one can start DGUI without having to give the arguments each time. Create a file called `dg.bat` in the `dynac\bin` directory and edit it to contain the following:

```
python c:\path_to_dynac\dynac\ogui\ogui.py -ppath_to_ogui
```

Of course, the paths need to be replaced by the appropriate ones in this example. **Again, there should be no space between “-p” and the path\_to\_ogui and no leading tilde ~ character in the path names.**

You can now start DGUI by typing

```
dg
```

from any directory.

You can also make a shortcut, for instance on the desktop:

- [Right-click](#) a blank space on the Windows desktop, a folder, or in a directory
- Move your mouse cursor over **New** in the [drop-down menu](#) that appears
- Then select **Shortcut**
- On the Create Shortcut window, type `c:\path_to_dynac\dynac\ogui\ogui.py -ppath_to_ogui` directly in the field under “Type the location of this item...”
- Then click **Next**
- Finally, give a name to the shortcut, e.g. `ogui`

One can access the User Guides from the GUI (see section 4.1.3), whereby on Windows, `AcroRd32.exe` will be used to open them. It may be necessary to add the path to this .exe to the Windows PATH, as an example do this by opening a DOS window and type:

```
set PATH=%PATH%;C:\Program Files (x86)\Adobe\Acrobat Reader DC\Reader
```

and

```
setx PATH "%PATH%;C:\Program Files (x86)\Adobe\Acrobat Reader DC\Reader"
```

If `AcroRd32.exe` is in a different directory than in this example, change the DOS commands accordingly. These commands only need to be given once.

## 4 USER INTERFACE

This chapter describes the functionality and usage of the GUI. To start DGUI, click on the DGUI short cut on the desktop (this assumes you followed instructions as per chapter 3) or open a terminal window (MAC/linux) or MS-DOS window (Windows) and type the following command (this assumes you followed instructions as per chapter 3):

**dg**

You should now have a window similar to the one shown in Fig.1.

In what follows, buttons and input fields on the GUI window are marked in magenta text, output to the terminal is marked in blue. To exit DGUI, click “**File**” on the menu bar and select “**Close DGUI**”.

### 4.1 MAIN WINDOW MENU BAR

#### 4.1.1 File

The options below “**File**” in the menu bar are:

“**Open input file**”, which has the same functionality as the “**Get input file**” button on the main window

“**Open dist. file**”, which has the same functionality as the “**Get dist. file**” button on the main window

“**Set project files directory**”, see section 4.6.

“**Save project files**”, see section 4.6.

“**Open dist. file**”, which has the same functionality as the “**Get dist. file**” button on the main window

“**Close DGUI**”, which will cause the DGUI and the DGUI options window (if open) to close. It will not close any graphics windows that may be open.

“**Close all windows**”, like “Close DGUI”, but it will also close any graphics windows that may be open.

#### 4.1.2 Options

There are 2 options below “**Options**” in the menu bar:

“**Print Screen**”, with which one can print the full screen to file.

“**List software versions**”, with which one can display the versions of the different software packages related to the DYNAC environment.

#### 4.1.3 Help

The UGs for DGUI as well as for DYNAC can be directly accessed by clicking on “**Help**” in the menu bar and selecting the UG of interest. The UGs are in the form of PDF files.

On **Windows**, AcroRd32.exe will be used to open them. You may need to add the path to this exe to the Windows PATH (see section 3.3).

On **MAC**, the “open” command will be used to open the PDF files.

On **linux**, xreader will be used by default. Alternatively, acroread or evince can be used. You can change your preference on the fly by clicking on the gray “**Options**” button: an options window will pop up (see Fig.7), from where one can select the “**acroread**” or “**evince**” button in the “Open User Guides” field. If you wish to change the default, open the dgui.ini file in the dynac/dgui directory and add or change the line containing PDFVIEWER, e.g.

PDFVIEWER acrobat

or

PDFVIEWER evince

#### 4.1.4 About

The “**About DGUI**” option below “**About**” in the menu bar will “about” information in a pop-up menu.

## 4.2 VISUALIZING STORED PARTICLE DISTRIBUTIONS

Click the “**Get dist. file**” button and select the distribution file (typically with .dst as file extension) of interest using the pop-up window.

If you do not have any distribution files yet, you can for instance use the procedure under 4.3 to run DYNAC, whereby one selects the SNS example input file from the dynac/datafiles directory. This input file uses IFLAG=100 under WRBEAM to generate an output distribution file called sns\_mebt\_dtl\_out.dst  
If it does not, you can get an updated version of the input file from the DYNAC website.

### 4.2.1 Plotting distributions that are consistent with the DYNAC WRBEAM flag IFLAG set to less than 100

With older versions of DYNAC, the first line of a particle distribution did not contain numbers for IFLAG, the RF frequency and the beam energy. As the phase will be plotted in degrees, the frequency is required. You need to add these numbers in the distribution file<sup>\*</sup>, change the IFLAG number and then refer to the section below related to IFLAG  $\geq 100$ .

### 4.2.2 Plotting distributions that are consistent with the DYNAC WRBEAM flag IFLAG set to 100 or larger

Click the “**Plot dist. file**” button and you will see particle distribution plots for X-X’, Y-Y’, X-PHI on top and Y-X, W-PHI, Y-PHI at the bottom; an example is shown in Fig.2 for a multi-charge state distribution.




Figure 2: Particle distribution plot for a multi-charge state beam

### 4.2.3 Plotting profiles

By default, “**Plot dist. file**” only causes the distributions to be plotted: “**Dst**” (in the “Plot dist. options” field, top right of window) is selected by default. One can, however, also plot the profiles that are defined by these distributions, by selecting “**Pro**” and subsequently clicking the “**Plot dist. file**” button again. One can also just plot the profiles by deselecting “**Dst**” (only “**Pro**” selected) and subsequently clicking the “**Plot dist. file**” button again. Profiles will only be shown in the X-X’, Y-Y’ and W-PHI phase planes. An example is shown in Fig.3 for a single charge state distribution.

<sup>\*</sup> In the old distribution file format, the first line contains the number of particles, followed by two dummy parameters. In the new distribution file format, the first line contains at a minimum the number of particles, followed by IFLAG (see DYNAC UG), the frequency (MHz) and the beam energy (MeV).




Figure 3: Particle distribution plot for a single charge state beam, including profiles based on raw data.

By default, the profiles will be based on the raw binned data. One can apply a Gaussian fit to these data by clicking the “Options” button, and in the DYNAC GUI OPTIONS window (see Fig.7) that will appear, selecting the “Fit” check box in the “Data in the profiles are to be” field. One can choose either option (see Fig.4 for result), both, or neither.




Figure 4: Particle distribution plot for a single charge state beam, including profiles based on fitted data, with printout of emittance values. This printout of emittance values can be selected in the DYNAC GUI OPTIONS window (see Fig.7).

If upon opening DGUI, you wish the default to be “Fitted” data, one can modify the dgui.ini to achieve this. In dgui.ini add the following line after the first line:  
 PROFILES fitted

The amplitudes of the profiles can be adjusted by using the amplitude buttons (ranging from 1 to 4) in the “Amplitude of profiles” field in the DGUI options window (see Fig.7).

#### 4.2.4 Changing scales on plots

By default, auto scaling is in effect. To change the scale on any of the plots, right-click on the plot of interest and change the settings in the pop-up menu (Fig.5).





Figure 5: A pop-up window appears after right-clicking a plot.

When left-clicking on a plot, one can displace the graph by continuing to press the mouse button and moving the mouse simultaneously. Following this, an  button will appear. You can left-click this button to go back to the original setting before the move.

One can also set the default graph limits in the dgui.ini file, e.g.

```
RANGES X   -1.    1.
RANGES XP  -100.  100.
RANGES Y   -1.    1.
RANGES YP  -100.  100.
RANGES Z   -180.  180.
RANGES ZP  -1.    12.
```

These will be used if one selects “**User**” in the “Graph limits based on” field in the DGUI Options window (see Fig.7). One can also change these graph limits on the fly. This is done by changing the setting(s) at the bottom of the DGUI Options window (see Fig.7) and subsequently clicking the “**Update graph limits**” button below.

One can optionally display the values of the RMS emittances in the top three plots if one selects “**Display**” in the “Emittance values” field in the DGUI Options window (see Fig.7). In that case these values will be plotted at the top of the aforementioned three plots. By selecting “**at the bottom**” as well, they will be displayed at the bottom. The transverse emittances are normalized. To calculate the normalized emittance, the AMU of the particle is needed. It has a default value of 1 (protons), but can be changed at the bottom of the DYNAC GUI OPTIONS window (see Fig.7).

#### 4.2.5 Plotting distributions as density plots

Change from the default distribution plot to a density plot by selecting the “**Density**” radio button (in the “Plot dist. options” field) and click the “**Plot dist. file**” button. Fig.6 shows an example result corresponding to the same particle distribution as shown in Fig.3.

The plot shown in Fig.6 uses an interpolation method to establish the local densities, which is the default. One can also choose a (much slower) KDE (Kernel Density Estimation) method. To do so, click the “**Options**” button, and in the DYNAC GUI OPTIONS window (see Fig.7) that will appear, select the “**KDE**” button in the “Density plot method” field.

The plot shown in Fig.6 uses an interpolation method to establish the local densities, which is the default. One can also choose a (much slower) KDE (Kernel Density Estimation) method. To do so, click the “**Options**” button, and in the DYNAC GUI OPTIONS window (see Fig.7) that will appear, select the “**KDE**” button in the “Density plot method” field.



One can change the colormap on the fly in the DGUI options window, as well as set a default colormap in the DGUI.ini file (see Chapter 2). Now click the “**Plot dist. file**” button again. Fig.8 shows an example result corresponding to the same particle distribution as shown in Fig.6.




Figure 6: Same particle distribution as represented in Fig.3, but shown as a density plot based on interpolation




Figure 7: DYNAC GUI OPTIONS window






Figure 8: Same particle distribution as represented in Fig.6, but with a density plot based on a KDE method.

The granularity of the kernels in the plot can be changed by changing the number of bins used by the KDE method. To do so, change the number of bins in the DYNAC GUI OPTIONS window (see Fig.7). The higher the number, the finer the resolution (and the longer it takes to calculate the plot!).

One can change the threshold for the density plots by changing the slider in the “Threshold for density plot” field in the DYNAC GUI OPTIONS window. Click the “**Plot dist. file**” button again to see the result. This works for both types of density plots. On Windows, the first time you use the slider, you may need to click next to it to activate it.

#### 4.2.6 Plotting ellipses

By selecting “**Plot ellipses**” in the “Ellipse options” field in the DGUI Options window (see Fig.7), ellipses will be plotted on three of the six particle distribution plots (longitudinal and both transverse emittances). The size of the ellipses can be set in terms of multiples of the RMS size by changing the numerical field marked NRMS in the DGUI Options window. Once the numerical entry has been entered, one has to click the adjacent “**Change**” button for the value to take effect.

### 4.3 DYNAC PROGRAM EXECUTION

Prior to starting the DYNAC program, one needs to select an input file by clicking on “**Get input file**” and choosing the DYNAC input file of interest.

Once the input file has been selected, you can click the “**Run DYNAC**” button. Text output from DYNAC will be displayed in the large text box below in the main window. Program execution can be interrupted by typing ctrl-I (cmd-I on MAC) or by clicking the “**Run DYNAC**” button once more.

If one were to run DYNAC again, by default the text in the text box will be cleared before the new output is displayed in it. By deselecting “**Clear page**” in the “Run time options” field, new text blocks will be displayed above the existing ones in the text box.

The DYNAC executable can be changed by entering the name of the binary in the appropriate text file in the DGUI options box and subsequently clicking the adjacent “**Change**” button. The default can be set in the dgui.ini file by entering DYNACVERSION dynacv7

or for instance

DYNACVERSION dynacv6\_0

for this older version of DYNAC (do not use versions older than V6R19). The name of the binary (without extension) should be the same as in the dynac/bin directory.

#### 4.4 PLOTS BASED ON THE DYNAC INPUT FILE

In the DYNAC input file one can request plots based on various cards (EMITGR, PROFGR etc). After executing the DYNAC program with the input file of choice (see section 4.3), and assuming that plot cards were present in the input file, one can plot the results from these cards by clicking on the “**plotit**” button. This will start gnuplot and will make one window per requested plot. All plots will be plotted at once. Text output from plotit will be printed in the DYNAC GUI main window large text box.

Clicking on the “**Save**” button (to the right of the “**plotit**” button) will cause the gnuplot graphics windows to be saved as picture files. The picture file format (.png or .jpeg) can be selected in the DYNAC GUI OPTIONS window (see Fig.7). Clicking on the “**Close gnuplots**” button will cause any open gnuplot graphics windows to be closed.

#### 4.5 PLOTTING WITH THE GUI

In using the plot options mentioned in this section, data is read from the dynac.print and/or dynac.dmp files and subsequently plotted. If you want to ensure that you get plots of the data you want, make sure to execute DYNAC with the input file of your choice (see section 4.4) prior to plotting.

Clicking on the “**Save visible plots**” button (bottom right of the main DGUI window) will cause the visible DGUI graphics windows to be saved as picture files. The picture file format (.png or .jpeg) can be selected in the DYNAC GUI OPTIONS window (see Fig.7).

Clicking on the “**Close plots**” button will cause any open graphics windows to be closed (with the exception of the gnuplot graphics windows).

Changing scales can be achieved as described under **Changing scales (4.2.4)**. If the legend of any of the plots below is obscured by the plotted data, you can simply left-click the legend, drag it and drop it to a location in the plot where it will not be obscured.

##### 4.5.1 Plot Erms

With this option, 2 graphs will be displayed as a function of the position along the beam axis (z): the top one will show the normalized transverse RMS emittances, the bottom one the longitudinal RMS emittance (example in Fig.9).




Figure 9: Example of a result obtained with **Plot Erms**.

##### 4.5.2 Plot $W, \varphi$

With this option, 2 graphs will be displayed as a function of the position along the beam axis ( $z$ ): the top one will show the energy of the reference ( $W_{ref}$ ) as well as of the COG ( $W_{cog}$ ), the bottom one the synchronous phase ( $\varphi_s$ ).

#### 4.5.3 Plot $X, Y$ env.

By default, the “Env” box (in the “Envelope options” field) is selected. With this option, 2 graphs will be displayed as a function of the position along the beam axis ( $z$ ): the top one will show a curve corresponding to the horizontal RMS beam size, the bottom one will show a curve corresponding to the vertical RMS beam size.

One can also select the “Ext” box (in the “Envelope options” field); with this option the largest horizontal extents (top graph) and largest vertical extents (bottom graph) will be plotted.

In addition, one can plot the beam line elements by selecting the “ELE” box (in the “Envelope options” field); see Fig.10 for an example. The color coding of the beam line elements and their “labeling” is as follows:

- RF elements are **green**: RFQ cells “RFQ”, DTL gaps (CAVSC) “C”, cavities (CAVMC and CAVNUM) “CA”, bunchers (BUNCHER) “B” and multi-harmonic bunchers (MHB) “MHB”
- Solenoids (SOLENOID, FSOLE) “S” are **cyan**
- Quadrupoles are **red**: (QUADRUPO) “Q”, (QUAFK) “Q”
- Quadrupole-Sextupole combinations (QUADSXT) “QS” are **red**
- Electrostatic quadrupoles (QUAELEC) “Q” are **red** with a **green** border
- Magnetic dipoles (BMAGNET) “DI” are **yellow**
- Electrostatic dipoles (EDFLEC) “DI” are **yellow** with a **green** border
- Sextupoles (SEXTUPO) “SX” are **magenta**

Drifts (DRIFT) are not displayed and are not labeled either.




Figure 10: Example of a result obtained with *Plot  $X, Y$  env.*

#### 4.5.4 Plot $dW, d\phi$ env.

By default, the “Env” box (in the “Envelope options” field) is selected. With this option, 2 graphs will be displayed as a function of the position along the beam axis ( $z$ ): the top one will show a curve corresponding to the RMS energy spread ( $dW_{rms}$ ), the bottom one the RMS phase extent ( $d\phi_{rms}$ ).

One can also select the “Ext” box (in the “Envelope options” field); with this option the largest transverse extents (top graph) and largest phase extents (bottom graph) will be plotted.

#### 4.5.5 Plot dispersion

With this option, 2 graphs will be displayed as a function of the position along the beam axis ( $z$ ): the top one will show the dispersion in  $x$  ( $Dx$ ) and the bottom one the dispersion in  $y$  ( $Dy$ ).

It should be noted that in non-dispersive beam lines, one will observe very small values for  $Dx$  and  $Dy$ , which are an artifact of the calculation and are essentially in the noise.

#### 4.5.6 Plot $\bar{x}, \bar{y}, TX$

With this option, plots of the average position in  $X$  and  $Y$  as a function of the position along the beam axis ( $z$ ) will be made. In addition, the transmission ( $TX$ ) as a function of the position along the beam axis ( $z$ ) will also be plotted.

#### 4.5.7 Plot losses

With this option, beam loss will be plotted as a function of the position along the beam axis ( $z$ ). Here beam loss is defined in terms of relative beam loss (in %) per unit length with the beam available at the input as reference. Also, the beam line elements will be plotted (see Fig.11), with the same definition of color coding and labeling of the beam line elements as in section 4.5.3. In this example one can observe that there is also a loss in the drift after the cavity.




Figure 11: Example of a result obtained with *Plot losses*.

### 4.6 WORKING WITH PROJECT DIRECTORIES

In view of working on different beam dynamics studies (e.g. related to different accelerators) or with different beam dynamics files for the same accelerator (e.g. different parts of the accelerator), DGUI offers the option of structuring (sub-)directories and copying files to these.

#### 4.6.1 Set projects file directory

In order to set a project directory, click on “File” (left top of DGUI window) and select “Set projects file directory”. The current directory, in case you have already set one, will be listed at the top of the main DGUI window (see example outlined in red in Fig.12).




Figure 12: The current project directory is listed at the top of the DGUI main window.

You are then asked if you wish to change the current directory, after which you can create a new one, or select a different one. Following this, you can select a directory.

#### 4.6.1 Save project files

Once the project directory has been selected, you can save relevant files associated with a particular beam dynamics simulation to this directory. To do so, click on “File” (left top of DGUI window) and select “Save project files”. You will get a pop-up window as in Fig.13, where you can select the type of files you want to save in the project directory.




Figure 13: Pop-window, in which one can select the type of files to be saved to the project directory.

Following this, a new pop-up will appear (see Figure 14); here one sets the project (or case) number. This will create a sub-directory to the directory chosen in the previous step. The sub-directory name will be “project” followed by the number you selected. As an example, selecting “1”, will create a sub-directory called “project1”.




Figure 14: Pop-window, in which one can select the type of files to be saved to the project directory.

## 5 GLOSSARY

<b>COG</b>	<b>Center Of Gravity (of the beam)</b>
<b>GUI</b>	<b>Graphical User Interface</b>
<b>KDE</b>	<b>Kernel Distribution Estimation</b>
<b>OS</b>	<b>Operating System</b>
<b>RF</b>	<b>Radio Frequency</b>
<b>RMS</b>	<b>Root Mean Squared</b>
<b>UG</b>	<b>User Guide</b>

## 6 KNOWN ISSUES

In the lists below, unresolved or potential issues are listed.

### 6.1 ISSUES RELATED DGUI

In this section, issues will be listed that are definite issues with the DGUI python script itself.

### 6.2 ISSUES RELATED TO THE DGUI ENVIRONMENT

The issues listed in this section, seem to be ones related to the DGUI system environment.

**DGS00001** Print screen: works on MAC, Windows, linux mint; not yet demonstrated on centos linux

**DGS00002** Printing a window by right-clicking: works on MAC, Windows, linux mint; not yet demonstrated on centos linux

**DGS00003** Exporting a partial scene from a distribution plot: works on MAC, Windows; does not work properly on centos linux, linux mint (no particles are printed)

**DGS00005** On Windows, the first time you use the “Threshold for density plot” slider (DYNAC GUI OPTIONS window), you may need to click next to it to activate it.

#### 6.2.1 Closed issues

**DGS00004** *Closed because the following error does not occur on MAC Sierra or Catalina and is anyhow not fatal.*

On more recent MAC OSs, one may see an error when opening a file:

*objc[63527]: Class FIFinderSyncExtensionHost is implemented in both*

*/System/Library/PrivateFrameworks/FinderKit.framework/FinderKit (0x136e80c90) and*

*/System/Library/PrivateFrameworks/FileProvider.framework/*

*OverrideBundles/FinderSyncCollaborationFileProviderOverride.bundle/Contents/MacOS/*

*FinderSyncCollaborationFileProviderOverride (0x145828cd8). One of the two will be used. Which one is undefined.*

**DGS00006** *Closed* On MAC OS, the plotit button will not work if the gnuplot X11 terminal was not installed. To fix this, re-install gnuplot with the necessary terminal (X11, but also wxt and/or qt); this can be conveniently done with macports. Also ensure xquartz is installed.