



PlutoPilot Code Structure

1) void plutoInit():

- The setup function is called once at Pluto's hardware start-up.
- Add your hardware initialization code here.

2) void onPilotStart():

- The function is called once before plutoPilot when you activate UserCode by Volume-Up key on Pluto Controller.
- Do your one time stuffs here like variable initializations.

3) void plutoPilot():

- The loop function is called in an endless loop when you activate UserCode by Volume-Up key on Pluto Controller.
- Add your main logic here.

4) void onPilotFinish():

- The function is called once after plutoFly when you deactivate UserCode by Volume-Down key on Pluto Controller.**
- Do your clean-up stuffs here like resetting your logic.**