

Vive Trackers for Unity3D

Unity3D Configuration

1. Import the SteamVR plugin for Unity in your project:

<https://assetstore.unity.com/packages/tools/integration/steamvr-plugin-32647>


2. If applicable (depends on SteamVR plugin version), uncheck :

Preferences -> SteamVR -> Automatically Enable VR

3. Check : Project Settings -> Player -> XR Settings > Virtual Reality Supported

- Add VR SDK None
- Add VR SDK OpenVR

***ViveTrackersManager** script automatically initializes OpenVR, so we need to set the primary VR SDK to **None** to prevent Unity3D to initialize OpenVR.




NB: The SteamVR application should always run in the background while the Unity3D application (either the UnityEditor or an executable) is running. If not, you should expect Vive Trackers connections issues !!!

Understanding SteamVR calibration and Vive Trackers calibration

1. Vive Trackers calibration in Unity3D

In Unity3D, ViveTracker objects can be calibrated. The **origin reference frame** is used as the default transformation for their calibration.



*during runtime, the **origin reference frame** can also be used to apply an offset (3D Position & Rotation) to all the trackers.




SteamVR reference frame
in the real space

2. SteamVR Room calibration

If you need to get a perfect match between your virtual world and your real world (e.g. going towards a direction in the real world applies the same direction in the virtual world), you should make the **SteamVR reference frame** aligned with the desired forward axis in your real space.

*each time a SteamVR calibration is done, the application using the Vive Trackers must be restarted (e.g: UnityEditor).



SteamVR configuration

Running SteamVR with Vive Trackers only (no HMD)


Modify these SteamVR configuration files:

- SteamFolder/steamapps/common/SteamVR/drivers/null/resources/settings/default.vrsettings
 - > set **enable** to **true**
- SteamFolder/steamapps/common/SteamVR/resources/settings/default.vrsettings
 - > set **requireHmd** to **false**
 - > set **forcedDriver** to **null**
 - > set **activateMultipleDrivers** to **true**

More informations:

<http://help.triadsemi.com/en/articles/836917-steamvr-tracking-without-an-hmd>

Set SteamVR properties in Steam



NB : Be careful when Steam performs a SteamVR update : default.vrsettings files could be overridden with new ones !!!

Optimize Vive Trackers
connection reliability

Configure Windows Power Options

The image shows the Windows 'Modifier les paramètres du mode de gestion de l'alimentation' window. The main window title is 'Modifier les paramètres du mode de gestion de l'alimentation'. The breadcrumb path is 'Matériel et audio > Options d'alimentation > Modifier les paramètres du mode de gestion de l'alimentation'. The current mode is 'Performances élevées'. The settings for 'Éteindre l'écran' and 'Mettre l'ordinateur en veille' are both set to 'Jamais'. There are links for 'Modifier les paramètres d'alimentation avancés' and 'Rétablir les paramètres par défaut pour ce mode'. At the bottom right are buttons for 'Enregistrer les modifications' and 'Annuler'.

Modifier les paramètres du mode : Performances élevées
Choisissez les paramètres de mise en veille et d'affichage de votre ordinateur.

Éteindre l'écran : Jamais

Mettre l'ordinateur en veille : Jamais

[Modifier les paramètres d'alimentation avancés](#)
[Rétablir les paramètres par défaut pour ce mode](#)

Options d'alimentation

Paramètres avancés

Sélectionnez le mode de gestion de l'alimentation à personnaliser, puis choisissez les paramètres de gestion de l'alimentation pour votre ordinateur.

Performances élevées [activé]

- Paramètres d'arrière-plan du Bureau
- Paramètres des cartes sans fil
 - Mode économie d'énergie
 - Paramètre : Performances maximales
- Veille
 - Paramètres USB
 - Paramètre de la suspension sélective USB
 - Paramètre : Désactivée
- Boutons d'alimentation et capot
- PCI Express
- Gestion de l'alimentation du processeur

Restaurer les valeurs par défaut

OK Annuler Appliquer

Set SteamVR settings

