



Configure

| | Port 1 | Port 2 | Port 3 | Port 4 |
|----------|--------|--------|--------|--------|
| Ethernet | Auto | Auto | Auto | Auto |
| MDI-X | Auto | Auto | Auto | Auto |

Save Cancel

Help

Ethernet: Configure the transmission capabilities of each ethernet port. The default of auto adapts to the abilities of the client.

MDI-X: The Medium Dependent Interface Crossover allows networked devices to connect to each other.