

Generic Timer Module (GTM)

28.7 First In First Out Module (FIFO)

28.7.1 Overview

The FIFO unit is the storage part of the FIFO sub-module. The F2A described in (FIFO to ARU Unit) and the AFD described in chapter “AEI to FIFO Data Interface” implement the interface part of the FIFO sub-module to the ARU and the AEI bus. Each FIFO unit embeds eight logical FIFOs. These logical FIFOs are configurable in the following manner:

- FIFO size (defines start and end address)
- FIFO operation modes (normal mode or ring buffer operation mode)
- Fill level control / memory region read protection

Each logical FIFO represents a data stream between the sub-modules of the GTM and the microcontroller connected to AFD sub-module (see chapter AEI to FIFO Data Interface). The FIFO RAM counts 1K words, where the word size is 29 bit. This gives the freedom to program or receive 24 bit of data together with the five control bits inside an ARU data word.

The FIFO unit provides three ports for accessing its content. One port is connected to the F2A interface, one port is connected to the AFD interface and one port has its own AEI bus interface.

The AFD interface has always the highest priority. Accesses to the FIFO from AFD interface and direct AEI interface in parallel - which means at the same time - is not possible, because both interfaces are driven from the same AEI bus interface of the GTM.

The priority between F2A and direct AEI interface can be defined by software. This can be done by using the register **FIFO[i]_CH[x]_CTRL** for all FIFO channels of the sub-module.

The FIFO is organized as a single RAM that is also accessible through the FIFO AEI interface connected to one of the FIFO ports. To provide the direct RAM access, the RAM is mapped into the address space of the microcontroller. The addresses for accessing the RAM via AEI can be found in [1].

After reset, the FIFO RAM isn't initialized by hardware.

The FIFO channels can be flushed individually. Each of the eight FIFO channels can be used whether in normal FIFO operation mode or in ring buffer operation mode.

Beside the possibility of flushing each FIFO channel directly, a write access to FIFO[i]_CH[x]_END_ADDR or to FIFO[i]_CH[x]_START_ADDR will also flush the regarding channel which means that the read and write pointer and also the fill level of the regarding channel will be reset. In consequence of this existing data in the concerned FIFO channel are not longer valid- thereafter the channel is empty.

28.7.2 Operation Modes

28.7.2.1 FIFO Operation Mode

In normal FIFO operation mode the content of the FIFO is written and read in first-in first-out order, where the data is destroyed after it is delivered to the system bus or the F2A sub-module (see chapter “FIFO to ARU Unit”).

The upper and lower watermark registers (registers **FIFO[i]_CH[x]_UPPER_WM** and **FIFO[i]_CH[x]_LOWER_WM**) are used for controlling the FIFO's fill level. If the fill level falls below the lower watermark or it exceeds the upper watermark, an interrupt signal is triggered by the FIFO sub-module if enabled inside the **FIFO[i]_IRQ_EN**.

The interrupt signals are sent to the Interrupt Concentrator Module (ICM) (see chapter “Interrupt Concentrator Module”). The ICM can also initiate specific DMA transfers.