

Yocto cheatsheet

Related topics

- [Simplify yocto project setup using kas \(yocto-kas.html\)](#).
- [Create bitbake recipes \(creating-recipe.html\)](#).

conf/local.conf - frequent configurations

- Adding a package ([IMAGE__INSTALL \(https://docs.yoctoproject.org/ref-manual/variables.html#term-IMAGE__INSTALL\)](#)):

```
IMAGE_INSTALL:append = " wireguard-module rsyslog" # syntax for "Honister" or newer releases
IMAGE_INSTALL_append = " wireguard-module rsyslog" # syntax for releases older than "Honister"
```

- Configuring the hardware target ([MACHINE \(https://docs.yoctoproject.org/ref-manual/variables.html#term-MACHINE\)](#)):

```
MACHINE = "raspberrypi4-64"
```

- Adding a rootfs format ([IMAGE__FSTYPES \(https://docs.yoctoproject.org/ref-manual/variables.html#term-IMAGE__FSTYPES\)](#)):

```
IMAGE_FSTYPES:append = " hddimg" # syntax for "Honister" or newer releases
IMAGE_FSTYPES_append = " hddimg" # syntax for releases older than "Honister"
```

- Don't fail on dangling *.bbappend files ([BB__DANGLINGAPPENDS__WARNONLY \(https://docs.yoctoproject.org/ref-manual/variables.html#term-BB__DANGLINGAPPENDS__WARNONLY\)](#)):

```
BB_DANGLINGAPPENDS_WARNONLY = "true"
```

- Set useful features ([EXTRA__IMAGE__FEATURES \(https://docs.yoctoproject.org/ref-manual/variables.html#term-EXTRA__IMAGE__FEATURES\)](#)):

```
EXTRA_IMAGE_FEATURES = "debug-tweaks ssh-server-dropbear package-management"
```

- Switch the kernel recipe ([PREFERRED__PROVIDER \(https://docs.yoctoproject.org/ref-manual/variables.html#term-PREFERRED__PROVIDER\)](#), [PREFERRED__VERSION \(https://docs.yoctoproject.org/ref-manual/variables.html#term-PREFERRED__VERSION\)](#)):

```
PREFERRED_PROVIDER_virtual/kernel = "linux-raspberrypi-rt"
PREFERRED_VERSION_virtual/kernel = "4.19.%"
```

- RaspberryPi extra flags ([ENABLE__I2C \(https://meta-raspberrypi.readthedocs.io/en/latest/extra-build-config.html#enable-i2c\)](#)),

RPI_EXTRA_CONFIG (<https://meta-raspberrypi.readthedocs.io/en/latest/extra-build-config.html#manual-additions-to-config-txt>):

```
ENABLE_I2C = "1"
RPI_EXTRA_CONFIG:append = "\n \
dtoverlay=i2c-rtc,ds3231 \n \
" # syntax for "Honister" or newer releases
RPI_EXTRA_CONFIG:append = "\n \
dtoverlay=i2c-rtc,ds3231 \n \
" # syntax for releases older than "Honister"
```

- Appending to a variable when building for a specific architecture/hardware target:

```
IMAGE_INSTALL:append:gemual1 = " ntpdate " # syntax for "Honister" or newer releases
IMAGE_INSTALL_append_gemual1 = " ntpdate " # syntax for releases older than "Honister"
```

- Removing from a variable when building for a specific architecture/hardware target:

```
IMAGE_INSTALL:remove:gemual1 = "avrdude" # syntax for "Honister" or newer releases
IMAGE_INSTALL_remove_gemual1 = "avrdude" # syntax for releases older than "Honister"
```

- Setting the default hostname ([reference \(https://docs.yoctoproject.org/dev-manual/common-tasks.html#customizing-an-image-hostname\)](https://docs.yoctoproject.org/dev-manual/common-tasks.html#customizing-an-image-hostname)):

```
hostname:pn-base-files = "custom hostname" # syntax for "Honister" or newer releases
hostname_pn-base-files = "custom hostname" # syntax for releases older than "Honister"
```

- Ignoring some recipes ([BBMASK \(https://docs.yoctoproject.org/ref-manual/variables.html#term-BBMASK\)](https://docs.yoctoproject.org/ref-manual/variables.html#term-BBMASK)):

```
BBMASK = "meta-freescale/recipes-kernel/linux"
BBMASK += "meta-freescale/recipes-connectivity/openssl"
```

- Blacklisting a package based on name (syntax from Kirkstone):

```
SKIP_RECIPE[busybox] = "Lorem ipsum error message"
```

- Blacklisting packages based on license ([INCOMPATIBLE_LICENSE \(https://docs.yoctoproject.org/ref-manual/variables.html#term-INCOMPATIBLE_LICENSE\)](https://docs.yoctoproject.org/ref-manual/variables.html#term-INCOMPATIBLE_LICENSE)):

```
INCOMPATIBLE_LICENSE = "GPL-3.0 LGPL-3.0 AGPL-3.0"
```

- Whitelisting packages with commercial license flags ([LICENSE_FLAGS_WHITELIST \(https://docs.yoctoproject.org/ref-manual/variables.html#term-LICENSE_FLAGS_WHITELIST\)](https://docs.yoctoproject.org/ref-manual/variables.html#term-LICENSE_FLAGS_WHITELIST)):

```
LICENSE_FLAGS_WHITELIST = "commercial ffmpeg commercial_x264" # Honister or older
LICENSE_FLAGS_ACCEPTED = "commercial ffmpeg commercial_x264" # Kirkstone or newer
```

conf/local.conf - mirroring & caching

- Enabling the low-level.wiki mirrors:

```
SOURCE_MIRROR_URL = "https://low-level.wiki/large_files/yocto/downloads/"
INHERIT += "own-mirrors"
```

- Setting a pre-mirror server ([SOURCE_MIRROR_URL](https://docs.yoctoproject.org/ref-manual/variables.html#term-SOURCE_MIRROR_URL) (https://docs.yoctoproject.org/ref-manual/variables.html#term-SOURCE_MIRROR_URL)):

```
SOURCE_MIRROR_URL = "http://.../sources/"
INHERIT += "own-mirrors"
```

- Setting a sstate-mirror server (do not change the PATH - it's a keyword, [SSTATE_MIRRORS](https://docs.yoctoproject.org/ref-manual/variables.html#term-SSTATE_MIRRORS) (https://docs.yoctoproject.org/ref-manual/variables.html#term-SSTATE_MIRRORS)):

```
SSTATE_MIRRORS = "file://.* http://.../sstate/PATH"
```

- Setting the local DL_DIR (this can be reused across multiple builds or to set up a mirror, [DL_DIR](https://docs.yoctoproject.org/ref-manual/variables.html#term-DL_DIR) (https://docs.yoctoproject.org/ref-manual/variables.html#term-DL_DIR), [BB_GENERATE_MIRROR_TARBALLS](https://docs.yoctoproject.org/ref-manual/variables.html#term-BB_GENERATE_MIRROR_TARBALLS) (https://docs.yoctoproject.org/ref-manual/variables.html#term-BB_GENERATE_MIRROR_TARBALLS)):

```
DL_DIR = "/var/data/downloads"
BB_GENERATE_MIRROR_TARBALLS = "1"
```

- Setting the local SSTATE_DIR (this can be reused across multiple builds or to set up a mirror, [SSTATE_DIR](https://docs.yoctoproject.org/ref-manual/variables.html#term-SSTATE_DIR) (https://docs.yoctoproject.org/ref-manual/variables.html#term-SSTATE_DIR)):

```
SSTATE_DIR = "/var/data/sstate"
```

Other Yocto commands

- Search engine for yocto programs, recipes and layers:
<https://layers.openembedded.org/layerindex/branch/master/recipes/>
(<https://layers.openembedded.org/layerindex/branch/master/recipes/>).

- Run kernel menuconfig (you have to save and copy the generated config file afterwards):

```
bitbake -c menuconfig virtual/kernel
```

- Clean the environment for a recipe:

```
bitbake -c cleanall avrdude
```

- Download all the prerequisites for a build:

```
bitbake core-image-minimal --runall=fetch
```

- Find out which recipe is responsible for a file in the final image:

```
oe-pkgdata-util find-path /bin/sh
```

- Find out which recipe is responsible for a package:

```
oe-pkgdata-util lookup-recipe python3-io
```

- Find out information (recipe name, version) about a package:

```
oe-pkgdata-util package-info acl
```

- Find out the value of some variables from a recipe:

```
oe-pkgdata-util read-value RDEPENDS acl
```

- Start a docker container with the container's directory /home mapped over the physical directory /mnt/ssd/rpi-tutorial-2/. This is useful if you're recreating old yocto builds, and the host OS is newer (and incompatible). The re-mapping is specified, in case the default docker filesystem is placed on a HDD, but you also have an SSD installed.

```
sudo docker run -it --mount type=bind,source=/mnt/ssd/rpi-tutorial-2/,target=/home ubuntu:16.04
```

Using generated images

- Run image in qemu (without root permissions or graphical interface, after the yocto environment has been "sourced", check the [README](#) (<http://git.yoctoproject.org/cgi/cgit.cgi/poky/tree/scripts/runqemu.README>)). Only works if the board has an accompanying *.qemuboot.conf file:

```
runqemu nographic slirp
```

- Copy the generated image for RaspberryPi on sdcard:

```
sudo apt-get install bmap-tools
sudo bmaptool copy core-image-minimal-raspberrypi4-64.wic.bz2 /dev/mmcblk0
```

- Converting from "hddimg" image to "vdi" (loadable into virtualbox):

```
"C:\Program Files\Oracle\VirtualBox\VBoxManage.exe" convertdd core-image-minimal.hddimg new_file.vdi --format VDI
```

- Converting from "vmdk" image to raw "hddimg" (writable on a disk):

```
vboxmanage clonemedium disk ubuntu-cosmic-18.10-cloudimg.vmdk --format RAW pm-vm-physical-1.0.img
```

Using "templateconf"

- Create a new folder.
- Use the [poky/meta-poky/conf](#) (<http://git.yoctoproject.org/cgi/cgit.cgi/poky/tree/meta-poky/conf>), or [poky/meta-debian/conf](#) (<https://github.com/meta-debian/meta-debian/tree/master/conf>) folders as references. You only need bblayers.conf.sample and local.conf.sample. The bblayers.conf.sample file uses ##OEROOT## placeholder to point to the poky folder. The conf-notes.txt file is optional.
- Use it (TEMPLATECONF must point to the configuration directory):

```
TEMPLATECONF=meta-.../.../conf source ./oe-init-build-env
```