



## Changing a Keg

### Quick Reference Guide

---

1. Remove the seal from the top of the keg by turning counterclockwise. Make sure the coupler is in the up/off position and not engaged.
2. Insert the coupler into the valve at the top of the new keg and slowly turn clockwise (90 deg.) until you have a snug fit. Do not forcefully over tighten. A good tight seal is all you need.
3. Pull the handle on the coupler out and push it down until you hear it lock into place.
4. Don't forget to rest the float on the FOB.  
You're ready to go!

