



Application Notes

M8baby Spdif Pinmux Setting Guide

Revision 0.1

AMLOGIC, Inc.

2518 Mission College Blvd

Santa Clara, CA 95054

U.S.A.

www.amlogic.com

AMLOGIC reserves the right to change any information described herein at any time without notice.
AMLOGIC assumes no responsibility or liability from use of such information.

Table of Content

1. OVERVIEW 4

2. SPDIF PIN CONNECTION..... 5

3. SPDIF PINMUX IN DTD FILE 6

Amlogic Confidential!

Amlogic Application Notes

Revision History

Revision	Revised Date	By	Changes
0.1	Jul. 3, 2014	chengshun.wang	Initial release draft

Amlogic Confidential!

1. Overview

This document shows how to configure the GPIO to spdif pin in M8baby platform.

It includes:

- Pin connection
- DTD file

Amlogic Confidential!

2. SPDIF Pin Connection

In M8baby mbox platform, we only use spdif out pin at now.




Fig 2.1 Spdif out connect in M8baby Mbox

GPIOAO_13	0xc8100024 bit[13]	0xc8100024 bit[29]	0xc8100028 bit[13]	IR_BLAZER Reg[31] test1341	PWM_E Reg[13]	IEC958_OUT Reg[3]
-----------	-----------------------	-----------------------	-----------------------	----------------------------------	------------------	----------------------

Fig 2.2 Spdif out use GPIOAO_13 pin

We know spdif out port connect GPIOAO_13 pin from Fig 2.1 and Fig 2.2. This is just example, we need set pinmux according to project.

3. SPDIF Pinmux in DTD file

Now we set pinmux in different project dtd file.

- Dtd file path:
Common/arch/arm/boot/dts/amlogic/meson8b_xxx_1G.dtd
- Set spdif pinmux
audio_pins:audio_pin{
 amlogic,setmask=<10 0x8>; // spdif out
 amlogic,clrmask=<10 0x2000>; // spdif out
 amlogic,pins = "GPIOAO_13"; // spdif out
};

Amlogic Confidential!