



Hewlett Packard
Enterprise

HPE ProLiant DL Server - How to Enable the PXE Boot Option in 366T add-on Network Adapter

Table of contents

- Objective
- Environment
- Steps

Objective

From the System Utilities screen, select System Configuration > BIOS/Platform Configuration (RBSU) > Network Options

- Network Boot Options
- Configuring Pre-Boot Network Settings

Step 1: Configuring Network Boot Options

- Network Boot Options > PCIe Slot Network Boot > Select /Enable the Network boot on Slot X Port X
- Save your changes

Step 2: Configuring Pre-Boot Network Settings

- Select the Pre-Boot Network Settings > Pre-Boot Network Interface > Select /Enable the Network boot on Slot X Port X
- Save your changes

Environment

- HPE ProLiant DL360 Gen10 Server
- HPE ProLiant DL380 Gen9 Server
- HPE ProLiant DL380 Gen10 Server
- HPE ProLiant DL385 Gen10 Server


Steps

From the System Utilities screen, select System Configuration > BIOS/Platform Configuration (RBSU) > Network Options


- Network Boot Options
- Configuring Pre-Boot Network Settings

Step 1: Configuring Network Boot Options


- From the System Utility screen, select System Configuration > BIOS/Platform Configuration (RBSU) > Network Options



- Network Boot Options > PCIe Slot Network Boot




- Select /Enable the Network boot on Slot 1 Port1 and Save your changes



Step 2:Configuring Pre-Boot Network Settings

- Select the Pre-Boot Network Settings > Pre-Boot Network Interface > Select /Enable the Network boot on Slot 1 Port 1
- Save your changes



- Reboot the system and Check the PXE boot status in the POST

```
>> Booting Slot 1 Port 1 : HPE Ethernet 1Gb 4-port 366T Adapter - NIC (PXE IPv4)
>>Start PXE over IPv4._
```

