



Scenario 1: Metal3 continuous under CAPM




The space between CAPM is set by MR_capm.SP.1. Met3_bot_plate (MR_capm.SP.2) rule does not apply.

Scenario 2: Metal3 not continuous under CAPM, but electrically connected



The space between CAPM is set by `MR_capm.SP.1`. `Met3_bot_plate` (`MR_capm.SP.2`) rule does not apply. Rules `MR_met3.SP.1` and `capm.SP.5` are met by meeting `MR_capm.SP.1`.

Scenario 3: Metal3 under CAPM not electrically connected



Met3_bot_plate (MR_capm.SP.2) applies to this layout.