

# Quick Installation Guide

---

- ☑ DAG1000-4S4O
- ☑ DAG2000-8S8O

## Thanks for Choosing Dinstar's VoIP Gateway!

Please read this guide carefully before installing the gateway. If you need any technical support, please contact us.

Tel: +86 755 61919966

Email: [support@dinstar.com](mailto:support@dinstar.com)

Website: [www.dinstar.com](http://www.dinstar.com)

# 1 Product Model & Number of Ports

Port Type Model	WAN	LAN	FXS	FXO
DAG1000-4S4O	1	3	4	4
DAG2000-8S8O	0	4	8	8


Please check the model of your gateway before installation, and then refer to corresponding installation instructions.

# 2 Description of Indicators


Indicator	Definition	Status	Description
PWR	Power Indicator	On	The gateway is powered on
		Off	The gateway has no power input or power supply is abnormal
RUN	Running Indicator	Slow Flashing	The gateway is running properly
		Fast Flashing	SIP account is registered successfully
		Off	The gateway is running improperly
FXS	Telephone In-use Indicator	On	FXS port is currently occupied by a call
		Off	FXS port is idle or faulty
FXO	FXO In-use Indicator	On	FXO Port is currently occupied
		Off	FXO Port is idle or faulty
WAN/LAN	Link (Green)	Flashing	The gateway is properly connected to network
		Off	The gateway is not connected to network or network connection is improper
	Speed	On	Work at 100Mbps
		Off	Work at 10Mbps

### 3 Indicators & Interfaces

#### ► DAG1000-4S4O



#### ► DAG2000-8S8O




## 4 Installation Attentions

- ◆ Product model: please check the model of your gateway before installation;
- ◆ Anti-jamming: to reduce interference, it's highly recommended that telephone lines and PSTN lines connected to the gateway should be placed away from power cables;
- ◆ Power supply: DAG1000-4S4O is equipped with 12VDC power adapter, while DAG2000-8S8O accepts AC input voltage of 100-240V. Please ensure safe and stable power supply;
- ◆ Network bandwidth: please ensure there is enough network bandwidth so as to guarantee stabilized running of the gateway;
- ◆ Ventilation: to avoid overheating, please do not pile up the gateway with other devices and make sure the gateway has good ventilation around;
- ◆ Temperature and humidity: to avoid any accident that might cause malfunction, it's advised to install the gateway in an equipment room where temperature and humidity are appropriate;
- ◆ Mechanical load: It's highly advised to horizontally place the gateway on a flat surface or a cabinet.


## 5 Installation Instructions

### ► Connection Diagram for DAG1000-4S4O


- Connect gateway with network



- Connect FXS port with Telephone line  
Connect FXO port with PSTN line




- Connect gateway with power input




## ► Connection Diagram for DAG2000-8S80


- Connect gateway with network



- Connect FXS port with Telephone line  
Connect FXO port with PSTN line




- Connect gateway with power input




## 6 Modify PC's IP Address

To log in the Web Management System of the gateway, you need to modify the IP address of PC first to make it at the same network segment with the gateway.


- 1 On the PC, click '**Network (or Ethernet)** → **Properties**'.



- 2 Double-click '**Internet Protocol Version 4 (TCP/IPv4)**'.



- 3 Select '**Use the following IP address**', and then enter an available IP address '192.168.11.XXX' which is at the same network segment with '192.168.11.1'.



## 7 Log in Web Management System

Open a web browser and enter the gateway's IP address (default IP is 192.168.11.1). Then input username and password in the displayed login GUI. Both the default username and password are admin.

## 8 Modify Gateway's IP Address

If you want to modify the IP address of the DAG gateway, please click '**Network** → **Local Network**' in the navigation tree on the left of the Web Management System, and then input new IP address and DNS server address on the displayed interface.

## 9 Basic Configurations of FXS

### (1) Configure SIP Server

Log in the Web Management System of the gateway, and then click **SIP Server** in the navigation tree and then enter the address of the SIP server which is to be registered. Click **Save** in the last.

**SIP Server**

**Primary SIP Server**

Primary SIP Server Address	<input type="text" value="172.16.95.110"/>
Primary SIP Server Port (Default: 5060)	<input type="text" value="5060"/>
Registration Expires (Default: 1800)	<input type="text" value="1800"/> s
Heartbeat	<input type="checkbox"/> Enable

### (2) Configure SIP Account Information

Click **Port** in the navigation tree on the left, and then click **Add**. Input the SIP account and authentication password assigned by the SIP server.

**Port Modify**

Port	<input type="text" value="1"/>
Disable Port	<input type="checkbox"/>
Registration	<input checked="" type="checkbox"/> Enable
Primary Display Name	<input type="text" value="Bob"/>
Primary SIP User ID	<input type="text" value="10000"/>
Primary Authenticate ID	<input type="text" value="10000"/>
Primary Authenticate Password	<input type="text"/>
Secondary Display Name	<input type="text"/>
Secondary SIP User ID	<input type="text"/>
Secondary Authenticate ID	<input type="text"/>
Secondary Authenticate Password	<input type="text"/>


Click **Save** and then restart the gateway for the new configurations to take effect.

## 10 Basic Configurations of FXO

### (1) Create Port Group

You are advised to divide PSTN lines into several groups and then distribute them to different port groups. Generally, PSTN lines belonging to a same telecom operator are distributed to a same port group.

Click **Call&Routing →Port Group**, and then click **Add** on the displayed interface.




The 'Port Group Add' window contains the following fields and controls:

Index	15
Description	TELE
Primary Display Name	TELECOM
Primary SIP User ID	10000
Primary Authenticate ID	10000
Primary Authenticate Password	
Secondary Display Name	
Secondary SIP User ID	
Secondary Authenticate ID	
Secondary Authenticate Password	
Offhook Auto-Dial	
Auto-Dial Delay Time	
Port Select	Cyclic Ascending
Pick Up on Group	#
Port	<button>Click to Select Ports for this Group</button>

When calls come from PSTN to the gateway, the offhook auto-dial number is generally regarded as the DID (Direct-inward-dial) number or destination number of the SIP server.

Click **Click to select to select ports for this group**, and the following interface will be displayed.




The 'Select Port for this Group' dialog box shows the following options:

<input type="checkbox"/> Port 0(FXS)	<input type="checkbox"/> Port 1(FXS)	<input type="checkbox"/> Port 2(FXS)	<input type="checkbox"/> Port 3(FXS)
<input checked="" type="checkbox"/> Port 4(FXO)	<input checked="" type="checkbox"/> Port 5(FXO)	<input checked="" type="checkbox"/> Port 6(FXO)	<input checked="" type="checkbox"/> Port 7(FXO)

Buttons: **Select All**, **Select Invert**, **Select None**, **Cancel**, **Ok**

### (2) Create IP Trunk

On the **Call & Routing→IP Trunk** interface, click **Add** to create an IP trunk which connects to a peer SIP server.



The 'IP Trunk Modify' window contains the following fields and controls:

Index	63
Description	eLA
Remote Address	172.30.6.2
Remote Port	5060
Heartbeat	<input type="checkbox"/> Enable



### (3) Create Outbound Route

On the **Call & Routing**→**IP**→**Tel Routing** interface, click **Add** to create an outbound route for the IP trunk.

As shown in the following figure, Caller/Callee Prefix is set as 'any' and calls from IP trunk 63<eLA> are routed to port group 15<TELE>.

The screenshot shows the 'IP->Tel Routing Modify' window. It contains the following fields and settings:

- Index:** 31
- Description:** call out
- Calls from:** ☒ IP Trunk (63 <eLA>)
- Caller Prefix:** any
- Callee Prefix:** any
- Calls to:** ☐ Port (0) and ☒ Port Group (15 <TELE>)

### (4) Create Inbound Route

On the **Call & Routing**→**Tel**→**IP/Tel Routing** interface, click **Add** to create an inbound route for the IP trunk. As shown in the following figure, Caller Prefix is set as 'any' and calls from port group 15<TELE> are routed to IP trunk 63<eLA>.

The screenshot shows the 'Tel->IP/Tel Routing Modify' window. It contains the following fields and settings:

- Index:** 31
- Description:** call in
- Calls from:** ☐ Port (0) and ☒ Port Group (15 <TELE>)
- Caller Prefix:** any
- Callee Prefix:** any
- Calls to:** ☐ Port (0), ☐ Port Group (15 <TELE>), ☒ IP Trunk (63 <eLA>), and ☐ SIP Server

## 11 Configure FXO Parameters

On the **Advanced** →**FXS/FXO** interface, configure the gateway to detect CID after ring or before ring, and enable 'Send Original CID when call from PSTN'. Format of "from" field is set as 'CID/CID' when CID is available, while format of "from" field is set as 'Display/User ID' when CID is unavailable.

The screenshot shows the 'FXO Parameter' configuration window. It contains the following settings:

- Incoming Call from PSTN**
  - Configuration by FXO:** ☒ Enable
  - Detect CID:** After Ring
  - Send Original CID when Call from PSTN:** ☒ Enable
  - Format of "From" field when CID is Available:** CID/CID
  - Format of "From" field when CID is Unavailable:** Display/User ID
- CID :** Calling Number    **Name :** Calling Name

## 12 Basic Operations

- ◆ Dial \*158# to query the IP address of LAN port of the gateway;
- ◆ Dial \*159# to query the IP address of WAN port of the gateway;
- ◆ Dial \*114# to query the telephone number of a FXS port;
- ◆ Dial \*165\*000000# to restore default IP address, username and password;
- ◆ Restore factory default settings:
  - (1) dial \*166\*000000#;
  - (2) press the **RST** button for 7 seconds; then restart by manual;
  - (3) Log in the gateway and then click '**Tools** → **Factory Reset**', then click **Apply** and restart the gateway.
- ◆ Restart the gateway:
  - (1) Dial \*111# to restart the gateway.
  - (2) Log in Web Management System, click '**Tools** → **Restart**' in the navigation tree on the left, and then click **Restart** on the displayed interface.

## 13 More Details

This document only provides instructions for quick installation and basic configuration, For detailed configuration and parameter explanation, please make reference to user manual or ask for online technical support.

Honest, Concentrated, Innovative, Open

Shenzhen Dinstar Co., Ltd.

Website: <http://www.dinstar.com>

Facebook: <http://www.facebook.com/dinstarvoip/>

