



M8123B2 User's Manual

This document is the User's Manual for M8123B2, an OEM circuit board for the force/torque sensor (loadcell) manufactured by SRI (Sunrise Instruments Co., Ltd). It's strongly recommended that anyone who uses M8123B2 should read this document before any operation. SRI reserves all the rights of this document. Please do not hesitate to contact SRI if there is any question.



Content

| | |
|---|-----------|
| 1. INTRODUCTION..... | 3 |
| 2. QUICK START | 4 |
| 2.1 IDAS RD SOFTWARE..... | 4 |
| 2.2 SEND COMMANDS | 4 |
| 2.3 GET REAL-TIME DATA VIA RS232 | 5 |
| 2.4 CONFIGURATION | 6 |
| 3. CIRCUIT BOARD | 7 |
| 3.1 DIMENSION..... | 7 |
| 3.2 CONNECTOR | 7 |
| 3.3 CONNECTOR DEFINITION | 8 |
| 4. COMMANDS | 9 |
| 4.1 SFWV / READ FIRMWARE VERSION | 10 |
| 4.2 DCPM / READ OR SET DECOUPLED MATRIX | 10 |
| 4.3 DCPCU / CALCULATION UNIT FOR DECOUPLED DATA | 10 |
| 4.4 SMPF / READ OR SET SAMPLING RATE..... | 11 |
| 4.5 CRATE / BAUD RATE OF CAN BUS..... | 12 |
| 4.6 CFIDL / ID#1 OF CAN BUS..... | 12 |
| 4.7 CTXIDL / ID#2#3#4 OF CAN BUS | 12 |
| 5. DECOUPLED CALCULATION..... | 13 |
| 5.1 MATRIX DECOUPLED LOADCELL..... | 13 |
| 5.2 STRUCTURALLY DECOUPLED LOADCELL..... | 14 |
| 5.3 OTHER LOADCELLS | 15 |
| 6. ETHERCAT DICTIONARY..... | 16 |
| 7. CAN BUS | 17 |
| 7.1 BAUD RATE | 17 |
| 7.2 ID | 17 |
| 7.3 HOW TO GET DATA VIA CAN BUS | 17 |

1. Introduction

The OEM circuit board M8123B2 provides bridge excitation, signal conditioning, data acquisition and digital communication to the user's controller or PC via EtherCAT, CAN bus or RS232. A 24 bit sigma-delta AD converter (16 bit effective) is used to provide high resolution (1/5000 to 1/10000 of full scale) analog to digital converting. The data rate is up to 2 kHz. A 6 axis loadcell is connected to M8123B2 via a Molex connector.



Specifications:

- Analog
 - # of Channels: 6
 - Low noise instrumentation amplifiers
- Digital
 - EtherCAT, CAN bus and RS232
 - 24 bit sigma-delta ADC (16 bit effective), Sampling rate: 10~2kHz
 - Resolution: 1/5000 to 1/10000 of full scale
 - Programmable system parameters
- Connector
 - Loadcell connector: Molex connector
 - EtherCAT: Molex connector
 - CAN bus: Molex connector
 - RS232: Molex connector
 - Power supply: Molex connector, DC12 – 24V, MAX250mA
- Dimension
 - Outer diameter 54mm, Height 13.3mm, Mounting hole 3*M2.5
- Software
 - iDAS RD: Debugging software to display real-time sampling curve via RS232.
 - The dictionary file(*.xml) is supplied, can be connected into EtherCAT easily.

2. Quick start


M8123B2 and sensor were configured in SRI factory, and it can be connected to EtherCAT directly by the dictionary file (*.xml).

RS232 is supplied to debug M8123B2 and have a quick start to get sensor real time data by software iDAS RD.

- PC Requirement: WIN 7 or above
- Installation Procedure: Uncompressed iDAS RD


Note: M8123B2 only can communicate with iDAS RD via RS232. EtherCAT communication is not supported by iDAS RD.

2.1 iDAS RD software




2.2 Send Commands

Type in a command to the Command Box, and click Send. The response information will be shown in the command response window. Error will be prompted or no response will be given if the input command is wrong or is not supported by M8123B2.



2.3 Get real-time data via RS232

Step 1: Power on M8123B2 and open iDAS RD. Connect M8123B2 to PC via RS232.



Step 2: Set PortName, Baudrate and Open Port.


Step 3: Select CH1 through CH6 at the lower right corner on screen.

Step 4: Set SampRate to 100Hz, set Unit to N or Nm.

Set PointPerPackage to 10, and put in 0 at Skip.

Step 5: Select CH1 through CH6 at the top right corner on screen.

Step 6: Click "Realtime" to get data from M8123B2, the real time data will be shown in the window.



Note:

With RS232 communication, SampRate is up to 300 Hz for 6-channel data upload and 1 kHz for 1-channel data upload at BaudRate 115200bps.



If the real-time data shown by iDAS R&D is incorrect, please click Stop and send Commands DCPM and DCPCU to make sure that current matrix coefficients and calculation unit match the sensor calibration report.

2.4 Configuration

To configure decoupling matrix:

If the M8123B2 is purchased together with SRI sensor, the decoupled matrix and calculation unit of SRI sensor have been configured in the M8123B2.


When different sensor connects to M8123B2, M8123B2 must have different configuration. The method is described in chapter 5.

To configure the sampling rate:


Sampling rate can be configured by command SMPF.

3. Circuit Board


3.1 Dimension





3.2 Connector




3.3 Connector definition

| Sensor connector (Molex connector Part# 501189-2010) | | | |
|---|-------|------------|----------|
|  | PIN # | Definition | Note |
| | 1 | CH1+ | |
| | 2 | CH1- | |
| | 3 | CH2+ | |
| | 4 | CH2- | |
| | 5 | CH3+ | |
| | 6 | CH3- | |
| | 7 | CH4+ | |
| | 8 | CH4- | |
| | 9 | CH5+ | |
| | 10 | CH5- | |
| | 11 | CH6+ | |
| | 12 | CH6- | |
| | 13~18 | N/A | Reserved |
| | 19 | +E | |
| | 20 | GND | |

| EtherCAT connector (Molex connector Part# 505565-0501) | | | |
|---|-------|------------|------|
|  | PIN # | Definition | Note |
| | 1 | TXP | |
| | 2 | TXN | |
| | 3 | RXP | |
| | 4 | RXN | |
| | 5 | Shield | |

| Power connector (Molex connector Part# 505565-0201) | | | |
|---|-------|------------|------|
|  | PIN # | Definition | Note |
| | 1 | +24V | |
| | 2 | GND | |

| CAN & RS232 connector (Molex connector Part# 505565-0501) | | | |
|---|-------|------------|-------|
|  | PIN # | Definition | Note |
| | 1 | RX | RS232 |
| | 2 | TX | |
| | 3 | GND | |
| | 4 | CANH | CAN |
| | 5 | CANL | |

4. Commands

Definition:

Master: Master equipment, eg. PC, PLC, Robot controller.
 Slave: M8123B2, the DAQ supplied by SRI.

Commands are supplied for master equipment communicate with M8123B2 via RS232 or CAN bus.

| Command | Function | Note |
|---------------|--|------------|
| SMPF | Read or set sampling rate | |
| DCPM | Read or set decoupling matrix coefficient | |
| DCPCU | Read or set matrix calculation unit | mV or mV/V |
| SFWV | Read firmware version | |
| CRATE | Read or set baud rate of CAN bus | |
| CFIDL | Read or set CAN ID of slave for receiving data | |
| CTXIDL | Read or set CAN ID of slave for sending data | |

4.1 SFWV / Read firmware version

Description: To read firmware version.

Command Syntax: AT+SFWV=?

Example:

Send: AT+SFWV=?

Response: ACK+SFWV=V11.00\$OK

4.2 DCPM / Read or set decoupled matrix

Description: To read or set decoupled matrix

Command Syntax: AT+DCPM=Matrix

Example:

Send: AT+DCPM=?

Response: ACK+DCPM=(0.000041,-0.020164,-0.000348,0.020287,-0.000145,-0.000047);(-0.000160,-0.011703,-0.000089,-0.011668,-0.000217,0.023526);(-0.031415,-0.000185,-0.032273,0.000010,-0.031708,-0.000481);(-0.000888,-0.000014,0.000951,-0.000006,0.000029,0.000009);(-0.000521,0.000011,-0.000531,-0.000009,0.001061,0.000015);(0.000002,0.000754,-0.000008,0.000753,-0.000007,0.000768)\$OK

Send: AT+DCPM=(0.000041,-0.020164,-0.000348,0.020287,-0.000145,-0.000047);(-0.000160,-0.011703,-0.000089,-0.011668,-0.000217,0.023526);(-0.031415,-0.000185,-0.032273,0.000010,-0.031708,-0.000481);(-0.000888,-0.000014,0.000951,-0.000006,0.000029,0.000009);(-0.000521,0.000011,-0.000531,-0.000009,0.001061,0.000015);(0.000002,0.000754,-0.000008,0.000753,-0.000007,0.000768)

Response: ACK+DCPM=(0.000041,-0.020164,-0.000348,0.020287,-0.000145,-0.000047);(-0.000160,-0.011703,-0.000089,-0.011668,-0.000217,0.023526);(-0.031415,-0.000185,-0.032273,0.000010,-0.031708,-0.000481);(-0.000888,-0.000014,0.000951,-0.000006,0.000029,0.000009);(-0.000521,0.000011,-0.000531,-0.000009,0.001061,0.000015);(0.000002,0.000754,-0.000008,0.000753,-0.000007,0.000768)\$OK

4.3 DCPCU / Calculation unit for decoupled data

Description: To set or read calculation unit.

Command Syntax: AT+DCPCU=Unit

Example:

Send: AT+DCPCU=?

Response: ACK+DCPCU=MV\$OK

Send: AT+DCPCU=MVPV

Response: ACK+DCPCU=MVPV\$OK



4.4 SMPF / Read or set sampling rate

Description: To read or set sampling rate.

Command Syntax: AT+SMPF=SampleFreq

Example:

Send: AT+SMPF=?

Response: ACK+SMPF=300\$OK

Send: AT+SMPF=200

Response: ACK+SMPF=200\$OK

4.5 CRATE / Baud Rate of CAN Bus

Description: To read or set baud rate of CAN Bus.

Command Syntax: AT+CRATE=BR:rate

Example:

Send: AT+CRATE=?

Response: ACK+CRATE=BR:1000000\$OK

Send: AT+CRATE=BR:125000

Response: ACK+CRATE=BR:125000\$OK

Note: New configuration of CAN bus is available after re-power on.

4.6 CFIDL / ID#1 of CAN Bus

Description: To read or set CAN ID of slave for receiving data. Master use this ID to send data to M8123B2.

Command Syntax: AT+CFIDL=id

Example:

Send: AT+CFIDL=80

Response: ACK+CFIDL=80\$OK

Send: AT+CFIDL=?

Response: ACK+CFIDL=80\$OK

Note: New configuration of CAN bus is available after re-power on.

4.7 CTXIDL / ID#2#3#4 of CAN Bus

Description: To read or set CAN ID of slave for sending data. M8123B2 use these IDs send data to master.

Command Syntax: AT+CTXIDL=id#2, id#3, id#4

Example:

Send: AT+CTXIDL=291,292,293

Response: ACK+CTXIDL=291,292,293\$OK

Send: AT+CTXIDL=?

Response: ACK+CTXIDL=291,292,293\$OK

Note: New configuration of CAN bus is available after re-power on.

5. Decoupled Calculation

If the M8123B2 is purchased together with SRI sensor, the decoupled matrix and calculation unit of SRI sensor have been configured in the M8123B2. The decoupled matrix and calculation unit can be updated by Command DCPM and DCPCU when necessary.

Decoupled matrix and calculation unit can be found in the calibration report. Two different reports formats will be provided according to the sensor's structure.

5.1 Matrix decoupled loadcell

The decoupled matrix and calculation unit are provided in the calibration report, as shown below:

| | | | | | | |
|---------------|----------|----------|----------|----------|----------|----------|
| [DECOUPLED] = | -0.03220 | 0.49984 | 0.00136 | -1.01398 | -0.01208 | 0.50908 |
| | 0.00046 | 0.84855 | 0.01531 | 0.02114 | -0.03126 | -0.86432 |
| | 1.19167 | 0.00028 | 1.20748 | 0.00224 | 1.19808 | 0.00320 |
| | -0.06386 | -0.00097 | 0.13028 | -0.00009 | -0.06523 | 0.00012 |
| | -0.11090 | 0.00016 | -0.00049 | 0.00075 | 0.11138 | -0.00019 |
| | -0.00046 | 0.08401 | -0.00067 | 0.08304 | -0.00089 | 0.08433 |

The six axis loads can be decoupled as follows:

Step 1: Obtain the raw data of Channels 1 through 6 into mV
 [DAT] = {rawchn1, rawchn2, rawchn3, rawchn4, rawchn5, rawchn6}
 where rawchn1, rawchn2, rawchn3, rawchn4, rawchn5 and rawchn6 are in mV

Step 2: To calculate decoupled loads
 $[RESULT]^T = [DECOUPLED] * [DAT]^T$
 where [RESULT] = {FX, FY, FZ, MX, MY, MZ}. Force Unit: N. Moment Unit: Nm
 [DECOUPLED] is the above decoupled matrix

The Commands to input the matrix coefficients and to set the calculation unit are as follows:

AT+DCPM=(-0.03220,0.49984,0.00136,-1.01398,-
 0.01208,0.50908);(0.00046,0.84855,0.01531,0.02114,-0.03126,-
 0.86432);(1.19167,0.00028,1.20748,0.00224,1.19808,0.00320);(-0.06386,-
 0.00097,0.13028,-0.00009,-0.06523,0.00012);(-0.11090,0.00016,-
 0.00049,0.00075,0.11138,-0.00019);(-0.00046,0.08401,-0.00067,0.08304,-
 0.00089,0.08433)
 AT+DCPCU=MV

5.2 Structurally decoupled loadcell

The sensitivity provided in the calibration report needs to be converted into a matrix as shown below:

| Voltage Calibration | | | | | | | |
|---------------------|----------|-------------|--------------|------------|-------------------|-------------|--------|
| Bridge | Capacity | Zero Offset | Nonlinearity | Hysteresis | Output @ Capacity | Sensitivity | Change |
| | N/Nm | mV/V | %FS | %FS | mV/V | mV/V/EU | % |
| FX | -5400 | 0.0131 | -0.08 | -0.33 | -3.0269 | 5.6054E-04 | 0.00 |
| FY | 5400 | 0.0007 | 0.08 | 0.27 | 3.0500 | 5.6481E-04 | 0.00 |
| FZ | -10800 | 0.0001 | -0.09 | -0.18 | -0.7369 | 6.8230E-05 | 0.00 |
| MX | -540 | -0.0027 | -0.09 | -0.10 | -1.8703 | 3.4636E-03 | 0.00 |
| MY | -540 | -0.0090 | -0.09 | -0.09 | -1.9014 | 3.5210E-03 | 0.00 |
| MZ | 432 | -0.0099 | 0.05 | 0.08 | 1.9603 | 4.5378E-03 | 0.00 |

Sensitivity unit is mV/V/Eu,. The diagonal elements of the matrix are the inverse of the sensitivities (1/Sensitivity). The calculation unit is mV/V.

| | | | | | |
|-----------|-----------|------------|----------|----------|----------|
| 1783.9940 | 0 | 0 | 0 | 0 | 0 |
| | | | | | |
| 0 | 1770.5069 | 0 | 0 | 0 | 0 |
| 0 | 0 | 14656.3095 | 0 | 0 | 0 |
| 0 | 0 | 0 | 288.7169 | 0 | 0 |
| 0 | 0 | 0 | 0 | 284.0102 | 0 |
| 0 | 0 | 0 | 0 | 0 | 220.3711 |

The Commands to input the matrix coefficients and to set the calculation unit are as follows:

AT+DCPM=(1783.9940,0,0,0,0,0);(0,1770.5069,0,0,0,0);(0,0,14656.3095,0,0,0);(0,0,0,288.7169,0,0); (0,0,0,0,284.0102,0); (0,0,0,0,0,220.3711)
 AT+DCPCU=MVPV

Four possible conversion formula:

- 1) Sensitivity unit is mV/V/Eu. The conversion formula is 1/Sensitivity.
 Calculation unit is mv/V: AT+DCPCU=MVPV.
- 2) Sensitivity unit is mV/Eu. The conversion formula is 1/Sensitivity.
 Calculation unit is mv: AT+DCPCU=MV.
- 3) Sensitivity unit is V/V/Eu. The conversion formula is 1/Sensitivity/1000.
 Calculation unit mv/V: AT+DCPCU=MVPV.
- 4) Sensitivity unit is V/Eu. The conversion formula is 1/Sensitivity/1000.
 Calculation unit is mv: AT+DCPCU=MV.

5.3 Other Loadcells

Except 6 axis loadcells, other sensors with voltage out put can also be connected to M8123B2. For calculation in M8123B2, a matrix is also needed.

Please follow the method described below to get the matrix.

3 Axis loadcell

| Voltage Calibration | | | | | | | |
|---------------------|----------|-------------|--------------|------------|-------------------|-------------|--------|
| Bridge | Capacity | Zero Offset | Nonlinearity | Hysteresis | Output @ Capacity | Sensitivity | Change |
| | N/Nm | mV/V | %FS | %FS | mV/V | mV/V/EU | % |
| FX | -20000 | 0.0101 | -0.13 | -0.28 | -2.8941 | 1.4471E-04 | 0.00 |
| FY | 20000 | -0.0027 | 0.11 | 0.19 | 2.8894 | 1.4447E-04 | 0.00 |
| FZ | -20000 | 0.0175 | -0.07 | -0.27 | -0.5441 | 2.7207E-05 | 0.00 |

Sensitivity unit is mV/V/Eu. The diagonal elements of the matrix are the inverse of the sensitivities (1/Sensitivity).

| | | | | | |
|-----------|-----------|------------|---|---|---|
| 6910.3725 | 0 | 0 | 0 | 0 | 0 |
| 0 | 6921.8523 | 0 | 0 | 0 | 0 |
| 0 | 0 | 36755.2468 | 0 | 0 | 0 |
| 0 | 0 | 0 | 0 | 0 | 0 |
| 0 | 0 | 0 | 0 | 0 | 0 |
| 0 | 0 | 0 | 0 | 0 | 0 |

The Commands to input the matrix coefficients and to set the calculation unit are as follows:

AT+DCPM=(6910.3725,0,0,0,0,0);(0,6921.8523,0,0,0,0);(0,0,36755.2468,0,0,0);(0,0,0,0,0,0);(0,0,0,0,0,0);(0,0,0,0,0,0)

AT+DCPCU=MVPV

Torque Sensor

| Voltage Calibration | | | | | | | |
|---------------------|----------|-------------|--------------|------------|-------------------|-------------|--------|
| Bridge | Capacity | Zero Offset | Nonlinearity | Hysteresis | Output @ Capacity | Sensitivity | Change |
| | Nm | V | %FS | %FS | V | V/EU | % |
| MZ | 100 | -0.0049 | 0.04 | 0.27 | 2.0445 | 2.0445E-02 | 0.00 |

Sensitivity unit is V/Eu.

The first row and the first column equal to 1/sensitivity/1000.

Calculation unit is mV.

The Commands to input the matrix coefficients and to set the calculation unit are as follows:

AT+DCPM=(0.048913,0,0,0,0,0);(0,0,0,0,0,0);(0,0,0,0,0,0);(0,0,0,0,0,0);(0,0,0,0,0,0);(0,0,0,0,0,0)

AT+DCPCU=MV



6. EtherCAT Dictionary

| Object | Name | Data Type | W/R | Discription |
|-----------|--------------------------|-----------|-----|---|
| 0x1000 | Device Type | UINT32 | RO | |
| 0x1008 | Manufacturer Device Name | STRING | RO | |
| 0x1009 | Hardware Version | STRING | RO | |
| 0x100A | Software Version | STRING | RO | |
| 0x1018 | Identity Object | RECORD | RO | |
| 0x1018.01 | Vendor ID | UINT32 | RO | |
| 0x1018.02 | Product Code | UINT32 | RO | |
| 0x1018.03 | Revision Number | UINT32 | RO | |
| 0x1018.04 | Serial Number | UINT32 | RO | |
| 0x1601 | RPDO | UINT32 | RO | |
| 0x1A03 | TPDO | UINT32 | RO | |
| 0x1A02 | TPDO | UINT32 | RO | |
| 0x1C12 | SM2 PDO | REC | RW | |
| 0x1C13 | SM3 PDO | REC | RW | |
| 0x6030.01 | DataNo | UINT16 | RO | unsigned int 16bit 0~65535 increment each sample. |
| 0x6030.02 | Fx | REAL | RO | float 32bit eng. unit: N |
| 0x6030.03 | Fy | REAL | RO | float 32bit eng. unit: N |
| 0x6030.04 | Fz | REAL | RO | float 32bit eng. unit: N |
| 0x6030.05 | Mx | REAL | RO | float 32bit eng. unit: Nm |
| 0x6030.06 | My | REAL | RO | float 32bit eng. unit: Nm |
| 0x6030.07 | Mz | REAL | RO | float 32bit eng. unit: Nm |
| 0x6020.01 | DataNo | UINT16 | RO | unsigned int 16bit 0~65535 increment each sample. |
| 0x6020.02 | Fx | INT32 | RO | Fx = INT32/10000 eng. unit: N |
| 0x6020.03 | Fy | INT32 | RO | Fy = INT32/10000 eng. unit: N |
| 0x6020.04 | Fz | INT32 | RO | Fz = INT32/10000 eng. unit: N |
| 0x6020.05 | Mx | INT32 | RO | Mx = INT32/10000 eng. unit: Nm |
| 0x6020.06 | My | INT32 | RO | My = INT32/10000 eng. unit: Nm |
| 0x6020.07 | Mz | INT32 | RO | Mz = INT32/10000 eng. unit: Nm |
| 0x7010.01 | Para1 | UINT16 | RW | NA, reserved for future use |
| 0x7010.02 | Para2 | INT16 | RW | NA, reserved for future use |
| 0x7010.03 | Para3 | INT16 | RW | NA, reserved for future use |

7. CAN Bus

M8123B2 supports CAN 2.0, and the maximum baud rate is 1Mb/s.

7.1 Baud Rate

The default Baud Rate of CAN Bus is 1Mb/s, and the Baud Rate can be changed by Command CRATE.

7.2 ID

M8123B2 uses CAN Bus with standard 11-bits ID. ID can be configured by Command CFIDL and CTXIDL. Please note that the configured ID is unavailable until M8123B2 is restarted. One M8123B2 have 4 IDs.

ID #1:

Master use this ID to send data to M8123B2. Configure by Command CFIDL. Default ID #1 is 0x80.

ID #2:

M8123B2 use this ID send data to master. Configure by Command CTXIDL. Default ID #2 is 0x291.

ID #3:

M8123B2 use this ID send data to master. Configure by Command CTXIDL. Default ID #2 is 0x292.

ID #4:

M8123B2 use this ID send data to master. Configure by Command CTXIDL. Default ID #2 is 0x293.

7.3 How to Get Data via CAN Bus

Step1:

By RS232 communication, configure CAN ID and baud rate by commands CRATE, CFIDL and CTXIDL.

Step2:

By CAN Bus, master send 1(0x01) or 2(0x02) with ID #1 to M8123B2 to notice the start of getting data. 1 means to get one package of data. 2 means to get data continuously.

To stop get data continuously, master should send 0(0x00) with ID #1 to M8123B2.

Step3:

By CAN Bus, M8123B2 send 3 packages of data to Master with ID #2, ID #3, and ID #4 in order. Every package contains 8 bytes data, so there are 24 bytes data. One six axis loadcell has 6 channels FX, FY, FZ, MX, MY and MZ, therefore, each channel has 4 bytes data.

| Data Package | Package 1 with ID #2 | | Package 2 with ID #3 | | Package 3 with ID #4 | |
|---------------|----------------------|--------|----------------------|--------|----------------------|--------|
| | 4Bytes | 4Bytes | 4Bytes | 4Bytes | 4Bytes | 4Bytes |
| Definition | FX | FY | FZ | MX | MY | MZ |
| Variable Type | Float | Float | Float | Float | Float | Float |