



1. Nut
2. Washer
3. Bolt
4. Tension rod assembly

412_MM_53_0004

Figure 53-4. Tension Rod Assembly — Removal and Installation