



ADJUSTMENTS:

*	SW1	ENGINE NO. 1 SELECT
*	SW2	ENGINE NO. 2 SELECT
	SW3	ROTOR LOW LIMIT SELECT
	SW4	ROTOR HIGH LIMIT SELECT
	R31	AUDIO ADJUST

WARNING LIGHTS:

L ₁	-	ENGINE NO. 1 LAMP
L ₂	-	ENGINE NO. 2 LAMP
L _R	-	ROTOR LAMP

NOTE

Positions 6 and 7 on both SW1 and SW2 are electrically connected to positions 5 of respective switch.

212_MM_96_0016

Figure 96-11A. RPM Limit Detector