



NOTES

- △1 Location of temperature indicator TEMP-PLATES on outer couplings. (BHT-212-CR&O, Chapter 65)
- △2 Torquing sequence is as follows: 10, 12, 13, and 11.
- △3 Clamp halves shall be kept together as a set.
- △4 Location of hanger bearing assembly visual overtemperature indicator stripe. (BHT-212-CR&O, Chapter 65)

212-M-65-1

Figure 65-1. Tail rotor driveshaft and hangers