



NOTES

1 Shipping spacer is removed from gearbox prior to installation.

2 Refer to BHT-212-CR&O for TEMP-PLATE installation procedure.

1. Tail rotor gearbox
2. Cap assembly
3. Lever
4. Nut
5. Washer
6. Washer
7. Bolt
8. Link assembly
9. Cotter pin
10. Thin steel washer
11. Nut
12. Vertical fin cover
13. Driveshaft
14. Support fitting
15. Spacer (NAS43DD6-49) (2)
16. Coupling
17. Stud
18. Temperature indicator TEMP-PLATE

212-M-65-11

Figure 65-11. Tail rotor gearbox