



GRIP (204-011-121)

- |   |                                                                                     |                                                                                                                                             |
|---|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------|
| 1 |  | <b>AREA TO BE INSPECTED</b><br><b>UPPER AND LOWER TANGS</b><br><b>ALL EXPOSED SURFACES</b>                                                  |
| 2 |  | <b>AREA TO BE INSPECTED</b><br><b>GRIP BARREL LEADING</b><br><b>AND TRAILING SIDES</b><br><b>EXPOSED SURFACE (-009</b><br><b>GRIP ONLY)</b> |

#### NOTES

- |   |                                                |
|---|------------------------------------------------|
| 1 | Inspect every 25 hours for all grips.          |
| 2 | Inspect daily for grip (204-011-121-009) only. |

212\_MM\_05\_0008

Figure 5-4. Inspection of Main Rotor Hub Grip Tangs and Barrel