



1. Idle stop adjustment screw (ENG 2)
2. Idle stop lever (ENG 2)
3. Idle stop solenoid (ENG 2)
4. Plunger
5. NAS43DD3 spacers
6. Plunger
7. Idle stop solenoid (ENG 1)
8. Idle stop lever (ENG 1)
9. Idle stop adjustment screw (ENG 1)
10. Bracket assembly
11. Base

NOTES

- 1 0.003 to 0.015 in. (0.08 to 0.38 mm) gap typical with plunger retracted.

Figure 76-4. Engine Idle Adjustment

212_M_76_4_c01