


tpl_task_static architecture dependant fields for the C167



Architecture dependant fields

The 2 fields **context** and **stack** are located in the `tpl_task_static` and may be located in ROM.

context contains the context storage. For the C167 architecture, the context can only be the integer context.

stack contains the system stack and the user stack of the task. The system stack is located in *iram* and is used only for function calls. The user stack is used for local variables and is located in RAM.

- `sys_stack_zone` a pointer to the memory area dedicated to the system stack of the task.
- `sys_stask_size` the size of the stask counted in bytes.
- `user_stack_zone` a pointer to the memory area dedicated to the user stack of the task.
- `user_stask_size` the size of the stask counted in bytes.