




ELEKTROMAG

Organize Sanayi Bölgesi 3.Street 15.Alley
Çerkezköy/TEKİRDAĞ

Tel:+90 (282) 726 13 14 - Fax:+90 (282) 726 14 43

E-mail: info@elektromag.com.tr



FILLING & CAPPING MACHINES

M-KAP-C01

USER MANUAL

YOUR INNOVATION SOLUTION PARTNER





Turnkey Liquid Line
Solutions



Customer-Specific Solutions



R&D

About us

Started production in a small workshop in Topçular in 1978, Elektromag has become one of the leading companies in the Turkish packaging machinery sector with its 14,000 m² closed area and its 70 employees. In the rapidly developing packaging industry, our customers are in search of affordable yet high quality and high capacity machines. Along with the technological developments in existing machines, Elektromag aims to engineer, manufacture and introduce simple and high capacity machines.

Our Production Programme

Automatic Machines

Plastik Bottle Unscrambler machine	Cartoning
Blow air bottle cleaning machine	Packaging Machine
Liquid Filling without gases product	Security Band Machines
Capping	Shrinking Machinery
Labelling	Body Sleeve Machinery
Open Cartoning	Datamatrix Coding Machinery
Cartoning	Ampul Labelling

Semi-automatic Machines

- Capping
- Filling





©2020 Elektromag Makine San. Ve Tic.A.Ş.

All rights reserved.

No part of this user manual may be reproduced, stored in a retrieval system or transmitted in any form or by any means electronic, mechanical, photocopying, recording, scanning or otherwise. This is valid for diagram and/or scheme indicated in publication.

The data in this user manual is based on general data about the method of operation of parts and machinery. It is known the published date, we have reserved the right to make a change without notice.

This document is valid for given version machines. The manufacturer therefore assumes no responsibility for any damage or injury caused by deviating from the technical specifications of the specified machine.

All possible care was taken in creating this document, but the manufacturer does not accept responsibility for errors or any consequences.

PLEASE READ THIS DOCUMENT FOR YOUR SAFETY.

2020





The ongoing success of Elektromag depends on quality, which is the most important competitive factor of today. The quality of the product and company for our company is an inseparable whole.

Our Quality Policy:

- To continuously improve and improve quality management system .
- To ensure that the product is completely suitable for the purpose used.
- To ensure that the customer can obtain the product on time and in accordance with Sunday prices, to reflect the latest technological developments on the products, not to fall behind the technology.
- To increase the customer's confidence in the company's competence.
- To ensure that all employees are qualified and qualified in their fields and to reinforce them through training.
- Ensure a regular, clean and reliable working environment
- To ensure that the instructions, procedures and job descriptions used within the company are adhered to one by one.
- Working in accordance with national laws and regulations



1

**INFORMATION.....6**

- 1.1 Main Components.....7
- 1.2 Manufacturer Definition Plate.....8
- 1.3 Service and Technical Support.....8
- 1.4 Machinery Definition Plate.....8
- 1.5 Necessary Environmental Conditions.....9
- 1.6 Technical Specifications.....9
- 1.7 Destruction.....9
- 1.8 Guarantee.....10
- 1.9 The persons who authorized to operate the machine.....12

2

**SECURITY.....13**

- 2.1 Security Information.....14
- 2.2 Safety Instructions.....15
- 2.3 Safety Tags and Markings.....17
- 2.4 Security and Protection Device.....18

3

**TRANSPORT AND INSTALLATION.....21**

- 3.1 Carrier.....22
- 3.3 Electrical connection of the machine23
- 3.5 Starting.....24
- 3.6 Cap Feeding.....25

4

**OPERATION.....26**

- 4.1 Description of Control.....27
- 4.2 Operator Console.....28
- 4.3 Format Change.....39
- 4.4 Operator Placement.....43
- 4.5 Working Cycle.....43
- 4.6 Capless Product.....43
- 4.7 Unexpected Electrical Fluctuations.....44
- 4.8 Alerts.....44
- 4.9 Stopping The Machine.....44

5

**MAINTENANCE.....45**

- 5.1 Information Notes.....46
- 5.2 General Safety Rules.....46

6

**SPARE-PARTS**

- 6.1 Components subject to wear and mechanical stress.....49






Information

1



1.1 Main Components



1) Vibratör

2) Ball Choicer

3) Closing Unit

4) Drilling Unit

5) Filling Unit

6) Electricity Panel

7) Conveyor

8) Chassis

9) PE Carrier Group

10) Plexiglas Cap

11) Eject Unit

12) Reject Box



1.2 Manufacturer Definition Plate

ELEKTROMAG MAKİNA

Ç.O.S.B 15.Sokak No.3
59500 - ÇERKEZKÖY / TEKİRDAĞ
Phone. 0282.726.13.14
Fax. 0282.726.14.43
www.elektromag.com.tr



1.3 Service and Technical Support

Please contact the manufacturer for settings, maintenance, and information that fall outside this guide. We are always willing to help you. Make sure you have the following data before you search:

- Machinery Model
- Serial Number

1.4 Machinery Definition Plate

Definition Plate is indicated below:


ELEKTROMAG MAKİNE SANAYİ VE TİC. A.Ş.
TYPE
SERIAL NO
DATE
WEIGHT
POWER
Ç.O.S.B 15. CAD. 15. SOK. NO:3 ÇERKEZKÖY, TEKİRDAĞ/TÜRKİYE TEL: +90(282) 726 1314 Pbx www.elektromag.com.tr




1.5 Necessary Environmental Conditions

To ensure proper operation of the machine with an ambient temperature not exceeding 5°C and 45°C, rain, hail, snow, fog, dust should be kept in a closed environment for protection. The work area must be clean, sufficiently lit and free of explosive gases.

1.6 Technical Specifications

System	Lineer
Work Principle	Star, Stalling work
Construction	All surfaces appearing in steel Aisi 304 , All contactable surface with AISI 316,
Conveyor	82mm PVC with pallet, ~3.
Conveyor Height	Standart 950 mm (±50mm)
Package	Plastic
Control Unit	Beckhoff Brand PLC Contr
Electricity Requirement	5 kw
Capping System	Mechanic, Torque settings,
Capping Head	1
Cylinder	2 pcs.
Cylinder Volume	100cc
Basis Weight	~600 kg
Filling Sensitivity	± %0,3
Filling Range	10-100cc

1.7 Destruction

Destruction occurs at the end of the machine's lifetime, which has a life of more than ten years under normal operating and maintenance conditions .When disposing of the machine at the end of its life, all components must be disposed of in appropriate dumps in accordance with applicable legislation. Send used oils to appropriate collection centers. Before disposal, plastic or rubber parts, as well as electrical and electronic components, must be separated. Parts made entirely of plastic, aluminum and steel can be recycled when taken to appropriate collection centers.



1.8 Guarantee

General Conditions

- 1-** Machinery; electrical, electronic, hydraulic, pneumatic and automation equipment except (these parts are covered by manufacturer's warranty) against manufacturing and assembly defects are covered by our company warranty. Other than the technical conditions required by the user and the machine (voltage fluctuations, causes of compressed air, etc.) failures caused by running with ELEKTROMAG company has been excluded from the warranty coverage in the failures that occur as a result of the intervention of non-certified users.
- 2-** Warranty period starts from the date of shipment and is 2 (two) years or 3000 (eight thousand) hours is guaranteed.
- 3-** During the warranty period, the period of maintenance, repair and replacement due to manufacturing and assembly errors shall be added to the warranty period, and this period shall include:
starting from the date of application to the station and to the manufacturer or seller company for its replacement.
- 4-** As a result of the failure of our product due to manufacturing and assembly errors within the warranty period, maintenance and repair of our factory will be done free of charge without the cost of Labor and spare parts. However, the transportation, accommodation and costs of the technical service that will go to the service operations that require on-site repair are the customer's own.
- 5-** If it is not possible to repair the defects caused by manufacturing and assembly faults within the warranty period, the necessary parts/parts will be replaced in accordance with the report to be given by our maintenance and repair company.
- 6-** To fulfill our warranty obligations in accordance with the relevant provisions of the Consumer Protection Law dated 3/2/1995 and numbered 4077 if so, we accept and undertake to make the situation public by the Ministry of Industry and trade.
- 7-** Consumers must notify the manufacturer of maintenance, repair and cases by fax or mail.
- 8-** If the consumer is a injured part, the Ministry of Industry and trade must apply to the General Directorate of measurements and Quality Control.



Special Warranty Terms

1- Our company is not responsible for any damage that may occur during the transportation and placement of the customer.

2- The warranty is valid only for failures that may occur in this machine and our company cannot be held responsible for the damage of any other goods or persons during the operation of the machine, and cannot claim any rights or compensation under any name.

3- Failures that may occur within the warranty period are only resolved by our service personnel. The warranty is void in the event that other persons interfere with the machine without our written agreement.

4- The determination of the faults within the scope of the warranty and the manner and method of their removal belong to our service personnel. Defective parts can be repaired or replaced with new ones. The repair of the faults within the warranty period can be done at the place where the machines are located or at our company's shipping costs depending on our request.

5- In order to resolve a complaint within the scope of the warranty, we will be given sufficient time by the customer and, when necessary, we will provide assistance and tools and equipment.

6- In order for the warranty to be valid, the customer must have made all payments to ELEKTROMAG in full and on time.

7- If damage is done on the warranty certificate, the original serial number on the machine is removed or destroyed, this warranty shall be void.

8- The warranty shall remain in force in the event that the obligations and responsibilities of the customer written in this document, user manual and catalogue are fully fulfilled.



1.9 The persons who authorized to operate the machine



The following are the people who can work on the machine after once you have received all the necessary instruction in this guide;



Security Manager

The security manager will ensure that all people running the machine receive all the instructions set out in this manual. Occupational Safety Training should be provided.



Operator

The operator must have experience gained under the guidance of expert staff. He can only perform the operations assigned to him in this manual. Under no circumstances is it appropriate for the machine to be operated by untrained persons.



Mechanical Maintenance Technician

Mechanical maintenance technician should have general machine experience and also special experience in this machine model.



Electrical Maintenance Technician

The electrical maintenance technician should have the experience of the electrical panel as well as the experience of the electrical panel and the electrical components in this machine.



Manufactured Company

For other actions not mentioned in this manual or assigned to a person other than those mentioned above, contact ELEKTROMAG.

Security

2



2.1 Security Information



The security manager is responsible for informing employees about the risks associated with the use of the machine. It also has to train workers until they can ensure their own safety and the safety of others.

Failure to pay attention to Basic Rules and precautions during operation, maintenance or repair of the machine can cause accidents. Potentially dangerous situations must be eliminated or reported before accidents occur. The operator must be aware of potential hazards and have the necessary training, work capability and tools.

ELEKTROMAG does not accept responsibility for accidents or damage caused by improper use of the machine. The enterprise is obliged to observe applicable safety.

There are safety warning signs on the machine. Safety warning signs are described in the guide. The operator must fully comply with these safety signs. Failure to comply may cause serious damage to itself and its environment.



ATTENTION !


Failure to comply with these warnings may result in injury to the operator.



ATTENTION !

Failure to comply with these warnings may damage the machine.

ELEKTROMAG cannot predict every possible danger. The warnings in this guide are not all inclusive. Ensure that there is no danger to yourself or anyone else if instruments, procedures and working methods not recommended by ELEKTROMAG are used.



Use only the original part recommended by ELEKTROMAG

ELEKTROMAG does not accept responsibility for the use of non-genuine spare parts.

2.2 Safety Instructions



Attention!

The instructions below do not prevent all hazards that may be encountered while using the machine. Following these warnings, along with the operator's common sense and experience, is the only sure way to prevent accidents.

The presence of a technician may be necessary during Special Operations (change of parts, maintenance, loading etc.).

The operator and technician should work together. The responsible operator is obliged to check that it is working under the security conditions.

If an operation or intervention is required that is not included in the manual, consult Elektromag before proceeding.

Access to the work area or machine intervention is not permitted except for the responsible operator and the authorized person.

In the event that the customer attaches an accessory to the machine that cannot be supplied by ELEKTROMAG, they are obliged to carry out the necessary checks to ensure compliance with the safety conditions. In all cases, ELEKTROMAG does not accept responsibility for any potential problems arising from the use of this section.

The machine should not be operated in an abrasive or explosive environment.

Keep the machine away from objects that could damage its operation and cause injury to people.

Wet or oily floors can cause accidents. Immediately clean and dry any liquid or oil stains that occur during any work done on the machine.



Avoid using flammable or toxic solvents such as gasoline, benzene, ether, or alcohol for cleaning.

Avoid prolonged contact with solvents and inhalation of vapors. Keep away from outdoor or heat sources. Provide adequate ventilation.

Prolonged overloads or disruptions can cause electrical motors and electrical equipment to over heat, resulting in the emission of harmful fumes. Turn off the power immediately and fan the media. Do not approach the machine until the resulting smoke is removed.

Never use drain water with a pipe in case of fire, use a CO2 fire extinguisher tube instead.





When compressed air is used to clean the machine, the operator, any assistant and maintenance technician must wear protective clothing, protective glasses and masks to protect them from possible flying debris.

Employees should use work gloves, shoes, and hearing protection when the acoustic radiation pressure at work exceeds 85db (A), as required. Wear the appropriate work clothes. For long hair, use a hairnet to avoid the risk of entanglement.

The manual must always be kept at hand so that it can be consulted to check the correct working cycle. In the event that this guide is lost or damaged, a backup copy must be requested from the Elektromag.

Structural damage, renovations, alterations or improper repairs may alter the protection capacity of the machine and therefore the warranty may expire. Only ELECTROMAG technicians can make any changes.

Note that when a red warning light is on, there is a fault in the machine, and therefore the type of error must be identified before proceeding.

During maintenance operations on the machine, a note should be placed on the machine, preferably on the control panel that says "do not operate the machine".

When conducting authorized intervention of a special technical maintenance nature, inspection or repair, the assigned person may be required to disable (partially or completely) some of the safety devices and to open or remove protective guards. It is the personal responsibility of the authorized person after completing the task to ensure the operation of these security devices and the related guards.

To Climb the machine is forbidden.

Electrical cables, switches, buttons, etc. do not touch with wet hands.

There is a red emergency button on the control panel or chassis to stop the machine.

2.3 Safety Tags and Markings

Safety tags are available on the machine.



Attention!

Make sure all safety signs are not damaged. Tags should be cleaned by using cloth. Never use a solvent material. Replace damaged labels with new labels available from Elektromag. If the label is part of a machine that is being replaced, make sure that a new label is pasted.



2.4 Security and Protection Device



The emergency button stops all movement of the machine, but does not cut the voltage on the electrical board.

Emergency Button (STOP)



Attention!

Specified components have special Prevention for security . In case of failure or wear, replacement must be made using parts supplied or permitted by the manufacturer. Protection covers should not be removed while the machine is running.

2.5 The Remains Risks

The manufacturer recommends full compliance with the instructions, procedures, recommendations contained in this manual and the applicable safety regulations, including the use of both machine-fitted and personal safety equipment.

Attention!

As a measure of security interests, the operation of security devices should be checked regularly. Additional hazards or risks of unforeseen consequences no mechanical, electrical or pneumatic modifications are strictly prohibited, so as not to create them.



The risks that remain within the scope of machine foresight are as follows::

Lack of adequate lighting If the machine is placed in a dark area, provide a 24-volt portable lamp (for maintenance only)

Electrical risk due to needed maintenance Only trained personnel are allowed to intervene. Insulated work clothes if necessary (gloves etc.) should be worn.

Attention!

Before connecting to the power supply, ensure that the AC current at the installation point does not exceed the appropriate value on the meter. If this is not the case, the necessary action must be taken at the customer's expense.



Risk of misuse in the presence of explosives or flammable substances The machine should not be used in flammable powders or in areas containing flammable liquids that may evaporate.

The risk of working in humidity environment

Follow the limitations described in this guide. Section 1.5 the necessity of environmental conditions.

The risks that may occur when moving the machine

It is recommended that the machine or its parts be removed from the point provided, removed to the minimum height required by appropriate means, and moved at slow speed by checking whether the persons assisting in the operation are at a safe distance from the item being carried.

Before moving, make sure the passageways are clean and there are no loose objects in the machine. It is important that to avoid sudden movements or movements that may be dangerous to people in the area, the experienced people should do this thing.

Risk of failure in Panel, safety, protection and emergency stop circuits

Panel, safety, protection and emergency stop systems may not work in case of circuit failure. It is therefore recommended that their functionality be checked periodically.



The Warning Signs in the Machine

As a result of risks and identification, the manufacturer has affixed a minimum warning label to the machine. Other warning signs that must be affixed to the machine about possible risks are the customer's responsibility. The user is obliged to change the warning labels in case of wear or damage.



Attention!

Removal of safety tags and/or warning signs is strictly prohibited. The manufacturer does not accept any responsibility for the safety of the machine if this provision is not taken into account.




Attention!

People being exposed to the moving parts of the machine can create dangerous situations for their safety. It is strictly prohibited to operate the machine until the fixed protection components provided are properly installed. Tampering or removing the bodyguards attached to the machine is strictly prohibited.

Transport and Installation

3



3.1 Carrier



It is the customer's job to ensure that the support Surface power is sufficient to carry the weight of the machine (Weight 950~Kg) Lift and move the machine using a Forklift. Place both forks of the forklift, as in the representative picture . (Take into account the center of gravity) .



When carrying the machine using a forklift, lift the load up 200mm above the ground and tilt it backwards. Consider the height of the workspace when lifting the machine .Make sure the passageway is clean and there are no loose objects in the machine before you start the moving.

Before attempting to move the machine, the following initial preparations must be made:

- Make sure the machine is not fixed to the floor
- Remove all removable parts
- Block all moving parts to avoid damage during transport
- Use sufficient lifting equipment for specified weight
- Empty/remove the product from the machine.

3.2 Settlement

Attention!

Before starting the docking process, a preliminary visual scan of the machine must be performed to determine any damage during the transport phase.

In the event of damage to one or more components during settlement, ensure that necessary precautions are taken when informing the manufacturer about the problem and the path to be applied. The machine will operate within the expected technical parameters as long as it is properly placed or secured on the workshop floor.

Attention!

Only properly trained and experienced persons can make electrical connections.

3.3 Electrical connection of the machine


Electric Connection to the machinery:
Line Connection

3.4 Pneumatics Connection

Attention!

Only properly trained and experienced persons can connect the pneumatic system. Suitable personal protective equipment should be used during connection process

To ensure the correct operation of the machine, the pneumatic supply system must be at 4 - 6 bar pressure. Connect the (representation) arrow to the point in the image shown below.



3.5 Starting

After you have completed all the connections described in the previous section, run the machine. If the phase sequence is incorrectly connected, the phase control part on the panel does not energize the machine. Correct phase sequence. Ensure that all machine units are installed correctly. Ensure that all utilities, both electrical and pneumatic, are connected correctly. Make sure there is no problem with the machine, the mechanical operating range and the security guards (doors) are working properly. Check security systems: emergency button, door switches etc. The work area consists of objects (cables, pipes, etc.) that can create obstacles and hazards for employees.) make sure it is free. Check the function of the buttons and display on the main control panel and the accuracy of the relationship between the command and the function.

Adjust the pressure of the pneumatic system.



Attention!

Electrical and pneumatic connections must be made by persons authorized to mount and maintain the machine and use the necessary personal protective equipment. Check that there are no air leaks in the valves at the joints. Installation and adjustment of the equipment must be done when the machine is stopped and power supplies are disabled. By adjusting or adjusting machinery and equipment to prevent any danger that may come to humans or the machine before starting any relevant activity, ensure that the work area is free of unauthorized people or unnecessary tools and that there are no obstacles.



3.6 Cap Feeding


Fill the selector chamber with a ball **(A)**

Fill the Vibrator chamber with cover **(B)**

Ensure that the canal is at the same height as the conveyor **(C)**

Make the pipe connection **(D)**

Adjust height **(E)**




Operation 4

**Attention!**

Unauthorized use of the machine is prohibited.

Operators and maintenance personnel carrying out approved activities on the machine should be properly trained to use personal protective equipment such as safety shoes and gloves and to avoid hazards arising from such activities.

4.1 Description of Control




- (A) Operator Console**
Touchable HMI that is controlled Production Information, Receipt entry, time adjustment, etc.
- (B) Conveyor start/stop**
Conveyor open/close
- (C) Emergency Fill Buton**
- (D) Machinery start / stop**
Filling&Capping start/stop
- (C) Load Separator**
Open/Close of the machine



4.2 Operator Console

The interface designed for this particular machine model gives information within the scope of the operator and technician.

Üst Gösterge




- 1) System clock indicator box. If the background color is red, the communication between the drivers is broken. Yesil means communication is provided.
- 2) The name of user logged in is the instrumental panel. If you are not logged in, you can log in by clicking on the empty box.
- 3) Quick alarm information screen. Click on the detailed alarm page opens.


log in

Login

Please locate the Load separator (I) and waiting to open screen. Choose Language (**Pic-4.2**)



Main Menu




- 4) Opens the screen where alarms can be seen and reset
- 5) Filling settings can be made opens the screen.
- 6) Opens the screen where filling time settings can be made.
- 7) Opens the screen where shutdown settings can be made.
- 8) Opens the screen where PE / Servo motor settings can be made.
- 9) Opens the screen where Inverter settings can be made.
- 10) Opens the screen where washing can be done.
- 11) Opens the screen where manual control
- 12) Indicates the machine capacity.
- 13) Indicates daily production information. The production data can be reset by clicking on it.
- 14) Indicates total production information.



Alert Menu


From this menu, the alarms that occur on the machine can be monitored and reset. (Picture-4.4))



- 15)** Reset alarms.
- 16)** Alerts history displayed.
- 17)** Returns to the main menu
- 18)** Deletes reset alarms.

Filling Settings Menu

The filling parameters are set from this menu. (Pic.-4.5)



- 19) The value entered determines how many cc's are filled in a fill motion.
- 20) Indicates the remaining cc that must be pressed during the filling process
- 21) Information on how many refills are made can be seen from this screen.
- 22) Filling stop ramp value.
- 23) Filling Velocity
- 24) Filling start ramp value.
- 25) This feature divides the filling cylinder into 5 equal parts, allowing the product in each part to be adjusted for printing speed. "0" (Zero) must be written if it is not to be used.
- 26) Opens the setting menu to pull product to the filling cylinder
- 27) Returns to the main menu



Filling Time Setting Menu

Filling time settings are made from this menu.. (Pic.-4.6)



Pic-4.6


- 28) Returns to the main menu
- 29) The value entered determines how many seconds after the sensor in the input conveyor sees the bottle, the input full information will be reported to the PLC.
- 30) The entered value is the time the sensor in the input conveyor does not see the bottle. If it does not see the bottle until the second entered, it transmits the input blank information to the PLC.
- 31) If tightening does not occur within the entered millisecond value, the operation stops the rotation.
- 32) The value entered is the cover sight of the sensor located in the cover chamber the amount of time. If it sees the cover until the second entered, it transmits the information that the cover has arrived to the PLC.
- 33) The value entered is the length of time the sensor in the cover chamber does not see the cover. If it does not see the cover until the second entered, it transmits the input blank information to the PLC.
- 34) The value entered is the length of time the sensor in the cover channel chamber does not see the cover. If the cover does not see until the second entered, it transmits the vibrator start signal to the PLC.
- 35) The value entered is the cover Vision time of the sensor in the cap channel chamber. If it sees a cap within seconds of entering, it transmits a stop vibrator signal to the PLC.
- 36) The entered value is the duration of the sensor in the output conveyor not seeing the bottle. If it does not see the bottle until the second entered, it transmits the output blank information to the PLC.
- 37) The value entered determines how many seconds after the sensor in the output conveyor sees the bottle, the output full information will be reported to the PLC.
- 38) The value entered is the amount of time the sensor in the selector does not see the ball. If the ball is not seen by the seconds entered, the ball is finished information is passed to the PLC.



- 39) The value entered is the ball Vision time of the sensor in the selector. If the ball is seen by the second entered, the ball has arrived information is passed to Plc.
- 40) The value entered is the amount of time the sensor in the selector channel does not see the ball. If the ball is not seen by the second entered, the ball is dropped information is passed to the PLC.
- 41) The value entered is the inappropriate bottle Vision time of the sensor in the reject. Reject full information is transferred to Plc if it sees an inappropriate bottle until the second entered.
- 42) The value entered is the amount of time that the sensor in the reject does not see an appropriate bottle. Reject empty information is transferred to the PLC if it does not see the bottle as unsuitable as the seconds entered.

Capping Settings

Capping settings are set from this menu (Pic-4.7)




- 43) Returns to the main menu
- 44) Opens the menu where ramp settings can be made.
- 45) The value entered determines the parking position of the closure head
- 46) The value entered determines the cover distance of the closing head
- 47) The value entered determines the holding distance of the closing head
- 48) The value entered determines the tightening distance of the closing head
- 49) The value entered determines the grinder pitch of the closure head
- 50) Period Indicator
- 51) The cap tests the setting parameters by starting the tightening process.
- 52) The value entered determines the rotation speed of the shutdown cap head.
- 53) The value entered determines the torque limit of the closure head.
- 54) Torque indicator



PE Servo Settings

The PE servo settings are made from this menu (*pic-4.8*)




- 55) Returns to the main menu
- 56) Servo driver DC volt indicator
- 57) Servo driver temp. indicator
- 58) Servo motor temp indicator
- 59) Servo motor ACT torque indicator
- 60) The value entered is the acceleration (ramp) value of the PE motor. At the value entered, the servo motor takes off.
- 61) The value entered is the thaw (ramp) value of the PE motor. Servo motor stops at the entered value.
- 62) The value entered is the speed value of the PE motor.



Inverter Settings Menu

The Inverter settings are made from this menu (pic-4.9)




- 63) Returns to the main menu
- 64) The value entered determines the speed of the conveyor
- 65) The value entered determines the speed of the band.
- 66) The value entered determines the speed of the selector
- 67) Percentage value entered determines machine capacity
- 68) The value entered determines the diameter of the filling cylinder.



Manuel Yıkama Menüsü


Manual washing control is done from this menu. (**Pic-4.10**)



- 69) Return the Main Menu
- 70) Manuel modu open, close.
- 71) Manuel washing open/closed
- 72) Washing count display
- 73) Washing Cycle Setting
- 74) Washing start button

Manual Menu

Manual control is done from this menu. (Pic-4.11)




Pic-4.11

- 75)** Return the Main Menu
- 76)** Manuel modu open, close.
- 77)** Holding cap active.
- 78)** To spin PE servo motor
- 79)** Forceps open/close
- 80)** Ball Nailing head open/close
- 81)** Cap forward open/close
- 82)** Cap squeezing open/close
- 83)** The next manual menu opens.



Manual Menu 2

Manual control is done from this menu (*pic-4.12*)



- 84)** Return the main menu
- 85)** Manual mode open/close
- 86)** Cap holding activated
- 87)** To spin the PE servo motor.


4.3 Format Change

Attention!


Make sure there are no oil stains on the work area floor. There should be no foreign objects in the machine.

The star set for 60cc and 100cc bottles is provided alongside the machine. Contact ELEKTROMAG for Star team requirements.

Changement of Star Set.



Stop the machine, turn off the air and press the emergency stop button.

1) Changement of Star Set.


Remove the knobs of Part A-visually enclosed in a round - by turning. Remove the loose piece and lift it to a suitable location. Repeat the above process for Parts B, C, and D respectively.

Install the desired format parts D, C, B, and A by following the order. Make sure the D gear is in place.

2) Recipe Selection


Select the format-changed recipe from the screen (see Format-changed recipe). Chapter 4.x) Click the mechanical adjustment button (see mechanical adjustment button).Chapter 4.x) The display will display the required numeral and Ruler values for the setting. These values go in a sequence with the numbering system. See the group number pasted on the machine to see which group the typed value is for.

3) Filling Nozzle Height Adjustment



See the mm value defined by "3" in the "mechanical adjustment" window that you opened in the HMI in the previous step. Loosen the butterfly nut marked on the picture. Turn the filling nozzle group height adjustment flywheel by checking the numeral until it reaches the desired value. Tighten the butterfly nut.


4) The bottle came Photocell Setting



See the mm value defined by" 4 "in the" mechanical adjustment " window.

5 alyan ile şekilde gösterilen imbus civatayı gevşetin ve mil üzerindeki cetveli referans yüzeye göre reçete değerine getirip imbus civatayı sıkın.

5) Ball Nailing Head Setting




See the mm value defined by" 5 "in the" mechanical adjustment " window.

See the mm value defined by" 5 "in the" mechanical adjustment " window. Loosen the butterfly nut marked on the picture. Turn the head height adjustment flywheel until it reaches the desired value by checking the numeral. Tighten the butterfly nut.




6) Cap Tightening Head Adjustment



“See the mm value defined by” 6 “in the” mechanical adjustment “ window. Loosen the butterfly nut. Cover tightening head turn the height adjustment lever, controlling the numeral, until it reaches the desired value. Tighten the butterfly nut.

7) Cap Yes-No Sensor Height Adjustment



See the mm value defined by” 7 “in the” mechanical adjustment “ window. Loosen the butterfly nut. Cover yes-no turn the height adjustment flywheel until it reaches the desired value by checking the numeral. Tighten the butterfly nut.

8) Conveyor Barrier Settings

See the mm value defined by "8" in the "mechanical adjustment" window. Loosen the conveyor barriers knob. Slide the spindle in the holder to the desired value and tighten the knob. Repeat the process for other conveyor barrier holders.

4.4 Operator Placement

Attention!

It is recommended to have one operator during the working cycle.

4.5 Working Cycle

Attention!

The operator must ensure that there are no unauthorized persons in the work area. There should be no foreign objects on the machine.

Switch the main switch to "I" position. The button lights that indicate the presence of voltage on the machine will be on.

Deactivate the emergency button. Access the software within your jurisdiction.

Choose a prescription.

Make sure the machine is set according to the selected recipe. Press conveyor start button (conveyor becomes active)

Press the machine start button (the machine becomes active)

The bottles coming from the conveyor enter the system and start filling, ball ramming and cap screwing process respectively. The bottles take off from the outlet conveyor for the transition to the next machine.

4.6 Capless Product

Cap control sensor check the existing of capping in exit. If there is capless bottle, it will be rejected.

In 3 consecutive reject cases, the machine stops itself and alarms for operator intervention.

Check:

Cap feed channel Vibrator ve Selector capping head

Nailing Head

Star set

Cap yes or no sensor



4.7 Unexpected Electrical Fluctuations

In the event of an unexpected voltage surge, short circuit, or engine overheating, the power of the machine may be cut off.

3 phase voltage, phase order, phase loss role Possible over-voltage, low voltage, 3-phase systems and 3-or 4-wire systems during the phase error and Phase loss during the role system power cuts. Power is restored to the system when the voltage is restored and/or phase status is corrected Fuses There are a number of fuses inside the electrical board. Excessive voltage fluctuations can cause them to burn. In this case, turn off the machine by turning the main switch to the '0' position, then turn on the power panel. Using a tester, identify the burning fuse and replace it with another from the same amp.

Driver

There are drivers for the motors within the power board. These drivers control the engine overheating and failure conditions. In case of error or corruption, the driver will give an error. Fault detection can be done with the error code given by the driver. You can get error code information from Electromag or Omron.

4.8 Alerts

In the event of failure and unexpected situations in the machine, the machine will sound an alarm. These alarms can be seen in the alarms menu on the operator screen.

Alert	Status	Solution
Exit Full	Product accumulation in output conveyor	Drain the outlet.
Ball Selection Cap Reduced	Cap reduction status in selector	Feed the selective
Entry Empty	No bottles on the inlet conveyor	Feed the entry
Channel Cap Reduced	Channel cap reduction status	Feed the vibrator.
Cap Over	Cover evaluation status in channel	Feed the vibrator.
No Air	4-6 bar air condition in the machine	Check the air connections
Door open	The state of at least one of the doors being open	Close the doors.
Emergency Stop	Acil stop basılı	Deactivate the emergency stop button.
Eject Full	Reject unit is full	Empty Unit

4.9 Stopping the Machine

Press the emergency STOP button to stop all operations of the machine.



Maintenance

5

**Attention!**

Any outstanding maintenance on the machine is performed only by the manufacturer's technicians.

The manufacturer recommends an inspection service every two years to ensure Machine Safety.

*Note!*

The maintenance technician must register all maintenance performed on the machine in an appropriate registry.



5.1 Information Notes

This section contains a description of the basic controls and maintenance needed to ensure the proper operation of the machine. All other interventions necessary to eliminate errors or operating problems must be done by the manufacturer specifically. For important repairs, it is recommended that you consult Elektromag, whose expert staff is at your service at all times. ELEKTROMAG has the expertise of all technological components of the machine and can perform the necessary operations quickly.

5.2 General Safety Rules

Maintenance activities should be carried out for this machine-as indicated below - by specialist technicians trained in a specific discipline:

Mechanical maintenance

Maintenance of electrical systems

It is the duty of the Security Authority to ensure the professionalism and competence of the above mentioned persons.

Before starting maintenance activities, the security official should:

Ensure that the workspace is free of unnecessary materials and foreign personnel.

Ensure that the equipment required by the maintenance technician is at hand and in good condition.

Check that the lighting is adequate and provide a 24 Volt mobile lamp if necessary.

Ensure that the maintenance technician is equipped with the necessary, approved, personal protective equipment for a specific procedure (gloves, protective glasses, shoes, etc.)

Make sure that the maintenance technician reads the instructions in this manual carefully and knows the operation of the machine well.

Before starting maintenance activities, the maintenance technician should:

-Disconnect the electrical and pneumatic feeders from the machine and leave them in a safe state .



ATTENTION!

The main switch must be in the " O " position and must be locked with a padlock to avoid unintentionally reactivating it .The key to the padlock must remain with the maintenance team.



After completion of maintenance and before allowing the machine to return to service, the maintenance technician must check the entire working cycle, operation of the safety devices, and integrity of the protection devices.

**Attention!**

After each maintenance is complete, the security manager should check the safety status of the machine and the protection devices and confirm that they are operational.

During maintenance, it is recommended that a warning sign prohibiting the operation of the machine be hung on the control panel. Maximum reliability and minimum maintenance costs are the result of a planned maintenance and control program that is meticulously followed throughout the machine life.

During disassembly, mark each part relative to the others to ensure that the correct parts are assembled later. Always lubricate the interior and contact surfaces with the appropriate oil before mounting the unit. Replace all seals and orings with the original parts before mounting the components.

Always check the existence of grounding connections and compliance with regulations. Before starting the machine, ensure that the maintenance personnel are at a safe distance and there are no supplies or tools left with the machine.

5.3 Cleaning

Before starting the inspection and maintenance procedures, all dirt on the machine should be carefully cleaned with suction sponges and suitable solvents.

Clean all stubborn dirt traces with a soft, dry cloth that leaves no thread, or using a very flexible Hairy brush.



If dirt is difficult to remove using cloths or dry brushes, use a suitable non-flammable liquid solvent with a low level of toxicity. Purchase only solvents suitable for manual use. Check the recommendations given by the manufacturer. WD-40 chemical is recommended for surface cleaning of steel, Aisi 316 and Aisi 304. It is recommended to use dyo wax polish or thin pastry for aluminium surface cleaning. Glazing is recommended for plexic material cleaning. Cleaning with compressed air is recommended.

Attention!

Use cleaning solvents away from open flames and ensure good ventilation of the area. Avoid prolonged exposure of personnel to solvent fumes. Failure to comply with these rules may result in injury to staff. Do not use high pressure sprays for cleaning purposes. Do not use corrosive chemicals on aluminium surfaces for cleaning purposes.

5.4 Maintenance

Attention!

All operations described must be performed in the main switch "O" position and locked with a padlock to prevent involuntary reactivation. The key to the padlock must remain with the maintenance team. Before starting any maintenance or cleaning process, wear appropriate protective clothing such as safety glasses and / or gloves, depending on the work to be done.



Disconnect, lock, and secure all power supplies before starting any maintenance.

Put the following warning on the control panel:

MAINTENANCE IN PROGRESS DO NOT TURN ON THE POWER

Before starting operations again, check all procedures in accordance with the start procedures. After each maintenance operation, perform several manual test operations to check that the cycle is working correctly. Failure to comply with these rules can result in serious injury to staff.



Spare-Parts 6



Wear-exposed components (recommended spare parts)

Contact ELEKTROMAG for spare parts request.

Phone:

0(282) 726 13 14

E-mail :

W depo@elektromag.com.tr

6.1 Components subject to wear and mechanical stress

Attention!

Components exposed to wear due to their function should be checked at very short intervals and replaced as soon as they show significant signs of wear.

The manufacturer designed and manufactured the machine to last a reasonable amount of time, taking into account the normal working conditions of the customer. However, it is necessary to check all these components periodically very carefully.

If mechanical cracks, permanent or cyclic structural deterioration are encountered, contact the manufacturer and expert technicians who will take the necessary precautions immediately. Electrical cables lose their insulating properties over time, especially when exposed to heat, humidity and temperature. Check its functionality with technical experts.



ÜRÜN KODU	AÇIKLAMA	MİKTAR
5 MRED-VF30-P1-0,18KW/96	VF30-P1-15P63 B14 (0.18KW/96 dd.İ:15 MOT.REDÜKTÖR)	1 ADET
5 MRED-VF44-P1-0,37KW/70	VF44-P1-20P71-B14 (0.37KW/70 dd.İ:20 MOT.REDÜKT.)	1 ADET
5 PLBM-130-25	130-Z21-25 KONV.BANT MAKARASI (1205 7N)	1 ADET
5 MRD-LC090110STD95ACD19	LC090110STD95ACD19KE REDÜKTÖR 1/10 (BONFIGLIOLİ)	1 ADET
5 KZKA-T5-300	T5-15-300 KAUÇUK ZAMAN KAYIŞI	1 ADET
5 KZKA-5M-15-425	5M-15X425 KAUÇUK ZAMAN KAYIŞI	1 ADET
5 KZKA-8M-20-1120	8M-20-1120 TRİGEL KAYIŞ	1 ADET
5 RYKE-12-30-7	12-30-7 YAG KEÇESİ SUP-TEX	2 ADET
5 RYKE-30-47-10	30-47-10 YAG KEÇESİ SUP-TEX	1 ADET
5 MRED-VF30-P1-0,18KW/96	VF30-P1-15P63 B14 (0.18KW/96 dd.İ:15 MOT.REDÜKTÖR)	1 ADET
5 KBBK-55X2000	55X2000 BASKI BANT KAYIŞI (KD2LB1302-P9/A/BL) MAVİ	1 ADET
5 PNRE-SMC-3/8	AW30-F03DE-B 3/8 FİLTRE REGÜLAT.OTOM.TAHL.	1 ADET
5 PNRE-SMC-Y30T-A	Y30T-A 3/8 MOD.TESPİT ELEMANI SMC	2 ADET
5 PNYS-SMC-JMGPM-12-10	JMGPM-12-10 YATAKLI SİLİNDİR SMC	1 ADET
5 PNYS-SMC-MGPM-25-20	MGPM-25-20 YATAKLI SİLİNDİR	1 ADET
5 SICK-RZC1-04ZUS-KUBS03	RZC1-04ZUS-KUBS03 2-TELLİ 5mt.PİST.SENS.(1073286)	2 ADET
5 ETERM-KTS011	KTS011-0-60c TERMOSTAT (STEGO)01141.0-00	1 ADET
5 EHKO-3G3MX2-AB004E-ECT	0,4/0,55 KW. HIZ KONTROL (3G3MX2-AB004-E-ECT)	2 ADET
5 EGKA-S8VK-C24024	S8VK-C24024 (24V.DC 10A.240W.GÜÇ KAYNAĞI) OMRON	1 ADET
5 DELTA-NDR-480-48	NDR-480-48 (48VDC.10A.GÜÇ KAYNAĞI) MEAN WELL	1 ADET
5 TMK-A9K24110-10AX1	10AX1 W.OTOM.SİGORTA (A9K24110) TMK	2 ADET
5 TMK-A9K24106-6AX1	6AX1 W.OTOM.SİGORTA (A9K24106) TMK	1 ADET
5 TMK-24351	24351- 20AX3 OTOM.SİGORTA (A9K24320)	1 ADET
5 TMK-24351	24351- 20AX3 OTOM.SİGORTA (A9K24320)	1 ADET
5 ERÖ-K8AK-PM2	K8AK-PM2 KONTROL RÖLESİ (OMRON)	1 ADET
5 EM-KONT-DILEM-10-220V	DILEM-10 (4 KW.220V.AC KONTAKTÖR (MOELLER)	1 ADET
5 ERÖ-CMS-E-ER-099182	CMS-E-ER 099182 DEGERL.ÜNİTESİ (EMNİY.RÖLESİ)	1 ADET
5 ESEN-E2B-S08KN04-MC-B1	E2B-S08KN04-MC-B1 OMS (M8 KISA SENSÖR 4mm) PNP	4 ADET
5 ESEN-E2B-S08LN04-MC-B1	E2B-S08LN04-MC-B1 OMS (M8 UZUN SENSÖR 4mm) PNP	1 ADET
5 EFOT-OGU-081-G3-T3	OGU-081-G3-T3 ÇATAL FOTOSEL (201245 Dİ-SORİC)	2 ADET
5 EFOT-OGU-121-G3-T3	OGU 121 G3-T3 ÇATAL FOTOSEL (Dİ-SORİC-210246)	1 ADET
5 EFOT-OGU-121-G3-T3	OGU 121 G3-T3 ÇATAL FOTOSEL (Dİ-SORİC-210246)	1 ADET
5 SICK-WLG4S-3F2234	WLG4S-3F2234 REF.ŞEFFAF ŞİŞE FOTOSELİ SICK-1042084	3 ADET
5 BECK-CP6706-0001-0050	CP6706-0001-0050 (PANEL) 7- inch BECKHOFF	1 ADET
5 BECK-AX5106-0000-0200	AX5106-0000-0200 ETHERCAT SÜRÜCÜ 6A V2	1 ADET
5 BECK-AX5206-0000-0200	AX5206-0000-0200 ETHERCAT SÜRÜCÜ 2X6A V2	1 ADET
5 BECK-AM8033-OF10	AM8033-OF10 SERVO MOTOR - 400V.AC BECKHOFF	1 ADET
5 BECK-AM8042-OF11	AM8042-OF11 FRENLİ SERVO MOTOR BECKHOFF	1 ADET
5 BECK-AM8043-OE10	AM8043-OE10-0000 (SERVO MOTOR) 400V.AC	1 ADET
5 BECK-AM8131-IF20	AM8131-1F20 SERVO MOTOR	1 ADET



Notes







