




1. Hydraulic Power connection: This view is from the back side of the crane control valve bank.




2. Tank connection: Connect the tank to this connection



3. Pump connection: Connect the pump to this connection.




4. Load Sensing (LS) connection: Connect the pump's LS connection this plug.



5. Electrical Power (cable 1):

- i. Connect the brown and green wires to +10VDC to +30VDC.
- ii. Connect the white wire to Minus.



6. Start up the system and controlling the crane by remote control:

- i. Release the red emergency stop button on the remote control.
- ii. Push the black start button once and wait until the remote control is turned on.
- iii. Push the green button once.
- iv. It is now possible to control the crane via the remote control levers, see page 12.



7. Remote control – Info Center (i) Start up screen:

- i. Time to service
- ii. Crane load



8. Remote control – Info Center (ii) After start up:

- i. Screen 1
- ii. Battery level
- iii. Crane load



9. Remote control – Info Center (iii) Changing the displayed icons in the remote control Info Center:

- i. Activate switch 10, ie. move it to the right position.
- ii. Push the yellow button.
- iii. The information in the Info Center is now changed for each click on the yellow button.



10. Remote control – Info Center (iv) Other information from the Info Center:

- i. Screen 2
- ii. The turtle & the text '100%' indicates that full speed is possible on the crane functions.
- iii. The hand icon indicates whether a crane stop situation is being executed and the remaining stop time in seconds.




11. Remote control – Info Center (v) Other information from the Info Center:

- i. Screen 2: The turtle indicates '0%', meaning that the crane is in low speed (ie. HDL – Heavy Duty Lifting) mode. This mode is active if the 'FUNC' diode is blinking and:
 - a. - the crane load exceeds 80% of the lifting capacity, or
 - b. - the red button is pushed once



12. Crane functions – hand paddles for remote control:

SLEW**BOOM****JIB****EXTENSION****1. EX.VALVE (Fly Jib)****2. EX. VALVE (FJ extension)**

13. Start up the system and controlling the crane manually (directly on the crane control valve)

- i. Keep the transmitter turned off.
- ii. Push the green button on the RCL5300 front once. The RCL5300 display shows 180, ie. no radio contact.
- iii. Keep the yellow button pressed, while the red button is pressed once. The display must show 186, ie. manual operation mode is selected.
- iv. The crane can now be operated manually, see next page.
- v. **Before the crane can be operated by the remote control again:** Turn on the remote control. Keep the yellow button on the RCL5300 pressed, while the red button is pressed once. The RCL5300 display must show a running line and dot. The crane is now ready for remote control.



14. Crane functions – hand levers for manual control:

SLEW


BOOM

JIB

EXTENSION

1. EX.VALVE (Fly Jib)

2. EX. VALVE (FJ extension)



Valve section for full flow dump