

# AVR128: Setup and Use the Analog Comparator



## Introduction

This application note serves as an example on how to set up and use the AVR's On-chip Analog Comparator. The following program examples are given in the assembly file "avr200.asm":

- Detect a positive edge on the comparator output by polling the ACO-bit in the Analog Comparator Control and Status Register – ACSR.
- Detect a positive edge on the comparator output by polling the Analog Comparator Interrupt Flag – ACI in ACSR.
- Initialize interrupt on comparator output toggle. An interrupt routine which increments a 16-bit counter each time it is executed is given as an example.

8-bit **AVR<sup>®</sup>**  
**Microcontroller**


## Application Note

### Detecting a Positive Edge by Polling ACO

This part of the code shows the trivial way of detecting a positive edge on the comparator output. Even though it uses only four words of code and no initial setup, this approach to the task might cause problems. If a short pulse on the output occurs while the program is administrating the wait loop, the pulse could be missed as ACO is directly connected to the comparator output. If the user wants to insert code within the wait loop, the probability of detecting a short pulse will increase. Such code might be time-out if no edge occurs within a specific period. The procedure for detection is as follows:

1. If output is high, wait for output to go low.
2. Wait until output goes high.

**Figure 1.** ACO Polling Flow Chart



Rev. 0934B-AVR-05/02



**Table 1.** ACO Polling Performance Figures

Parameter	Value
Code Size (Words)	4
Response Time (Cycles)	3 - 5
Initialization Time (Cycles)	0
Register Usage	Low Registers :None High Registers :None Pointers :None
Interrupts Usage	None
Peripherals Usage	Analog Comparator

## Detecting a Positive Edge by Polling ACI

This part of the code shows a far more secure and flexible way of detecting a positive edge on the comparator output. Even though the Analog Comparator Interrupt is disabled, the interrupt flag will still be set when events on the comparator output matches the settings of the ACIS1/ACIS0 bits in ACSR. E.g., a positive edge will always set the ACI bit in ACSR if ACIS1/ACIS0 both are one (refer to the databook for details). The ACI flag will reflect whether the event to look for has occurred since the last ACI Reset. In this application note, positive edge detection by polling ACI is implemented according to the following procedure:


### Setup

1. Set ACIS0 and ACIS1 = 1.

### Polling

1. Clear the ACI bit by writing an logical "1" to it.
2. Wait until ACI goes high.

**Figure 2.** ACI Polling Flow Chart



**Table 2.** ACI Polling Performance Figures

Parameter	Value
Code Size (Words)	5
Initialization Time (Cycles)	2
Response Time (Cycles)	3 - 5
Register Usage	Low Registers :None High Registers :None Pointers :None
Interrupts Usage	None
Peripherals Usage	Analog Comparator

## Using the Analog Comparator Interrupt

The application note program shows an example on how to enable the comparator interrupt. In the example, interrupt on comparator toggle is shown. The following procedure is followed:

1. Clear interrupt flag and ACIS1/ACIS0. The interrupt flag must be cleared first. If not, and the flag for some reason already is set, the MCU will start executing the interrupt routine immediately when the interrupts is enabled. Clearing ACIS1/ACIS0 selects interrupt on toggle.
2. Enable Global Interrupts.
3. Enable the Analog Comparator Interrupt by setting the ACIE bit in ACSR.

Note that since the ACSR Register is one of the lower 32 I/O, registers, the “SBI” instruction can be used to set, clear and test bits.

**Table 3.** Analog Comparator Interrupt Enable Performance Figures

Parameter	Value
Code Size (Words)	4
Execution time (Cycles)	5
Register Usage	Low Registers :None High Registers :1 Pointers :None
Interrupts Usage	None
Peripherals Usage	Analog Comparator



## Atmel Headquarters

### *Corporate Headquarters*

2325 Orchard Parkway  
San Jose, CA 95131  
TEL 1(408) 441-0311  
FAX 1(408) 487-2600

### *Europe*

Atmel SarL  
Route des Arsenaux 41  
Casa Postale 80  
CH-1705 Fribourg  
Switzerland  
TEL (41) 26-426-5555  
FAX (41) 26-426-5500

### *Asia*

Atmel Asia, Ltd.  
Room 1219  
Chinachem Golden Plaza  
77 Mody Road Tsimhatsui  
East Kowloon  
Hong Kong  
TEL (852) 2721-9778  
FAX (852) 2722-1369

### *Japan*

Atmel Japan K.K.  
9F, Tonetsu Shinkawa Bldg.  
1-24-8 Shinkawa  
Chuo-ku, Tokyo 104-0033  
Japan  
TEL (81) 3-3523-3551  
FAX (81) 3-3523-7581

## Atmel Operations

### *Memory*

Atmel Corporate  
2325 Orchard Parkway  
San Jose, CA 95131  
TEL 1(408) 436-4270  
FAX 1(408) 436-4314

### *Microcontrollers*

Atmel Corporate  
2325 Orchard Parkway  
San Jose, CA 95131  
TEL 1(408) 436-4270  
FAX 1(408) 436-4314

Atmel Nantes  
La Chantreterie  
BP 70602  
44306 Nantes Cedex 3, France  
TEL (33) 2-40-18-18-18  
FAX (33) 2-40-18-19-60

### *ASIC/ASSP/Smart Cards*

Atmel Rousset  
Zone Industrielle  
13106 Rousset Cedex, France  
TEL (33) 4-42-53-60-00  
FAX (33) 4-42-53-60-01

Atmel Colorado Springs  
1150 East Cheyenne Mtn. Blvd.  
Colorado Springs, CO 80906  
TEL 1(719) 576-3300  
FAX 1(719) 540-1759

Atmel Smart Card ICs  
Scottish Enterprise Technology Park  
Maxwell Building  
East Kilbride G75 0QR, Scotland  
TEL (44) 1355-803-000  
FAX (44) 1355-242-743

### *RF/Automotive*

Atmel Heilbronn  
Theresienstrasse 2  
Postfach 3535  
74025 Heilbronn, Germany  
TEL (49) 71-31-67-0  
FAX (49) 71-31-67-2340

Atmel Colorado Springs  
1150 East Cheyenne Mtn. Blvd.  
Colorado Springs, CO 80906  
TEL 1(719) 576-3300  
FAX 1(719) 540-1759

### *Biometrics/Imaging/Hi-Rel MPU/ High Speed Converters/RF Datacom*

Atmel Grenoble  
Avenue de Rochepleine  
BP 123  
38521 Saint-Egreve Cedex, France  
TEL (33) 4-76-58-30-00  
FAX (33) 4-76-58-34-80

---

### *e-mail*

literature@atmel.com

### *Web Site*

<http://www.atmel.com>

### © Atmel Corporation 2002.

Atmel Corporation makes no warranty for the use of its products, other than those expressly contained in the Company's standard warranty which is detailed in Atmel's Terms and Conditions located on the Company's web site. The Company assumes no responsibility for any errors which may appear in this document, reserves the right to change devices or specifications detailed herein at any time without notice, and does not make any commitment to update the information contained herein. No licenses to patents or other intellectual property of Atmel are granted by the Company in connection with the sale of Atmel products, expressly or by implication. Atmel's products are not authorized for use as critical components in life support devices or systems.

ATMEL® and AVR® are the registered trademarks of Atmel.

Other terms and product names may be the trademarks of others.



Printed on recycled paper.