






MAINTENANCE INSTRUCTION

Desc: Procedure





Rev.: A 5-9-11

Step #	Description of work steps (What)	Key points (How)	Reason (Why)
Maintenance Procedure			
1	<p><u>Cycle Power:</u></p> <p>Power the machine down all the way than back on.</p>	<p>Turn power off on the controller then turn power off to the machine.</p>  <p>ON</p> <p>OFF</p>  <p>Reverse this process to turn the machine back on.</p>	To reset the machine.
2	<p><u>Input Bypass:</u></p> <p>1-)Select the Parameters Soft Key</p>		To allow I/O Write access
	<p>2-) Right Arrow Soft Key.</p>		To allow you to input commands into the controller.
	<p>3-) Type 1131 then select Input.</p>		Allows I/O Write access.

MAINTENANCE INSTRUCTION

Desc: Procedure



Rev.: A 5-9-11

Step #	Description of work steps (What)	Key points (How)	Reason (Why)
Maintenance Procedure			
3	<u>I/O Write:</u> 1-) Select Diagnos 2-) Select PLC Signal		
	3-) Select Version 4-) Select Diagnos Monitor		
	5-) Select I/O Write Type M6810-1 Then Input		To Override all alarms and Manually adjust Pallet Changer
4	<u>Pallet Unclamp:</u> 1-) Select Machine Button 2-) Pallet Maintenance		

MAINTENANCE INSTRUCTION

Desc: Procedure




Rev.: A 5-9-11

Step #	Description of work steps (What)	Key points (How)	Reason (Why)
Maintenance Procedure			
	3-) Hold MF1 and press Select signal ready. 4-) Select Pallet Unclamp		Unclamping the pallet will allow the MJR-2 Controller to move the pallet changer.
5	<u>Open MRJ-2 Program:</u> 1-) Open MR-J2 Program by using the cursor. 2-) Select Set-Up Axis drop down 3-) Select 2 Pallet Changer(2)		

MAINTENANCE INSTRUCTION

Desc: Procedure

Rev.: A 5-9-11

Step #	Description of work steps (What)	Key points (How)	Reason (Why)
Maintenance Procedure			
	3-) Select Test Operation 4-) Select OK on the pop-up window 5-) Select STEP in Operation Mode 6-) Select the appropriate Step Mode Feed		
	<u>Moving Pallet:</u> 7-) Click on the "Normal Rot" button until the Position reads: 180° for Pallet #2 0°/360° for Pallet #1 NOTE: Adjust Step Mode Appropriately to seed this process up. 8-) Select "Stop" Button once the display reads 180° / 0° 9-) Select "End" then exit the MRJ-2 Program.		
7	<u>Clamp Pallet:</u> 1-) Select the Pallet Clamp 2-) Repeat Step #1 (Cycle Power) 3-) Restart machine cycle		Clear out all Overrides