

---

# **Freescale MQX ETHERNET BOOTLOADER User's Guide**

Document Number:  
MQXBLDUG Rev.1.3  
07/2011

<b>Chapter 1 Before You Begin.....</b>	<b>5</b>
1.1 About This Book.....	5
1.2 Where to Look for More Information .....	5
1.3 Product Names .....	5
1.4 Typographic Conventions.....	5
<b>Chapter 2 Using Ethernet Boot Loader.....</b>	<b>1</b>
2.1 Ethernet Boot Loader at a glance .....	1
2.2 Ethernet boot loader flow .....	1
2.3 Boot loader Memory Maps.....	2
2.3.1 TWR-MPC5125 Memory Map .....	3
2.3.2 TWR-MCF54418 Memory Map .....	3
2.3.3 M5329EVB Memory Map .....	3
2.3.4 M53015EVB Memory Map .....	4
2.3.5 M54455EVB Memory Map .....	4
<b>Chapter 3 Reference: Functions .....</b>	<b>5</b>
3.1 _bootloader_init_table .....	5
3.2 _bootloader_check_image .....	5
3.3 _bootloader_del_image .....	5
3.4 _bootloader_del_table .....	5
3.5 _bootloader_store_image_data .....	6
3.6 _bootloader_list_image .....	6
3.7 _bootloader_set_default .....	6
3.8 _bootloader_get_timeout.....	6
3.9 _bootloader_set_timeout .....	7
<b>Chapter 4 Reference: Commands.....</b>	<b>8</b>
4.1 ipconfig.....	8
4.2 imgload .....	8
4.3 imglst .....	8
4.4 imgdel.....	8
4.5 tbldel.....	8
4.6 autoboot .....	8
4.7 imggo.....	9
4.8 imgtimeout.....	9
4.9 imgren.....	9
4.10 imgaddr.....	9
4.11 nandcheck .....	9
4.12 nandef .....	9
4.13 Reset .....	9
<b>Chapter 5 MQX Bootloader Examples.....</b>	<b>10</b>
5.1 Introduction.....	10
5.2 Preparing the setup .....	10
5.2.1 Software Setting up.....	10
5.2.2 Hardware Setting up .....	10
5.3 Preparing image file .....	11
5.3.1 Preparing image file for TWR-MPC5125.....	11
5.3.2 Preparing image file for TWR-MCF54418.....	14

---

5.4	Running Boot loader .....	16
-----	---------------------------	----

## Revision History

To provide the most up-to-date information, the revision of our documents on the World Wide Web will be the most current. Your printed copy may be an earlier revision. To verify you have the latest information available, refer to <http://www.freescale.com/mqx>.

The following revision history table summarizes changes contained in this document.

Revision Number	Revision Date	Description of Changes
Rev. 1.0	01/2011	Draft coming with MQX 3.6
Rev. 1.1	04/2011	Prototype coming with MQX 3.7.0 official release
Rev. 1.2	06/2011	Update Bootloader commands and Bootloader example
Rev. 1.3	07/2011	Update Bootloader for Nor flash devices

Freescall<sup>TM</sup> and the Freescale logo are trademarks of Freescale Semiconductor, Inc.

© Freescale Semiconductor, Inc., 2010. All rights reserved.

# Chapter 1 Before You Begin

## 1.1 About This Book

This book is a guide and reference manual for using the FSLMQX NAND Bootloader, which is a part of Freescale MQX Real-Time Operating System distribution.

## 1.2 Where to Look for More Information

- The release notes document accompanying the Freescale MQX release provides information that was not available at the time this user's guide was published.
- The *MQX User's Guide* describes how to create embedded applications that use the MQX RTOS.
- The *MQX Reference Manual* describes prototypes for the MQX API.

## 1.3 Product Names

In this book, we use BLD as the abbreviation for the Freescale MQX Bootloader Embedded File System.

## 1.4 Typographic Conventions

Throughout this book, we use typographic conventions to distinguish terms.

Font style	Usage	Example
<b>Bold</b>	Function families	The <b>_io_mfs</b> family of functions.
<b>Bold</b>	Function names	<b>_io_mfs_install()</b>
<i>Italic</i>	Data types (simple)	<i>uint_32</i>
	Data types (complex)	See following example.
Constant-width	Code and code fragments	—
	Data types in prototype definitions	See following example.
	Directives	#include "mfs.h"
	Code and code fragments	
<i>Italic</i>	Filenames and path names	<i>part_mgr.h</i>
<i>Italic</i>	Symbolic parameters that you substitute with your values.	See following example.
UPPERCASE Italic	Symbolic constants	<i>MFS_NO_ERROR</i>

## 1.5 Other Conventions

## 1.5.1 Cautions

Cautions tell you about commands or procedures that could have unexpected or undesirable side effects or could be dangerous to your files or your hardware.

<b>CAUTION</b>	If an application calls read and write functions with the partition manager, the file system will be corrupted.
----------------	---

## Chapter 2 Using Ethernet Boot Loader

### 2.1 Ethernet Boot Loader at a glance

Ethernet Boot Loader provides an easy and reliable way to load new user applications to the device that available Nand or Nor flash memory. After loaded, the new user applications will be able to run in the device. However, Ethernet boot loader support user to load more than one application to flash memory and specify booting image. The Ethernet boot loader needs an TFTP server running on PC.

This Ethernet boot loader was specifically written for several families of Freescale microcontrollers that have MQX RTOS support NAND or NOR flash driver and enough memory to store more than one applications.

Tested development boards:

- TWR-MPC5125 with NAND flash support
- TWR-MCF54418 with NAND flash support
- M5329EVB with NOR flash support
- M53015EVB with NOR flash support
- M54455EVB with NOR flash support

Tested operating systems:

- Windows XP Pro with Service Pack 2

Tested development tool:

- Code Warrior 10.1
- Code Warrior 9.2
- Code Warrior 7.2


This document intends to help you gain an insight into the Ethernet boot loader and capabilities to develop your own applications. The document targets to firmware application developers who would like to develop the applications using Ethernet boot loader.

### 2.2 Ethernet boot loader flow

The Boot loader is integrated with an application that performs the product's main functions. At beginning, the boot loader executes and does some simple checks to see which the application should start after a timeout value. The Boot loader should go to main application where user can setup own network and get image from server in first time. The Boot loader supports firmware image in S-record, Code warrior binary and raw binary file formats.

- S-record files are common ASCII files used to specify the program data stored in devices. Freescale's software tool chain called Code warrior generates S-record files and Code warrior binary files automatically when projects are compiled. S-record files have the extension .S19 and Code warrior binary files have the extension .bin.
- Raw binary file is the image file of flash memory.

After the image file has been transferred, the Boot loader will store in a specific area.



**Figure 2-1 Boot loader functional follow chart**

When entering to auto boot mode, the Boot loader will parse image file to Ram memory and execute booting from Ram.

## 2.3 Boot loader Memory Maps

The following sections show the memory maps for the different device examples. The memory map for both the boot loader and application are show to see how the RAM overlaps. Notice the application has access to all RAM and overlaps the bootloader RAM. All other memory sections are identical between the two.



### 2.3.1 TWR-MPC5125 Memory Map

**Table 2-1 TWR-MPC5125 Boot loader and application memory map**

Addresses	Boot loader	Application
0x0001_0000 to 0x0040_0000	Reserved	- Interrupt and exception vectors - Code and Const data
0x0040_0000 to 0x0081_0000	Reserved	RAM available for application
0x0081_0000 to 0x0100_0000	- Interrupt and exception vectors - Code and Const data	Reserved
0x0100_0000 to 0x0200_0000	RAM available for application	Reserved

### 2.3.2 TWR-MCF54418 Memory Map

**Table 2-2 TWR-MCF54418 Boot loader and application memory map**

Addresses	Boot loader	Application (Ram target only)
0x4000_0000 to 0x4000_0600	Vector table, due to the uboot the start address shifted by 0x100000	Reserved
0x4000_0600 to 0x4010_0000	Code + Const data (cached)	Reserved
0x4010_0000 to 0x4010_0600	Reserved	Vector table, due to the uboot the start address shifted by 0x100000
0x4010_0600 to 0x4300_0000	Reserved	Code + Const data (cached)
0x4300_0000 to 0x4400_0000	RW data cached	Reserved
0x4400_0000 to 0x4500_0000	Reserved	RW data cached
0x4500_0000 to 0x4600_0000	RW data uncached	Reserved
0x4600_0000 to 0x4800_0000	Reserved	RW data uncached

### 2.3.3 M5329EVB Memory Map

**Table 2-3 M5329EVB Boot loader and application memory map**

Addresses	Boot loader	Application (Ram target only)
0x4000_0000 to 0x4000_0600	Reserved	Vector table
0x4000_0600 to 0x4100_00000	Reserved	Code + Const data (cached)
0x4100_0000 to 0x4190_0000	Reserved	RW data cached
0x4190_0000 to 0x4190_0600	Vector table	Reserved

0x4190_0600 to 0x41A0_0000	Code + Const data (cached)	Reserved
0x41A0_0000 to 0x41B0_0000	RW data cached	Reserved
0x41B0_0000 to 0x41B0_0000	RW data uncached	Reserved
0x41f0_0000 to 0x4200_0000	Reserved	RW data uncached

### 2.3.4 M53015EVB Memory Map

**Table 2-4 M53015EVB Boot loader and application memory map**

Addresses	Boot loader	Application (Ram target only)
0x4000_0000 to 0x4000_0600	Reserved	Vector table
0x4000_0600 to 0x4200_00000	Reserved	Code + Const data (cached)
0x4200_0000 to 0x4200_0600	Vector table	Reserved
0x4200_0600 to 0x4280_0000	Code + Const data (cached)	Reserved
0x4280_0000 to 0x4300_0000	RW data cached	Reserved
0x4200_0000 to 0x43F0_0000	Reserved	RW data cached
0x43F0_0000 to 0x4400_0000	RW data uncached	Reserved
0x41F0_0000 to 0x4200_0000	Reserved	RW data uncached

### 2.3.5 M54455EVB Memory Map

**Table 2-5 M54455EVB Boot loader and application memory map**

Addresses	Boot loader	Application (Ram target only)
0x4000_0000 to 0x4000_0600	Reserved	Vector table
0x4000_0600 to 0x4100_00000	Reserved	Code + Const data (cached)
0x4100_0000 to 0x4100_0600	Vector table	Reserved
0x4100_0600 to 0x4110_0000	Code + Const data (cached)	Reserved
0x4110_0000 to 0x4120_0000	RW data cached	Reserved
0x4120_0000 to 0x4130_0000	RW data uncached	Reserved
0x4800_0000 to 0x4C00_0000	Reserved	RW data cached
0x4C00_0000 to 0x5000_0000	Reserved	RW data uncached

## Chapter 3      Reference:      Functions

### 3.1    `_bootloader_init_table`

Initialize image table

#### Synopsis

```
int_32 _bootloader_init_table(void)
```

#### Description

- Initialize image table. Create a blank table if does not exists.
- Calculate check sum all image. Image stored in NAND Flash may be deleted by another application, therefore it should calculate checksum before using.

#### Return Codes

*MQX\_OK*            – No error occurs

*IO\_ERROR*        – IO error occurs

### 3.2    `_bootloader_check_image`

#### Synopsis

```
boolean _bootloader_check_image  
(     boolean autoboot,  
      uint_32 index)
```

#### Description

Checking autoboot image

#### Return Codes

*TRUE*            - If image index is set to autoboot image

*FALSE*          - If image index not set to autoboot image

### 3.3    `_bootloader_del_image`

#### Synopsis

```
uint_32 _bootloader_del_image(uint_32 index)
```

#### Description

Delete image with index specified

#### Return Codes

*MQX\_OK*            – No error occurs

*IO\_ERROR*        – IO error occurs

### 3.4    `_bootloader_del_table`

#### Synopsis

```
int_32 _bootloader_del_table(void)
```

#### Description

Delete all images

#### Return Codes

*MQX\_OK*            – No error occurs

*IO\_ERROR*        – IO error occurs

### 3.5 `_bootloader_store_image_data`

#### Synopsis

```
int_32 _bootloader_store_image_data
(
    uint_32  addr,
    uint_32  size,
    uchar_ptr buff,
    uchar_ptr name
)
```

#### Description

Store image in NAND Flash. Bootloader find images was masked delete, overwrite this one if new image size equal or smaller than old image. Otherwise store new image in the end of table.

*Addr* - [IN] Start address refer  
*Size* - [IN] Image size  
*Buff* - [IN] Pointer to image data  
*Name* - [IN] Name of image will be store in table.

#### Return Codes

*MQX\_OK* - No error occurs  
*IO\_ERROR* - IO error occurs

### 3.6 `_bootloader_list_image`

#### Synopsis

```
void _bootloader_list_image(void)
```

#### Description

Print out all images stored in NAND Flash

#### Return Codes

NA

### 3.7 `_bootloader_set_default`

#### Synopsis

```
int_32 _bootloader_set_default(uint_32 index)
```

#### Description

Set image as autoboot image after bootloader startup with timeout value.

#### Return Codes

*MQX\_OK* - No error occurs  
*IO\_ERROR* - IO error occurs

### 3.8 `_bootloader_get_timeout`

#### Synopsis

```
int_32 _bootloader_get_timeout(void)
```

## **Description**

Get timeout value of autoboot image

## **Return Codes**

-1 – No image found or no timeout value found.

# **3.9    \_bootloader\_set\_timeout**

## **Synopsis**

```
int_32 _bootloader_set_timeout(uint_32 index, uint_32
timeout)
```

## **Description**

Set image timeout value

## **Return Codes**

*MQX\_OK*       – No error occurs  
*IO\_ERROR*     – IO error occurs

## Chapter 4 Reference: Commands

### 4.1 ipconfig

This command used to setup Ethernet network. Flow the command instruction to set you board IP address.

### 4.2 imgload

This command used to load a file type .bin or .s19 from TFTP server and store to NAND flash immediately.

This image is set as auto boot when transfer success.

#### Usage

```
imgload <host> <source> <addr> [<name>]
```

<host> - TFTP server ip address

<source> - Source file name

<add> - Start address in Ram

[<name>] - Name of image will be stored in table (optional). Default source file name is stored in table.

#### Examples

```
imgload 10.207.215.40 hello.s19 0x400048f8 helloworld
```

### 4.3 imglst

This command has no argument. This command used to list all images in NAND flash.

#### Usage

This command doesn't have argument

### 4.4 imgdel

This command used to delete a image in memory of NAND flash.

#### Usage

```
imgdel <index>
```

<index> - Index of image to delete

### 4.5 tbldel

This command used to delete all images in memory NAND flash.

#### Usage

This command doesn't have argument

### 4.6 autoboot

This command used to select image auto boot when reset or power on.

#### Usage

```
autoboot [<index>]
```

<index> - Image index to boot.

## 4.7 imggo

This command jumps to image and runs application of this image.

### Usage

```
imggo <index>  
    <index> - Image index in memory table.
```

## 4.8 imgtimeout

This command sets autoboot timeout expire in second.

### Usage

```
atbtmo <index> <timeout>  
    <index> - Image index to set timeout  
    <timeout> - Time out in second value.
```

## 4.9 imgren

This command used to rename the image in table.

### Usage

```
imgren <index> <name>  
    <index> - Image index to be renamed.  
    <name> - New image name.
```

## 4.10 imgaddr

This command used to set the boot address of image.

### Usage

```
imgren <index> <address>  
    <index> - Image index to set boot address.  
    <name> - New image boot address.
```

## 4.11 nandcheck

This command used to check bad blocks of Nand flash

### Usage

```
nandcheck
```

## 4.12 nandef

This command is used to force erase specific block of Nand flash

### Usage

```
nandef <block>  
    <block> - Block force erased.
```

## 4.13 Reset

This command is used to soft reset the board.

### Usage

```
reset
```

## **Chapter 5      MQX Bootloader Examples**

### **5.1      Introduction**

This chapter gives you insight on how to use the Boot Loader example. The example use TWR-MPC5125 board and Code Warrior version 9.2 and TWR-MCF54418 board and CodeWarrior version 10.1. The following sections described in this chapter:

- Preparing the setup
- Preparing image file (CodeWarrior 9.2 and CodeWarrior 10.1)
- Running the application

### **5.2      Preparing the setup**

#### **5.2.1    Software Setting up**


This demo uses the following software:

- Code Warrior version 9.2
- Code Warrior version 10.1
- Hyper terminal on Windows XP
- NetBurner TFTP Server Version 1.0

#### **5.2.2    Hardware Setting up**

Make connection as shown in this following picture





**Figure 5-1 Hardware Setting up**

This demo uses the following hardware:

- A personal computer
- A TWR-MPC5125 board and power supply for it

Follow these steps to setup the hardware

1. Connect the power supply to the board.
2. Connect the USB TAP to the COP jumper of the board TWR-MPC5125.
3. Connect to virtual com J19 of TWR-MPC5125 board.
4. Turn board power on.

## 5.3 Preparing image file

This section describes steps to create a MQX image, which will be loaded and executed in RAM by Boot loader.


### 5.3.1 Preparing image file for TWR-MPC5125

**Step1.** Build libraries of MQX by running

```
[MQX_PATH]\config\twrmpc5125\cwmpc92\build_twrmpc5125_libs.mcp
```


**Step2.** Compile an application that will be run by Boot loader. For examples, we chose “Hello World”

[MQX\_PATH] \mqx\examples\hello\cwmpc92\hello\_twrmpc5125.mcp  
There should be chose Ram target for compiling because boot loader will copy image for Flash memory to Ram memory and execute program.



**Figure 5-2 Select Ram Target**

**Step3.** Configured the target settings




**Figure 5-3 Setting Rom and Ram address**

Chose Binary File is One and set the start address in Generate ROM Image check box.  
 RAM Buffer Address is Ram address in Linker file.  
 ROM Image Address is Rom address in Linker file.

```
rom:          org = 0x00010000, len = 0x003EFF00
ram:          org = 0x00400000, len = 0x01c00000
kernel_data: org = 0x02000000, len = 0x06000000
```

**Step4.** Compile the project and then *extram\_d.bin* is generated.



**Figure 5-4 Generated file**

**Step5.** Copy *extram\_d.bin* to the TFTP root folder. For example

*D:\projects\tftp\_root\twrmc5125*

Rename *extram\_d.bin* to *helloworld\_extram\_d.bin*

Remember that Start address is Rom address. In this examples Start address = 0x00010000.

### 5.3.2 Preparing image file for TWR-MCF54418

**Step1.** Build libraries of MQX by running

```
[MQX_PATH] \mqx\build\cw10\bsp_twrpcf54418
```


```
[MQX_PATH] \mqx\build\cw10\psp_twrpcf54418
```

**Step2.** Compile an application that will be run by Boot loader. For examples, we chose “Hello World”

```
[MQX_PATH] \mqx\examples\hello\cw10\hello_twrpcf54418
```


There should be chose Ram target for compiling because boot loader will copy image for Flash memory to Ram memory and execute program.

**Step3.** Configured the target settings



**Figure 5-5 Target settings**

**Step4.** Compile project



**Figure 5-6 Generated files**

**Step5.** Determine start address – Entry point in CodeWarrior setting.

Open `extram_d.elf.xMAP` by a text editor and find **boot** address. The format will be same with following line:

```
4010A60A 00000058 .text __boot(bsp_twrnmc54418_d.a boot_c.o )
```

0x4010A60A is start address, remember that will be a argument of *imgload* command

**Step6.** Copy `extram_d.elf.s19` to the TFTP root folder. For example


`D:\projects\tftp_root\twrnmc54418`

Rename `extram_d.elf.s19` to `helloworld_extram_d.s19`

## 5.4 Running Boot loader


This section describes step by step running Boot loader application with assumption your PC had installed Net Burner TFTP server or other kind of TFTP server.

**Step1.** Setting up “Search Directories” to the folder of image file, refer to section 5.3.1 Step 5.



**Figure 5-7 TFTP server settings**

**Step2.** Manual configure your IP address as figure bellow:




**Figure 5-8 IP configure manual settings**

**Step3.** Setting up HyperTerminal


To ensure that applications run correctly, the HyperTerminal is used on your computer to get events from the device that running the application. These steps are used to configure the HyperTerminal program:

1. Open HyperTerminal applications as shown in **Figure 5-9**



**Figure 5-9 Launch HyperTerminal Application**

2. The HyperTerminal opens as shown in *Error! Reference source not found.*. Enter the name of connection and click on the **OK** button.



**Figure 5-10 HyperTerminal GUI**


3. The window shown in the **Figure 5-11** appears. Select the COM port appropriate with the COM port that you connect to the board.





**Figure 5-11 Connect using COM8**


4. In the next window set the communication baud rate to 115200, data length to 8, no parity, one stop bit and no flow control, then click **OK** to complete the HyperTerminal configuration. Configure the virtual COM port baud rate and other properties as shown in **Figure 5-12**



**Figure 5-12 COM8 Properties**

5. The HyperTerminal is configured now.

**Step4.** Run Boot loader application.



**Figure 5-13 Bootloader started with no image**

**Step5.** Configure board net IP address

```
shell> ipconfig 0 init
Ethernet device 0 initialization successful.
shell> ipconfig staticip 192.168.1.3 255.255.255.0 192.168.1.1
Static ip bind successful.
shell>
```

**Step5.** Load image to Flash

```
shell> imgload 192.168.1.2 helloworld_extram_d.bin 0x10000 helloworld
```

```

com - HyperTerminal
File Edit View Call Transfer Help

Ethernet device 0 initialization successful.
shell> ipconfig staticip 192.168.1.3 255.255.255.0 192.168.1.1
Static ip bind successful.
shell> imgload 192.168.1.2 helloworld_extram_d.bin 0x10000 helloworld

Downloading file helloworld_extram_d.bin from TFTP server: [192.168.1.2]
#####
Transfer 0x1f560 byte success
Write image to table Success
Listing images...
Table of stored images:
=====
| Index |      Name      | Start address |   Size   | Flash Addr | Auto |
| Timeout|
=====
|   1   | helloworld | 0x00010000 | 0x0001f560 | 0x00f00000 | 1 |
|   5   |             |             |             |             |   |
=====
shell>

```

Connected 0:22:07   Auto detect   115200 8-N-1   SCROLL   CAPS   NUM   Capture   Print echo

**Figure 5-14 Image is stored successful in flash**

### Step6. Run image

```
shell> imggo 1
```

If the Boot loader application is flash to Nand Flash memory by using Ext Nand Download targets, you can boot image from hard reset.