

Rev 5/23/24


[illegible]

<https://github.com/eshazen/blinky-avr-smt>

The rest of the parts are **not** reversible and must be installed the right way around.

Microcontroller (U1)
LEDs (D1-D8 and D11)
Light sensors (D9 and D10)
Battery holder wires

Pin 1 is marked by a dimple in the top of the chip. This should go next to the number “1” on the board.





They should be mounted with the white surface with a transparent window facing up.



LED D11 orientation.
You have to look closely
for this one.


LEDs are the most common
type of component to install
incorrectly!



The light sensors (D9, D10) have
leads of different lengths.
Bend and install as shown.

Long lead in left hole

Trim the extra leads off on the back



J1 is not installed

Install a two-pin header
as shown for the battery.

Install the switch SW1
as shown.

Battery connects with
Red lead to *left*

