

Rugged Connect Quick Start Guide

Welcome to Rugged Connect.

Please scroll down for a quick tutorial on:

1. How to change software Language
2. How to add /delete a Device
3. How to read connected Device(s)
4. How to import or export configurations
5. How to acquire temperature data or change configurations



Rugged

Click on this drop
down box to selected
desired Language of
Software

Serial Number
180116

English

HELP

Device Selection

Default Name ONLINE

T301-1 OFFLINE

L201-2 ONLINE

DATA

DATA LOGS

ALARMS

STATUS

CONFIGURE

Rugged Connect Quick Start Guide

Welcome to Rugged Connect.

Please scroll down for a quick tutorial on:

1. How to change software Language
2. How to add /delete a Device
3. How to read connected Device(s)
4. How to import or export configurations

How to acquire temperature data or change configurations

Click on this Button
to manually add a
device

Click on this Button
to automatically read
connected devices

Add Device

Read Devices

Help File

Document no. MAN0009R01

Copyright Rugged Monitoring Inc.

**L201**Serial Number
180116

Rugged Monitoring Temperature Monitor

English

Device Selection

Default Name ONLINE

T301-1 ONLINE

L201-2 ONLINE

Right click on a
device to Delete
device or
import/export device
configuration

Message Bar to show
important messages
during operation

DATA

DATA LOGS

ALARMS

STATUS

CONFIGURE

HELP

Rugged Connect Quick Start Guide

Welcome to Rugged Connect.

Please scroll down for a quick tutorial on:

1. How to change software Language
2. How to add /delete a Device
3. How to read connected Device(s)
4. How to import or export configurations
5. How to acquire temperature data or change configurations

Page: 1 of 4

Document no. MAN0009R01

Copyright Rugged Monitoring Inc.

Add Device

Read Devices

Help File

Physical device list updated

**L201**Serial Number
180118

Rugged Monitoring Temperature Monitor

English

Device Selection

Default Name

ONLINE

T301-1

OFFLINE

L201-2

ONLINE

Click on any device to
select it

Add Device

Read Devices

Physical device list updated

These menus may vary
depending on type of device
and system configuration

DATA

DATA LOGS

ALARMS

STATUS

CONFIGURE

HELP

SETUP

CHANNELS

COMMUNICATION

CONDITIONS

ANALOG OUTPUTS

RELAYS

DEVICE SETUP

Device Name

L201-2

Location Name

Default Location

Acquisition Mode

☐ Fixed Time ☒ AGC (auto gain)

Hold Last Good

1

Download log files stored in device
memory card

☐ Disabled ☒ Enabled, Logging

Internal Log Rate

10 sec

Use OS Date Time

☐

Date

5/2/2019

Time

8:47:43 PM

Write

Write

Acquire real-time temperature, log temperature on
this computer and many more.

Change device configurations

Check device information and system
configurations

Check alarms and relays status

This Help page. You can also click on
button below to open Software Manual

Default

Read

Write/Save