



Manual

XL Driver Library

.NET Wrapper Description

Version 7.5

English

Imprint

Vector Informatik GmbH
Ingersheimer Straße 24
D-70499 Stuttgart

The information and data given in this user manual can be changed without prior notice. No part of this manual may be reproduced in any form or by any means without the written permission of the publisher, regardless of which method or which instruments, electronic or mechanical, are used. All technical information, drafts, etc. are liable to law of copyright protection.

© Copyright 2010, Vector Informatik GmbH. Printed in Germany.
All rights reserved.

Table of contents

1	Introduction	3
1.1	About this User Manual	4
1.1.1	Access Help and Conventions	4
1.1.2	Certification	5
1.1.3	Warranty	5
1.1.4	Support	5
1.1.5	Registered Trademarks	5
2	.NET Wrapper	7
2.1	Overview	8
2.2	Comfort Layer	9
2.3	General Layer	12
2.3.1	XLClass - Defined Objects	14
2.3.2	XLClass - Defined Enumerations	14
2.4	Including the wrapper in a new .NET Project	16
3	Examples	19
3.1	xICANdemo .NET Easy	20
3.2	xICANdemo .NET Advanced	21
3.3	xILINdemo .NET Advanced	22
3.4	xIDAIOexample .NET Advanced	24
4	Appendix A: Address Table	27

1 Introduction

In this chapter you find the following information:

1.1	About this User Manual	page 4
	Access Help and Conventions	
	Certification	
	Warranty	
	Support	
	Registered Trademarks	

1.1 About this User Manual

1.1.1 Access Help and Conventions

To find information quickly







The user manual provides you the following access help:

- ➔ At the beginning of each chapter you will find a summary of the contents,
- ➔ In the header you can see in which chapter and paragraph you are ((situated)),
- ➔ In the footer you can see to which version the user manual replies.

Conventions

In the two following charts you will find the conventions used in the user manual regarding utilized spellings and symbols.

Style	Utilization
bold	Blocks, surface elements, window- and dialog names of the software. Accentuation of warnings and advices. [OK] Push buttons in brackets File Save Notation for menus and menu entries
Windows	Legally protected proper names and side notes.
Source code	File name and source code.
Hyperlink	Hyperlinks and references.
<STRG>+<S>	Notation for shortcuts.

Symbol	Utilization
	This symbol calls your attention to warnings.
	Here you can find additional information.
	Here is an example that has been prepared for you.
	Step-by-step instructions provide assistance at these points.
	Instructions on editing files are found at these points.
	This symbol warns you not to edit the specified file.

1.1.2 Certification

Certified Quality Management System

Vector Informatik GmbH has ISO 9001:2008 certification. The ISO standard is a globally recognized standard.

1.1.3 Warranty

Restriction of warranty

We reserve the right to change the contents of the documentation and the software without notice. Vector Informatik GmbH assumes no liability for correct contents or damages which are resulted from the usage of the user manual. We are grateful for references to mistakes or for suggestions for improvement to be able to offer you even more efficient products in the future.

1.1.4 Support

You need support?

You can get through to our support at the phone number
+49 711 80670-200 or by fax
+49 711 80670-111
E-Mail: support@vector-informatik.de

1.1.5 Registered Trademarks

Registered trademarks

All trademarks mentioned in this user manual and if necessary third party registered are absolutely subject to the conditions of each valid label right and the rights of particular registered proprietor. All trademarks, trade names or company names are or can be trademarks or registered trademarks of their particular proprietors. All rights which are not expressly allowed, are reserved. If an explicit label of trademarks, which are used in this user manual, fails, should not mean that a name is free of third party rights.

→ **Windows, Windows XP, Windows Vista, Windows 7** are trademarks of the Microsoft Corporation.

2 .NET Wrapper

In this chapter you find the following information:

2.1	Overview	page 8
2.2	Comfort Layer	page 9
2.3	General Layer	page 12
	XLClass - Defined Objects	
	XLClass - Defined Enumerations	
2.4	Including the wrapper in a new .NET Project	page 16

2.1 Overview



Caution: THE INCLUDED WRAPPER IS PROVIDED “AS-IS”. NO LIABILITY OR RESPONSIBILITY FOR ANY ERRORS OR DAMAGES.



Info: The Vector Driver Disk includes a separate .NET wrapper (assembly) for the XL Driver Library: `\Drivers\XL Driver Library\bin\vxlaplapi_NET20.dll`.

Framework .NET 2.0 or higher is required.



Info: In order to run the .NET wrapper in your application the general library `vxlaplapi.dll` must also be placed in the execution folder of your application.



Info: The .NET wrapper only supports CAN, LIN, and DAIO.

Overview

Vector offers an XL Driver .NET wrapper, which allows an easy integration of the XL Driver Library in any .NET environment. This means that Vector XL Interfaces can be accessed from any .NET programming language, like C#, Visual Basic .NET or Delphi .NET (Delphi 8). Examples for these languages are also available.

The XL Driver .NET wrapper consists of the single .NET assembly ***vxlaplapi_NET20.dll*** and offers the complete functionality of the XL Driver Library. The usage is similar to the XL API. There is also a “comfort layer” included, which allows a very easy access to XL Interfaces by only using a few code lines.

Easy and Advanced Examples

The XL Driver Library setup contains a few examples in different .NET languages in order to explain the usage in each environment, split by **Easy** (describing the “comfort layer”) and **Advanced** (describing the detailed wrapper methods).

2.2 Comfort Layer



Info: The comfort layer only supports CAN.

Quick introduction

In order to get a quick idea of the wrapper, we recommend using the comfort layer methods, which keeps the whole initialisation and the handle management in the background.

The comfort layer can be accessed by the class `xlSingleChannelCAN_Port`, which is part of the wrapper.

Class `xlSingleCAN_Port`

```
public xlSingleChannelCAN_Port(String appName,  
                               uint appChannel)
```

Description

This object creates a single port with a single channel, which is opened then. The driver configuration is read from Vector Hardware Config, therefore the application name and the channel number is needed at call.



Info: On the very first call, the application name does not exist in the Vector Hardware Config, but it is automatically created with two CAN channels. Afterwards it is necessary to assign these logical channels to physical channels in the Vector Hardware Config. One channel is used to transmit messages, the other one to receive them.

Input Parameters

- **appName**
Name of the application, registered in Vector Hardware Conf.
- **appChannel**
Channel of the named application.

List of methods The class `xlSingleChannelCAN_Port` contains the following methods:

.xlCheckPort `bool xlCheckPort ()`

Description Checks if the opened port by `xlSingleChannelCAN_Port` object is accessible.

Return value TRUE if accessible, otherwise FALSE.

.xlActivate `bool xlActivate ()`

Description Activates an accessible port.

Return value TRUE if accessible, otherwise FALSE.

.xlResetAcceptanceFilter `bool xlResetAcceptanceFilter ()`

Description Resets all acceptance filters of the opened port.

Return value TRUE if accessible, otherwise FALSE.

.xlCanAddAcceptanceRange `bool xlCanAddAcceptanceRange ()`

Description Adds acceptance filters.

Input Parameters

- **first_id**
First CAN ID of the range.
- **last_id**
Last CAN ID of the range.

Return value TRUE if accessible, otherwise FALSE.

.xlTransmit

```
bool xlTransmit(uint id, ushort dlc, UInt64 data)
```

Description

Transmits a single CAN message with a given ID, DLC and the data (8 byte value).

Input Parameters

- ➔ **id**
CAN ID.
- ➔ **dlc**
Data length code.
- ➔ **Data**
8 byte value to be transmitted.

Return value

TRUE if accessible, otherwise FALSE.

.xlReceive

```
bool xlReceive(ref XLClass.xl_event rxEvent)
```

Description

Reads CAN events (if available) from hardware queue of the XL Interface.

Input Parameters

- ➔ **rxEvent**
Reference to event buffer (event type defined in namespace XLClass)

Return value

TRUE if accessible, otherwise FALSE.

.xlPrintConfig

```
bool xlPrintConfig()
```

Description

Prints the current configuration of the port to the console.

Return value

TRUE if accessible, otherwise FALSE.

.xlPrintRx

```
bool xlPrintRx(XLClass.xl_event receivedEvent)
```

Description

Prints the received message to the console.

Input Parameters

- ➔ **receivedEvent**
Event to display (event type defined in namespace XLClass).

Return value

TRUE if accessible, otherwise FALSE.

2.3 General Layer

General layer of the .NET wrapper

The complete XL API can be accessed by the general layer, which is included in the class **XLDriver**. For further details on this methods, please look up the general XL API Description.



Info: The method names of the wrapper differs only in the prefix, e.g.

Wrapper	: XL_OpenDriver
XL API	: xlOpenDriver

Methods of the general layer

The following methods are available after the instantiation of **XLDriver**:

Class XLDriver

```
.XL_ActivateChannel
.XL_CanAddAcceptanceRange
.XL_CanFlushTransmitQueue
.XL_CanRemoveAcceptanceRange
.XL_CanRequestChipState
.XL_CanResetAcceptance
.XL_CanSetChannelAcceptance
.XL_CanSetChannelBitrate
.XL_CanSetChannelMode
.XL_CanSetChannelOutput
.XL_CanSetChannelParams
.XL_CanSetChannelParamsC200
.XL_CanSetChannelTransceiver
.XL_CanTransmit
.XL_CloseDriver
.XL_ClosePort
.XL_DAIORequestMeasurement
.XL_DAIOSetAnalogOutput
.XL_DAIOSetAnalogParameters
.XL_DAIOSetAnalogTrigger
.XL_DAIOSetDigitalOutput
.XL_DAIOSetDigitalParameters
.XL_DAIOSetMeasurementFrequency
.XL_DAIOSetPWMOutput
.XL_DeactivateChannel
.XL_FlushReceiveQueue
.XL_GenerateSynPulse
.XL_GetApplConfig
```

```

.XL_GetChannelIndex
.XL_GetDriverConfig
.XL_GetErrorString
.XL_GetEventString
.XL_GetReceiveQueueLevel
.XL_GetSyncTime
.XL_LinSendRequest
.XL_LinSetChannelParams
.XL_LinSetChecksum
.XL_LinSetDLC
.XL_LinSetSlave
.XL_LinSetSleepMode
.XL_LinWakeUp
.XL_OpenDriver
.XL_OpenPort
.XL_PopupHwConfig
.XL_Receive
.XL_ResetClock
.XL_SetApplConfig
.XL_SetNotification
.XL_SetTimerRate
...

```




Info: The complete list can be looked up with help of the intellisense function in your IDE:

```

XLDriver myApp = new XLDriver();
myApp.|

```



Info: Some of these methods have parameters expecting objects. All needed objects are already defined in the Class `XLClass` and ready to use. Most of these classes can be found again in the XL API in the form of structures (instead of a class). Please refer to the general XL API Description for further details on these structures.

The `XLClass` also offers a wide range of enumerations for an easy access to values and definitions. See the following tables for the detailed class information.

2.3.1 XLClass - Defined Objects

<code>xl_driver_config</code>	Needed by method <code>XL_GetDriverConfig</code> . Contains driver configuration.
<code>xl_event_collection</code>	Needed by method <code>XL_CanTransmit</code> . Contains one or more <code>xl_events</code> (see below) for transmission.
<code>xl_event</code>	Contains data to be transmitted.
<code>xl_bus_params</code>	Used by subclass <code>xl_channel_config</code> .
<code>xl_channel_config</code>	Used by subclass <code>xl_driver_config</code> .
<code>xl_can_message</code>	Used by subclass <code>xl_event</code> .
<code>xl_chip_params</code>	Used by method <code>XL_CanSetChannelParams</code> .
<code>xl_linStatPar</code>	Used by method <code>XL_LinSetChannelParams</code> .

2.3.2 XLClass - Defined Enumerations



Info: Please refer to `vxlapl.h` for all available definitions, or use the integrated intellisense function of your IDE to look up the available enumerations.

Each enumeration can be directly used without instantiation of `XLClass` by using `XLClass.<subclass>.<enumeration_value>`,

e.g. `XLClass.XLstatus.XL_SUCCESS`.

<code>XLstatus</code>	<ul style="list-style-type: none"> → <code>.XL_SUCCESS</code> → <code>.XL_PENDING</code> → <code>.XL_ERR_QUEUE_IS_EMPTY</code> → <code>.XL_ERR_QUEUE_IS_FULL</code> → <code>.XL_ERROR</code> → ...
<code>XLbusTypes</code>	<ul style="list-style-type: none"> → <code>.XL_BUS_TYPE_NONE</code> → <code>.XL_BUS_TYPE_CAN</code> → <code>.XL_BUS_TYPE_HWSYNC</code> → ...
<code>XLevenType</code>	<ul style="list-style-type: none"> → <code>.XL_NO_COMMAND</code> → <code>.XL_RECEIVE_MSG</code> → <code>.XL_CHIP_STATE</code> → <code>.XL_RECEIVE_DAIO_DATA</code> → ...
<code>XLmessageFlag</code>	<ul style="list-style-type: none"> → <code>.XL_CAN_MSG_FLAG_ERROR_FRAME</code>

- ➔ .XL_CAN_MSG_FLAG_OVERRUN
- ➔ .XL_LIN_MSGFLAG_CRCERROR
- ➔ ...

XLtransceiverTypes

- ➔ .XL_TRANSCEIVER_TYPE_NONE
- ➔ .XL_TRANSCEIVER_TYPE_CAN_251
- ➔ .XL_TRANSCEIVER_TYPE_DAIO_8444_OPTO
- ➔ ...

XLhwTypes


- ➔ .XL_HWTYPE_NONE
- ➔ .XL_HWTYPE_VIRTUAL
- ➔ .XL_HWTYPE_CANCARDXL
- ➔ .XL_HWTYPE_CANBOARDXL_PXI
- ➔ ...

2.4 Including the wrapper in a new .NET Project


General notes

If the starting point of your project is an empty .NET application, do the following in order to use the XL Driver .NET Wrapper. These steps are related to Visual Studio 2008 and C# but similar in any other IDE.


1. Copy the general XL Driver Library `vxlapi.dll` to your execution folder of your project (this might be `\Debug` or `\Release`).
2. In VS2008 click with the right mouse button on **References** (Solution Explorer) of your project and select **Add Reference...**



3. Browse for the .NET wrapper `vxlapi_NET20.dll`.



4. Close the dialog with **[OK]**. The DLL appears in the Solution Explorer.



5. Enter the following line in the top of your source code to access the wrapper:

```
using vxlapi_NET20;
```

6. Now, you are able to create an object from class XLDriver:

```
private static XLDriver MyApp = new XLDriver();
```

7. Try to open the port by entering the line:

```
MyApp.XL_OpenDriver();
```



Info: Take a look at our examples (source code) on the Driver Disk for further information.

3 Examples

In this chapter you find the following information:


3.1	xICANdemo .NET Easy	page 20
3.2	xICANdemo .NET Advanced	page 21
3.3	xILINdemo .NET Advanced	page 22
3.4	xIDAIOexample .NET Advanced	page 24



Info: All examples are available for C#, Visual Basic .NET, and Delphi .NET (Delphi 8).


3.1 xICANdemo .NET Easy

Screenshot



CAN loop application This example is a simple CAN loop application which demonstrates the usage of the comfort layer. The access to the XL Interfaces is done by using the class `xlSingleChannelCAN_Port` while the whole configuration of the application is done through the Vector Hardware Config.

Vector Hardware Config



Starting the example When the application starts, it looks for the application **xICANdemo NET** in the **Vector Hardware Config** and reads its configuration there, e.g. the assigned XL Interfaces. Since such application is not registered at the very first time, it is automatically created with two CAN channels. Afterwards the channel assignment can be

quickly done in **Vector Hardware Config**.

Send and receive messages

When the XL Interface(s) are assigned in the **Vector Hardware Config** and the physical channels are connected, CAN messages can be transmitted by pressing the **[ENTER]** key. The message is sent over the first configured channel and is received by the second one.

3.2 xICANdemo .NET Advanced

Screenshot

```

xICANdemo.NET1.1 C# Advanced V1.2
Copyright (c) 2006 by Vector Informatik GmbH. All rights reserved.

Open Driver      : XL_SUCCESS
Get Driver Config: XL_SUCCESS
DLL Version      : 5.7.16
Channels found   : 4

[0] CANcardXL Channel 1
  - Channel Mask : 1
  - Transceiver Name: CANcab 1041opto <Highspeed>
  - Serial Number : 1000


[1] CANcardXL Channel 2
  - Channel Mask : 2
  - Transceiver Name: CANcab 1041opto <Highspeed>
  - Serial Number : 1000

[2] Virtual Channel 1
  - Channel Mask : 4
  - Transceiver Name:
  - Serial Number : 0
  
```

CAN loop application

This example is a simple CAN loop application which demonstrates the usage of the general wrapper in the common way. The access to the XL Interfaces is done by using the class `XLDriver` while the whole configuration of the application is done over the **Vector Hardware Config**.

Vector Hardware Config



Starting the example

When the application starts, it looks for the application **xICANdemo NET** in the **Vector Hardware Config** and reads its configuration there, e.g. the assigned XL

Interfaces. Since such application is not registered at the very first time, it is automatically created with two CAN channels. Afterwards the channel assignment can be quickly done in **Vector Hardware Config**.

Send and receive messages

When the XL Interface(s) are assigned in the **Vector Hardware Config**, and the physical channels are connected, CAN messages can be transmitted by pressing the **[ENTER]** key. The message is sent over the first configured channel and is received by the second one.

3.3 xLINdemo .NET Advanced

Screenshot

```

C:\Framework 1.1\xLINdemo.NET11_C#_Advanced.exe
APPLICATION CONFIGURATION
-----
Configured Hardware Channel : CANcardXL Channel 2
Hardware Driver Version    : 6.0.14
Used Transceiver           : LINcab 6259opto
-----

Open Port                  : XL_SUCCESS
Set Channel Parameters <MASTER>: XL_SUCCESS
Set DLC <MASTER>           : XL_SUCCESS
Activate Channel           : XL_SUCCESS


Set Channel Parameters <SLAVE> : XL_SUCCESS
Set SLAVE                  : XL_SUCCESS
Activate Channel           : XL_SUCCESS

Set Notification           : XL_SUCCESS
Start Rx Thread...
Press <ENTER> to request LIN data. Press <x>.<ENTER> to close application.
XL_LIN_SLEEP
  
```

LIN loop application

This example is a simple LIN loop application which demonstrates the usage of the general wrapper in the common way. The access to the XL Interfaces is done by using the class `XLDriver` while the whole configuration of the application is done over the Vector Hardware Config.

Vector Hardware Config



Starting the example

When the application starts, it looks for the application **xLINdemo NET** in the **Vector**

Hardware Config and reads its configuration there, e.g. the assigned XL Interfaces. Since such application is not registered at the very first time, it is automatically created with two LIN channels. Afterwards the channel assignment can be quickly done in **Vector Hardware Config**.


Send and receive messages

When the XL Interface(s) are assigned in the **Vector Hardware Config**, and the physical channels are connected, LIN messages can be transmitted by pressing the **[ENTER]** key. The message is sent over the first configured channel and is received by the second one.

3.4 xIDAIOexample .NET Advanced

Description

This example demonstrates the setup of a single IOcab 8444opto for a test, and how to access the inputs and outputs for cyclically measurement.



```

C:\xIDAIOexample.exe

>> Press [ENTER] during measurement to toggle all switches.
>> Press [x] to stop measurement.
>> Press now any key to start...

-----
>> Measure every 500ms
- AIO0      : 4064mV
- AIO1      : 0mV
- AIO2      : 0mV
- AIO3      : 0mV
- Switch selected : DIO0/DIO1  DIO4/DIO5  DIO6/DIO7
- Switch states  : OPEN
- Digital Port   : DIO7:DIO6:DIO5:DIO4:DIO3:DIO2:DIO1:DIO0:<value>
                   1!  0!  0!  1!  0!  0!  0!  0! <90>


- AIO0      : 4064mV
- AIO1      : 0mV
- AIO2      : 0mV
- AIO3      : 0mV
- Switch selected : DIO0/DIO1  DIO4/DIO5  DIO6/DIO7
- Switch states  : CLOSED
- Digital Port   : DIO7:DIO6:DIO5:DIO4:DIO3:DIO2:DIO1:DIO0:<value>
                   1!  1!  1!  1!  0!  1!  0!  0! <f4>
  
```

Pin definitions

The following pins of the IOcab 8444opto are used in this example:

- AIO0 (pin 14): Analog output.
- AIO1 (pin 7): Analog input.
- AIO2 (pin 15): Analog input.
- AIO3 (pin 8): Analog input.
- DIO0 (pin 1): Digital output (shared electronic switch with DIO1).
- DIO1 (pin 9): Digital output (supplied by DIO0, when switch is closed).
- DIO2 (pin 2): Digital input.
- DIO3 (pin 10): Digital input.

Setup



Info: The internal switch between DIO0 (supplied by AIO0) and DIO1 is closed/opened with `xIDAIOSetDigitalOutput`. If the switch is closed, the applied voltage at DIO0 can be measured at DIO1.

Keyboard commands When the application is running, there is a couple of keyboard commands:

Key	Command
ENTER	Toggle digital output.
x	Closes application.



Example: Display output of xIDAIOexample.

```

AIO0      : 4032mV
AIO1      : 0mV
AIO2      : 0mV
AIO3      : 0mV
Switch selected : DIO0/DIO1
Switch states  : OPEN
Digital Port   : DIO7 DIO6 DIO5 DIO4 DIO3 DIO2 DIO1 DIO0 val
                  0    0    0    0    0    0    0    1 (1)

```

Explanation

- "AIO0" displays 4032mV, since it is set to output with maximum output level.
- "AIO1" displays 0mV, since there is no applied voltage at this input.
- "AIO2" displays 0mV, since there is no applied voltage at this input.
- "AIO3" displays 0mV, since there is no applied voltage at this input.
- "Switch selected" displays DIO0/DIO1 (first switch)
- "Switch states" displays the state of switch between DIO0/DIO1
- "Digital Port" shows the single states of DIO7...DIO0:
 - DIO0: displays '1' (always '1', due the voltage supply)
 - DIO1: displays '0' (switch is open, so voltage at DIO0 is not passed through)
 - DIO2: displays '0' (output of DIO1)
 - DIO3: displays '0' (output of DIO1)
 - DIO4: displays '0' (n.c.)
 - DIO5: displays '0' (n.c.)
 - DIO6: displays '0' (n.c.)
 - DIO7: displays '0' (n.c.)



Example: Display output of xIDAIOexample.

```

AIO0      : 4032mV
AIO1      : 0mV
AIO2      : 4032mV
AIO3      : 0mV
Switch selected : DIO0/DIO1
Switch state    : CLOSED
Digital Port     : DIO7 DIO6 DIO5 DIO4 DIO3 DIO2 DIO1 DIO0 val
                  0    0    0    0    1    1    1    1 (f)

```

- Explanation**
- "AIO0" displays 4032mV, since it is set to output with maximum output level.
 - "AIO1" displays 0mV, since there is no applied voltage at this input.
 - "AIO0" displays 4032mV, since it is connected to AIO0.
 - "AIO3" displays 0mV, since there is no applied voltage at this input.
 - "Switch selected" displays DIO0/DIO1 (first switch)
- "Switch state" displays the state of switch between DIO0/DIO1
 "Digital Port" shows the single states of DIO7...DIO0:
- DIO0: displays '1' (always '1', due the voltage supply)
 - DIO1: displays '1' (switch is open, so voltage at DIO0 is not passed through)
 - DIO2: displays '1' (output of DIO1)
 - DIO3: displays '1' (output of DIO1)
 - DIO4: displays '0' (n.c.)
 - DIO5: displays '0' (n.c.)
 - DIO6: displays '0' (n.c.)
 - DIO7: displays '0' (n.c.)



Info: If you try to connect DIO1 (when output is '1') to one of the inputs DIO4...DIO7, you will notice no changes on the screen. The digital output is supplied by the IOcab 8444opto itself, where the maximum output is 4.096V. Due to different thresholds, the inputs DIO4...DIO7 needs higher voltages ($\geq 4.7V$) to toggle from '0' to '1'.

Source code The source file `xlDAIOexample.c` contains all needed functions:

Function `InitIOcab`

Function Description This function opens the driver and reads the current hardware configuration. (`xlGetHardwareConfig`). Afterwards a valid `channelMask` is calculated and **one** port is opened.

Function `ToggleSwitch`

Function Description This function toggles all switches and passes through the applied voltage at DIO0 to DIO1.

Function `CloseExample`

Function Description Closes the driver and the application.

4 Appendix A: Address Table

Vector Informatik GmbH	Vector Informatik GmbH Ingersheimer Str. 24 70499 Stuttgart Germany Phone : +49 711 80670-0 Fax : +49 711 80670-111 info@de.vector.com http://www.vector-informatik.com
Vector CANtech, Inc.	Vector CANtech, Inc. Suite 550 39500 Orchard Hill Place Novi, Mi 48375 USA Phone : +1 248 449 9290 Fax : +1 248 449 9704 info@us.vector.com http://www.vector-cantech.com
Vector Japan Co., Ltd.	Vector Japan Co., Ltd. Seafort Square Center Bld. 18F 2-3-12, Higashi-shinagawa, Shinagawa-ku 140-0002 Tokyo Japan Phone : +81 3 5769 7800 Fax : +81 3 5769 6975 info@jp.vector.com http://www.vector-japan.co.jp
Vector France SAS	Vector France SAS 168, Boulevard Camélinat 92240 Malakoff France Phone : +33 1 4231 4000 Fax : +33 1 4231 4009 info@fr.vector.com http://www.vector-france.com
VecScan AB	VecScan AB Theres Svenssons Gata 9 41755 Göteborg Sweden Phone : +46 31 764 7600 Fax : +46 31 764 7619 info@se.vector.com http://www.vecscan.com

Vector Korea IT Inc.
Vector Korea IT Inc.
Daerung Post Tower III, 508
182-4 Guro-dong, Guro-gu
Seoul 152-790
Republic of Korea
Phone : +82 2 2028 0600
Fax : +82 2 2028 0604
info@kr.vector.com
<http://www.vector-korea.com/>

Vector GB Limited
Vector GB Limited
Rhodium, Central Boulevard
Blythe Valley Park
Solihull, Birmingham
West Midlands, B90 8AS
United Kingdom
Phone : +44 121 50681-50
Fax : +44 121 50681-66
info@uk.vector.com
<http://www.vector-gb.co.uk>

Get more Information!

Visit our Website for:

- > News
- > Products
- > Demo Software
- > Support
- > Training Classes
- > Addresses

www.vector.com